

# IBM Power System S914 server helps deliver the entry offering into the POWER9 family of servers, offers industry-leading integrated security and reliability, and is cloud-enabled out of the box with PowerVM technology

## Table of contents

<a href="#">2 Overview</a>	<a href="#">39 Publications</a>
<a href="#">3 Key prerequisites</a>	<a href="#">41 Technical information</a>
<a href="#">3 Planned availability date</a>	<a href="#">50 Terms and conditions</a>
<a href="#">3 Description</a>	<a href="#">56 Prices</a>
<a href="#">28 Product positioning</a>	<a href="#">73 Order now</a>
<a href="#">29 Product number</a>	<a href="#">74 Corrections</a>

## At a glance

The IBM<sup>(R)</sup> Power<sup>(R)</sup> System S914 (9009-41A) server easily integrates into your organization's cloud and cognitive strategy and delivers industry-leading price/performance for your mission-critical workloads.

- Deliver superior price/performance for your mission-critical applications with room to scale in IBM AIX<sup>(R)</sup>, IBM i, and Linux<sup>(R)</sup> environments.
- Help guard against security threats because of the server's features, reliability, and performance.
- Harness the integrated virtualization capabilities of the server to rapidly deploy, optimize, and recover workloads.
- Migrate from previous IBM Power Systems<sup>TM</sup> servers with Live Partition Mobility capabilities. Every new Power S914 server comes with a temporary IBM PowerVM<sup>(R)</sup> license for your old server to support a seamless move to IBM POWER9<sup>TM</sup> technology-based servers.
- Use this cloud-enabled server to build an agile, containerized cloud on a server platform that is optimized for data and cognitive services.
- Extend IBM i, the integrated operating system, and connect to the cognitive capabilities of the IBM Cloud using secure APIs.

The Power S914 server is a powerful 1-socket server that ships with up to eight activated cores and I/O configuration flexibility to meet today's growth and tomorrow's processing needs. The server features:

- The following fully activated POWER9 processor module configurations in a 19-inch rack-mount, 4U (EIA units) form factor.
  - 4-core typical 2.3 to 3.8 GHz (max)
  - 6-core typical 2.3 to 3.8 GHz (max)
  - 8-core typical 2.8 to 3.8 GHz (max) (rack-mount configuration only)
- Up to 1024 GB of DDR4 memory
- Storage backplane options:
  - Eighteen SFF-3 Bays/Dual IOA with Write Cache.
  - Twelve SFF-3 Bays/RDX Bays.

- Split feature to 6+6 SFF Bays: Add a second SAS Controller.
- Twelve SFF-3 Bays/RDX Bay/2 EXT PT.
- Optional PCIe3 NVMe carrier card with two M.2 module slots
- Expansion capabilities for the EXP24SX SFF Gen2 bay Drawer
- Hot-swap PCIe Gen4 and Gen3 slots
- Integrated:
  - Service processor
  - EnergyScale™ technology
  - Hot-swap and redundant cooling
  - USB 3.0 ports
  - Two HMC ports
  - One system port with RJ45 connector
- Two hot-plug, redundant power supplies
- 19-inch rack-mounting hardware (4U) and tower option

---

## Overview

---

The next generation of Power Systems servers with POWER9 technology is built with innovations that can help deliver security and reliability for the data-intensive workloads of today's enterprises. POWER9 technology is designed from the ground up for data-intensive workloads like databases and analytics.

Changes in the memory subsystem and the use of industry standard memory DIMMs take POWER9 technology to the next level by superseding a number of existing price/performance offerings. Designed to run commercial, cognitive, and database workloads, POWER9 technology provides a highly competitive server platform. Client references indicate POWER<sup>®</sup> servers help provide a robust and secure backbone for their IT infrastructure. More companies are using POWER technology in their IT infrastructure down from the shop level to large data center deployments.

The Power S914 server by default has its Power Management mode set to Dynamic Performance. This mode can dynamically optimize the processor frequency at any given time based on CPU utilization and operating environmental conditions. For a description of this feature and other power management options available for this server, see the [IBM EnergyScale for POWER9 Processor-Based Systems](#) website.

The Power S914 server supports one-processor sockets, offering 4-core typical 2.3 to 3.8 GHz (max), or 6-core typical 2.3 to 3.8 GHz (max), or 8-core typical 2.8 to 3.8 GHz (max) POWER9 processor-based configurations in a 19-inch rack-mount, 4U (EIA units) drawer or desk-side configuration. All the cores are active.

The Power S914 server supports a maximum of 16 DDR4 DIMM slots. Memory features supported are 16 GB, 32 GB, and 64 GB, and run at speeds of 2133, 2400, and 2666 Mbps, allowing for a maximum system memory of 1024 GB.

- Rich I/O options in the system unit include:
  - One PCIe x16 Gen4, full-height, half-length slot (This slot can contain a CAPI-capable card or an I/O drawer interface card.)
  - Two PCIe x16 Gen3, full-height, half-length slots (not CAPI)
  - One PCIe x8 Gen4, full-height, half-length slot (with x16 connector) (CAPI)
  - Four PCIe x8 Gen3, full-height, half-length slots (One of these slots is used for the required base LAN adapter.)
  - Eighteen or twelve 2.5-in. SFF disk bays
  - RAID 0, 5, 6, 10, 5T2, 6T2, and 10T2 support
  - One RDX bay (only available with x12 disk bays, not available with x18 disk bays)

- One PCIe G3 x8 slot for 1 GbE 4-port LAN controller integrated
- PCIe3 NVMe carrier card with two M.2 module slots
- One front and two rear USB 3.0 ports
- Service processor
- 1+1 Redundant hot-swap AC power supplies in each enclosure
- 19-inch rack-mount 4U or desk-side configuration
- IBM PowerVM

---

## Feature exchange

---

Not applicable.

---

## Key prerequisites

---

An IBM i or AIX operating system. See the [Software requirements](#) section for details.

---

## Planned availability date

---

March 20, 2018

---

## Description

---

The POWER9 scale-out family is the first set of entry servers that comes completely cloud-enabled out of the box with integrated PowerVM Enterprise capabilities.

Additionally, on-chip analytics and algorithms help clients run their workloads at an optimized processor frequency for performance and throughput. Live Partition Mobility capabilities are built in, to cloud-enable your POWER9 infrastructure and help you migrate from previous Power Systems. Every new S914 also has the option of a temporary PowerVM license for your old server to support a seamless move of workloads to POWER9. The new server has built-in security that can help you to be ready for current and future security threats.

The Power S914 server supports one-processor sockets, offering 4-core typical 2.3 to 3.8 GHz (max), or 6-core typical 2.3 to 3.8 GHz (max) or 8-core typical 2.8 to 3.8 GHz (max) POWER9 processor-based configurations in a 19-inch rack-mount, 4U (EIA units) drawer or desk-side configuration. All the cores are active. The server supports a maximum of 16 DDR4 DIMM slots. Memory features supported are 16 GB, 32 GB, and 64 GB and run at speeds of 2133, 2400, and 2666 Mbps, allowing for a maximum system memory of 1024 GB.

### Summary of standard features for Power S914 server:

- POWER9 processor modules:
  - 4-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor (#EP10)
  - 6-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor (#EP11)
  - 8-core, typical 2.8 to 3.8 GHz (max) POWER9 Processor (#EP12) (rack-mount configuration only)
- High-performance Mbps DDR4 ECC memory
  - 16 GB (#EM62), 32 GB (#EM63), or 64 GB (#EM64) memory features
  - Up to 1024 GB of DDR4 memory with one Power Systems processor
- Storage feature:
  - 12 SFF-3 Bays/RDX Bays.

- Optionally, split the above SFF-3 bays and add a second integrated SAS controller without cache.
- 18 SFF-3 Bays/Dual IOA with Write Cache and External SAS port.
- 12 SFF-3 Bays/RDX Bay/Dual IOA with Write Cache and External SAS port.
- Optionally, attach an EXP12SX/EXP24SX SAS HDD/SSD Expansion Drawer to the dual IOA.
- Up to two PCIe3 NVMe carrier cards with two M.2 module slots (with up to four Mainstream 400 GB SSD NVMe M.2 modules)
  - A quantity of one PCIe3 NVMe carrier card can be ordered only with storage backplane. If a PCIe3 NVMe carrier card is ordered with a storage backplane, then the optional split feature is not supported.
- PCIe slots with single processor:
  - One x16 Gen4 full-height, half-length (CAPI)
  - One x8 Gen4 full-height, half-length (with x16 connector) (CAPI)
  - Two x8 Gen3 full-height, half-length (with x16 connectors)
  - Four x8 Gen3 full-height, half-length (One of these slots is used for the required base LAN adapter.)
- Integrated:
  - Service processor
  - EnergyScale technology
  - Hot-swap and redundant cooling
  - One front USB 3.0 ports
  - Two rear USB 3.0 ports
  - Two HMC 1 GbE RJ45 ports
  - One system port with RJ45 connector
  - Four hot-plug, redundant power supplies
  - 19-inch rack-mounting hardware (4U)

## **PowerVM**

PowerVM, which delivers industrial-strength virtualization for AIX and Linux environments on POWER processor-based systems, has been enhanced with a virtualization-oriented performance monitor, and performance statistics are available through the HMC. These performance statistics can be used to understand the workload characteristics and to prepare for capacity planning.

## **S914 Capacity Backup (CBU) for IBM i**

Power S914 (9009-41A) CBU Offering

For IBM i OS:

The Power S914 (9009-41A) CBU designation enables you to temporarily transfer IBM i processor license entitlements and IBM i user license entitlements purchased for a primary machine to a secondary CBU-designated system for HA/DR operations. Temporarily transferring these resources instead of purchasing them for your secondary system may result in significant savings. Processor activations cannot be transferred.

The CBU specify feature 0444 is available only as part of a new server purchase. Certain system prerequisites must be met, and system registration and approval are required before the CBU specify feature can be applied on a new server. Standard IBM i terms and conditions do not allow either IBM i processor license entitlements or IBM i user license entitlements to be transferred permanently or temporarily. These entitlements remain with the machine they were ordered for. When you register the association between your primary and on-order CBU system, you must agree to certain terms and conditions regarding the temporary transfer.

After a new CBU system is registered along with the proposed primary system and the configuration is approved, you can temporarily move your optional IBM i processor license entitlement and IBM i user license entitlements from the primary system to the CBU system when the primary system is down or while the primary system processors are inactive. The CBU system can then support failover and role swapping for a full range of test, disaster recovery, and high availability scenarios. Temporary entitlement transfer means that the entitlement is a property transferred from the primary system to the CBU system and may remain in use on the CBU system as long as the registered primary and CBU system are in deployment for the high availability or disaster recovery operation. The intent of the CBU offering is to enable regular role-swap operations. The primary machine must be in the same enterprise as the CBU system. The Solution Editions are not eligible for CBU status.

The Power S914 server is available with six or eight cores in the P10 software tier and four cores in the P05 software tier.

#### **S914 SW tiers for IBM i on 9009-41A**

- The 4-core processor (#EP10, QPRCFEAT EP10) is IBM i SW tier P05.
- The 6-core processor (#EP11, QPRCFEAT EP11) is IBM i SW tier P10.
- The 8-core processor (#EP12, QPRCFEAT EP12) is IBM i SW tier P10.

#### **For the Power S914 CBU server in the P10 software tier**

The primary systems for a Power S914 (9009-41A) CBU server with a IBM i P10 software tier can be a POWER8<sup>(R)</sup> or POWER9 server with a P10 or P20 software tier listed below:

- Power S824 (8286-42A)
- Power S814 6-core or 8-core (8286-41A)
- Power S822 (8284-22A)
- Power S924 (9009 42A)
- Power S914 6-core or 8-core (9009-41A)
- Power S922 (9009-22A)

Before you can temporarily transfer IBM i user entitlements, you must have more than the minimum number of IBM i user entitlements on a primary server. You can then transfer any IBM i user entitlements above the minimum, assuming the total IBM i users on the primary system do not require the IBM i entitlement you want to transfer during the time of the transfer. The Power S924 and S824 servers do not have IBM i user entitlements to transfer, only processor entitlements. For a P10 primary, the minimum number of IBM i user entitlements on the eligible P10 POWER9 and POWER8 servers are:

- Power S814 6-core or 8-core (8286-41A): 10 users
- Power S822 (8284-22A): 10 users
- Power S914 6-core or 8-core (9009-41A): 10 users
- Power S922 (9009-22A): 10 users

#### **For the Power S914 CBU server in the P05 software tier**

The primary systems for a Power S914 (9009-41A) CBU server with a IBM i P05 software tier can be a POWER8 or POWER9 server with a P05 or P10 software tier listed below:

- Power S814 (8286-41A) 4, 6, or 8 core
- Power S822 (8284-22A)
- Power S914 (9009-41A) 4, 6, or 8 core
- Power S922 (9009-22A)

Before you can temporarily transfer IBM i user entitlements, you must have more than the minimum number of IBM i user entitlements on a primary server. You can then transfer any IBM i user entitlements above the minimum, assuming the total IBM i users on the primary system do not require the IBM i entitlement you want to transfer during the time of the transfer. The minimum number of IBM i user entitlements on the P05 or P10 POWER9 and POWER8 with IBM i user entitlements are:

- Power S814 4 core (8286-41A): 5 users
- Power S814 6 core or 8 core (8286-41A): 10 users
- Power S822 (8284-22A): 10 users
- Power S914 4 core (9009-41A): 5 users
- Power S914 6 core or 8 core (9009-41A): 10 users
- Power S922 (9009-22A): 10 users

For example, if you have a 2-core server as your primary system with two IBM i processor license entitlements (one above the minimum) and 50 IBM i user entitlements (20 above the minimum), you can temporarily transfer up to one IBM i entitlement and up to 20 user entitlements. During this temporary transfer, the CBU system's internal records of its total number of IBM i processor and user license entitlements is not updated, and you may see IBM i license noncompliance warning messages from the CBU system.

If your primary or CBU machine is sold or discontinued from use, any temporary entitlement transfers must be returned to the machine on which they were originally acquired. For CBU registration, terms and conditions, and further information, see the [IBM Power Systems: Capacity BackUp](#) website.

#### **4-core S914 processor feature**

The 4-core Power S914 server offers entry clients running AIX, IBM i, or Linux a entry server based on POWER9 technology. It uses a typical 2.3 to 3.8 GHz (max) POWER9 Processor Card (#EP10) with processor core activation feature (#EP40). All four processor cores must be activated, but factory deconfiguration feature (#2319) is supported. The chargeable feature EP40 is used for these activations.

There is no upgrade to increase the cores on this feature. This server supports AIX, IBM i, and Linux, but is especially attractive to IBM i clients with its P05 software tier. The Capacity Backup option for IBM i (#0444) is supported. The 4-core S914 server supports the 16 GB memory feature (#EM62). A maximum of four of these features is supported for a system maximum of 64 GB. The 4-core S914 server supports a maximum of 10 disk drives or 10 SSDs or a combination of 10 disks and SSDs in the system unit. This is true with any of the storage backplane options selected. SAS drives located in feature code I/O drawers such as the EXP24SX (#ESLS) are not supported. Attachment to SANs is supported. The following SFF-3 SAS drives are supported in the SAS bays of the 4-core S914 system unit:

#### **15k rpm disk drives**

- 300 GB 15k rpm disk drive (#ESDB) 5xx byte blocks (AIX/Linux)
- 283 GB 15k rpm disk drive (#ESDA) 5xx byte blocks (IBM i)
- 300 GB 15k rpm disk drive (#ESFB) 4k byte blocks (AIX/Linux)
- 283 GB 15k rpm disk drive (#ESFA) 4k byte blocks (IBM i)
- 283 GB 15K rpm disk drive (#ESNJ) 4k byte blocks (IBM i)
- 300 GB 15K rpm disk drive (#ESNK) 4k byte blocks (AIX/Linux)

#### **10k rpm disk drives**

- 600 GB 10k rpm disk drive (#ESD5) 5xx byte blocks (AIX/Linux)
- 571 GB 10k rpm disk drive (#ESD4) 5xx byte blocks (IBM i)
- 600 GB 10k rpm disk drive (#ESF5) 4k byte blocks (AIX/Linux)

- 571 GB 10k rpm disk drive (#ESF4) 4k byte blocks (IBM i)

## SSDs

- 387 GB SSD (#ES7K and #ES7L) 5xx byte blocks (eML4 technology)
- 387 GB SSD (#ES8N and #ES8P) 4k byte blocks (eML4 technology)
- 387 GB SSD (#ESG9 and #ESGA) 5xx byte blocks (Enterprise technology)
- 387 GB SSD (#ESGD and #ESGE) 4k byte blocks (Enterprise technology)
- 931 GB SSD (#ES83 and #ES84) 4k byte blocks (Mainstream technology)

Other SFF-3 drives are not supported. Note that 4k byte drives are generally cheaper than 5xx byte drives.

The 4-core S914 server has seven PCIe Gen3 slots. One slot is used by one 4-port 1 Gb Ethernet adapter. If the expanded function backplane is chosen, another PCIe port is used, leaving five ports.

The Capacity BackUp specify feature (#0444) is supported with the 4-core processor card (#EP10) in IBM i environments. With its P05 software, it can be paired with a POWER7<sup>(R)</sup>, POWER7 +, or POWER8 server with P05 or P10 software tier.

The PCIe expansion drawer (#EMX0) and EXP24SX /EXP12SX SAS Storage Enclosures (#ESLS/ELLS or #ESLL/ELLL) do not apply to the 4-core configuration S914 server.

## IBM i Solution Edition for S914

The IBM i Solution Editions are designed to help you take advantage of the combined experience and expertise of IBM and ISVs in building business value with your IT investments. A qualifying purchase of software, maintenance, services, or training for a participating ISV solution is required when purchasing an IBM i Solution Edition.

The Power S914 Solution Edition feature 4928 supports 4-core and feature 4927 supports 6-core configurations. For a list of participating ISVs, registration form, and additional details, see the [IBM i Solution Editions](#) website.

## IBM i Express<sup>(R)</sup> Edition for S914

IBM i clients acquiring a new 4-core or 6-core Power S914 server can choose to use an IBM i Express Edition. Two new editions are similar to the editions provided with POWER8 Servers and offer specific licensing advantages that further improve the price/performance of the Power S914 server when running IBM i. Feature EU2C can be included with a new 4-core Power S914 server, and feature EU2D can be included with a new 6-core Power S914 server.

## Power S914 system configuration

The minimum Power S914 initial order must include a processor module, two 16 GB DIMMs, four or two power supplies and line cords, an operating system indicator, a cover set indicator, and a Language Group Specify. Also, it must include one of the storage options and the network options below:

Storage options:

- For boot from NVMe: One NVMe carrier and one NVMe M.2 Module.
- For boot from local SFF-3 HDD/SDD: One storage backplane and one SFF-3 HDD or SDD.
- For boot from SAN: Internal HDD or SSD and RAID card are not required if feature 0837 (Boot from SAN) is selected. A Fibre Channel adapter must be ordered if feature 0837 is selected.

Network options:

- One PCIe2 4-port 1 Gb Ethernet adapter.
- One of the supported 10 Gb Ethernet adapters

AIX or Linux is the primary operating system. The minimum defined initial order configuration is as follows:

Feature number	Description	Quantity	Notes
EU0B	Operator Panel LCD Display	1	
Processors			
EP10	4-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor	1	
or			
EP11	6-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor	1	
or			
EP12	8-core, typical 2.8 to 3.8 GHz (max) POWER9 Processor	1	Rack-mount configuration only
Processor activations			
EP40	One Processor Core Activation for #EP10	4	
or			
EP41	One Processor Core Activation for #EP11	6	
or			
EP42	One Processor Core Activation for #EP12	8	
Memory DIMMs			
EM62	16 GB DDR4 Memory	2	
or			
EM63	32 GB DDR4 Memory	2	
or			
EM64	64 GB DDR4 Memory	2	
Storage Backplane			
EJ1C	Twelve SFF-3 Bays/RDX Bay	1	Optional split card EJ1E
or			
EJ1D	Eighteen SFF-3 Bays/RDX Bay/ Dual IOA with Write Cache	1	
or			
EJ1M	Twelve SFF-3 Bays/RDX Bay/2x EXT PT	1	
or			
EC59	PCIe3 NVMe carrier card w/2 M.2 module slots	1	Must order, at a minimum, one of feature ES14
Disk Drive			



Feature number	Description	Quantity	Notes
ESDB	300 GB 15K RPM SAS SFF-3 Disk Drive (AIX/Linux)	1	
LAN Adapter			
5899	PCIe2 LP 4-port 1 GbE Adapter	1	
Power supplies/ Power cord			
EB2L	AC Power Supply - 900 W for Server (200 - 240 V AC)	4	41A Tower: Qty 4 of #EB2L required
or			
EB2M	AC Power Supply - 1400 W for Server (200 - 240 V AC)	2	41A Rack: Qty 2 of #EB2M required
6458	Power Cord 4.3 m (14 ft), Drawer to IBM PDU (250V/10A)	4	41A Tower: Qty 4, or 41A Rack: Qty 2
9300/97xx	Language Group Specify	1	9300 - (default)
Front Bezel			
EJU2	Front IBM Bezel for 12-Bay BackPlane	1	41A Rack: used with #EJ1C or #EJ1M backplanes or with #EC59
or			
EJUF	Front IBM Bezel for 18-Bay Backplane	1	41A Rack: used with #EJ1D backplane
or			
EJU4	Front OEM Bezel for 12-Bay BackPlane	1	41A Rack: used with #EJ1C or #EJ1M backplanes or with #EC59
or			
EJUH	Front OEM Bezel for 18-Bay BackPlane	1	41A Rack: used with #EJ1D backplane
or			
EJU8	Front IBM Bezel for 12-Bay BackPlane	1	41A Tower: used with #EJ1C or #EJ1M backplanes or with #EC59
or			
EJU9	Front IBM Bezel for 18-Bay BackPlane	1	41A Tower: used with #EJ1D backplane
or			
EJUA	Front OEM Bezel for 12-Bay BackPlane	1	41A Tower: used with #EJ1C or #EJ1M backplanes or with #EC59
or			
EJUB	Front OEM Bezel for 18-Bay BackPlane	1	41A Tower: used with #EJ1D backplane
Primary operating system			

Feature number	Description	Quantity	Notes
2146	Primary Operating System Indicator - AIX	1	
or			
2147	Primary Operating System Indicator - Linux	1	

- The racking approach for the initial order must be either a 7014-T00, 7014-T42, 7965-S42, or 7953-94Y. If an additional rack is required for I/O expansion drawers as an MES to an existing system, either a feature 0551, 0553, or ER05 rack must be ordered.
- If NVMe carrier card feature EC59 is selected, no disk units are required to be ordered. If neither feature EC59 nor feature 0837 (SAN boot) is ordered, then at least one disk unit is required to be ordered. If no HDD/SSD/SAN boot (#0837) is ordered, then feature EC59 (with at least one of #ES14) is the load source.
- One PCIe2 4-port 1 GbE Adapter (#5899) is defaulted. Options for servers with AIX and Linux as the primary operating system are one of a 10 Gb Ethernet adapter, either feature EC2S, EC2U, EN0H, EN0K, EN0S, EN0U, EN0W, or EN15.
- Feature ES14 is not supported by IBM i virtualized through VIOS. If using IBM i (#2148), a storage option supported by IBM i with VIOS must be used with IBM i.

The minimum defined initial order configuration, if no choice is made, when IBM i is the primary operating system, is:

Feature number	Description	Quantity	Notes
EU0B	Operator Panel LCD Display	1	
Processors			
EP10	4-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor	1	
or			
EP11	6-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor	1	
or			
EP12	8-core, typical 2.8 to 3.8 GHz (max) POWER9 Processor	1	Rack-mount configuration only
Processor activations			
EP40	One Processor Core Activation for #EP10	4	
or			
EP41	One Processor Core Activation for #EP11	6	
or			
EP42	One Processor Core Activation for #EP12	8	
Memory DIMMs			
EM62	16 GB DDR4 Memory	2	
or			
EM63	32 GB DDR4 Memory	2	
or			

Feature number	Description	Quantity	Notes
EM64	64 GB DDR4 Memory	2	
Storage Backplane			
EJ1C	Twelve SFF-3 Bays/RDX Bay	1	Optional split card EJ1E
or			
EJ1D	Eighteen SFF-3 Bays/RDX Bay/ Dual IOA with Write Cache	1	
or			
EJ1M	Twelve SFF-3 Bays/RDX Bay/2x EXT PT	1	
Disk Drive			
ESNJ	283 GB 15K RPM SAS SFF-3 4k Block Cached Disk Drive (IBM i)	2	One system data protection specify code required
LAN Adapter			
5899	PCIe2 LP 4-port 1 GbE Adapter	1	
or			
EN15	PCIe3 4-port 10 GbE SR Adapter	1	
or			
EC2S	PCIe3 2-Port 10 Gb NIC&ROCE SR/Cu Adapter	1	
or			
EC2U	PCIe3 2-Port 25/10 Gb NIC&ROCE SR/Cu Adapter	1	
Power supplies/ Power cord			
EB2L	AC Power Supply - 900 W for Server (200 - 240 V AC)	4	41A Tower: Qty 4 of #EB2L required
or			
EB2M	AC Power Supply - 1400 W for Server (200 - 240 V AC)	2	41A Rack: Qty 2 of #EB2M required
6458	Power Cord 4.3 m (14 ft), Drawer to IBM PDU (250V/10A)	4	41A Tower: Qty 4, or 41A Rack: Qty 2
9300/97xx	Language Group Specify	1	9300 - (default)
Front Bezel			
EJU2	Front IBM Bezel for 12-Bay BackPlane	1	41A Rack: used with #EJ1C or #EJ1M backplanes
or			
EJUF	Front IBM Bezel for 18-Bay Backplane	1	41A Rack: used with #EJ1D backplane
or			
EJU8	Front IBM Bezel for 12-Bay BackPlane	1	41A Tower: used with #EJ1C or #EJ1M backplanes

Feature number	Description	Quantity	Notes
or			
EJU9	Front IBM Bezel for 18-Bay BackPlane	1	41A Tower: used with #EJ1D backplane
Primary operating system			
2145	Primary Operating System Indicator - IBM i	1	Feature EB72 or EB73 is required

- The racking approach for the initial order must be either a 7014-T00, 7014-T42, 7965-S42, or 7953-94Y. If an additional rack is required for I/O expansion drawers as an MES to an existing system, either a feature 0551, 0553, or ER05 rack must be ordered.
- IBM i operating system performance: Clients with write-sensitive disk/HDD workloads should upgrade from the feature EJ1C/EJ1E base storage backplane to the feature EJ1M/EJ1D expanded function storage backplanes to gain the performance advantage of write cache.

### Processor modules

A maximum of one processor with four processor cores (#EP10), or one processor with six processor cores (#EP11), or one processor with eight processor cores (#EP12) is allowed. All processor cores must be activated. The following defines the allowed quantities of processor activation entitlements.

- One 4-core, typical 2.3 to 3.8 GHz (max) processor (#EP10) requires that four processor activation codes be ordered. A maximum of four processor activations (#EP40) is allowed.
- One 6-core, typical 2.3 to 3.8 GHz (max) processor (#EP11) requires that six processor activation codes be ordered. A maximum of six processor activation code features (#EP41) is allowed.
- One 8-core, typical 2.8 to 3.8 GHz (max) processor (#EP12) requires that eight processor activation codes be ordered. A maximum of eight processor activation code features (#EP42) is allowed.

### System memory

- A minimum of 16 GB of memory is required on the Power S914 system.
- Memory upgrades require memory pairs. Base memory is two 16 GB DDR4 memory modules (#EM62).

Plans for future memory upgrades should be taken into account when deciding which memory feature size to use at the time of initial system order.

Feature description	Feature number	Minimum DIMM quantity	Maximum DIMM quantity
16 GB DDR4 Memory	EM62	0	16
32 GB DDR4 Memory	EM63	0	16
64 GB DDR4 Memory	EM64	0	16

**Note:** Different sizes/configurations run at different frequencies of 2133, 2400, and 2666 Mbps.

### Power supply

- Four power supplies supporting a tower: 1+1 900 Watt 100 - 127 Volt or 200 - 240 Volt AC options (#EB2L)
- Two power supplies supporting a rack: 1+1 1400 Watt 200 - 240 Volt (#EB2M)

### Redundant fans

Redundant fans are standard.

### **Power cords**

Two power cords are required. A maximum of two feature 6458 cords is allowed on the system unless a valid I/O drawer or tower is attached to the system. The Power S914 server supports power cord 4.3 m (14 ft), Drawer to Wall/IBM PDU (250V/10A) in the base shipment group. See the feature listing for other options.

### **PCIe slots**

The Power S914 server has up to eight PCIe hot-plug slots, providing excellent configuration flexibility and expandability. For more information about the PCIe slots, see the **Rack-integrated system with I/O expansion drawer** section below.

With one POWER9 processor single-chip module (SCM), eight PCIe slots are available: One is x16 Gen4 full-height, half-length slot (CAPI), one is x8 Gen4 full-height, half-length slot (with x16 connector) (CAPI), two are x8 Gen3 full-height, half-length slots (with x16 connectors), and four are x8 Gen3 full-height, half-length slots (one of these slots is used for the required base LAN adapter).

The x16 slots can provide up to twice the bandwidth of x8 slots because they offer twice as many PCIe lanes. PCIe Gen4 slots can support up to twice the bandwidth of a PCIe Gen3 slot, and PCIe Gen3 slots can support up to twice the bandwidth of a PCIe Gen2 slot, assuming an equivalent number of PCIe lanes.

At least one PCIe Ethernet adapter is required on the server by IBM to ensure proper manufacture, test, and support of the server. One of the x8 PCIe slots is used for this required adapter.

These servers are smarter about energy efficiency when cooling the PCIe adapter environment. They sense which IBM PCIe adapters are installed in their PCIe slots, and, if an adapter requires higher levels of cooling, they automatically speed up fans to increase airflow across the PCIe adapters. Note that faster fans increase the sound level of the server. Higher wattage PCIe adapters include the PCIe3 SAS adapters and SSD/flash PCIe adapters (#EJ10, #EJ14, and #EJ0J).

### **SAS bays and storage backplane options**

- Base Storage Backplane 12 SFF-3 Bays/RDX Bay (#EJ1C)
- Feature EJ1E (6 +6 SFF-3 Bays split backplane for #EJ1C)
- Expanded function Storage Backplane 18 SFF-3 Bays/Dual IOA with Write Cache and optional external SAS port (#EJ1D)
- Expanded function Storage Backplane 12 SFF-3 Bays/RDX Bay/Dual IOA with Write Cache and optional external SAS port (#EJ1M)

The backplane options provide SFF-3 SAS bays in the system unit. These 2.5-inch or small form factor (SFF) SAS bays can contain SAS drives (HDD or SSD) mounted on a Gen3 tray or carrier. Thus the drives are designated SFF-3. SFF-1 or SFF-2 drives do not fit in an SFF-3 bay. All SFF-3 bays support concurrent maintenance or hot-plug capability.

These backplane options use leading-edge, integrated SAS RAID controller technology designed and patented by IBM. A custom-designed PowerPC<sup>(R)</sup> based ASIC chip is the basis of these SAS RAID controllers and provides RAID 5 and RAID 6 performance levels, especially for SSD. Internally, SAS ports are implemented and provide plenty of bandwidth. The integrated SAS controllers are placed in dedicated slots and do not reduce the number of available PCIe slots.

The feature EJ1C Base Storage Backplane option provides twelve SFF-3 bays and one SAS controller with zero write cache.

By optionally adding the feature EJ1E Split Backplane, a second integrated SAS controller with no write cache is provided, and the twelve SFF-3 bays are logically

divided into two sets of six bays. Each SAS controller independently runs one of the six-bay sets of drives.

This backplane option supports HDDs or SSDs or a mixture of HDDs and SSDs in the SFF-3 bays. "Mixing" HDDs and SSDs applies even within a single set of six bays of the split backplane option. Note, if mixing HDDs and SSDs, they must be in separate arrays.

This backplane option can offer different drive protection options: RAID 0, RAID 5, RAID 6, or RAID 10. RAID 5 requires a minimum of three drives of the same capacity. RAID 6 requires a minimum of four drives of the same capacity. RAID 10 requires a minimum of two drives. Hot spare capability is supported with RAID 5, RAID 6, or RAID 10.

Note that RAID 5 and RAID 6 result in more drive write activity than mirroring or than unprotected drives.

This backplane option is supported by AIX, Linux, VIOS, and IBM i. It is highly recommended but not required that the drives be protected. With IBM i, all drives are required to be protected by either RAID or mirroring.

If the client needs a change after the server is installed, the backplane option can be changed. For example, the feature EJ1E split backplane feature can be added to an existing feature EJ1C backplane.

Unlike the hot-plug PCIe slots and SAS bays, concurrent maintenance is not available for the integrated SAS controllers. Scheduled downtime is required if a service action is required for these integrated resources.

In addition to supporting HDDs and SSDs in the SFF-3 SAS bays, the Expanded Function Storage Backplanes (#EJ1D and #EJ1M) support the optional attachment of an EXP12SX/EXP24SX drawer in mode 1. For these expanded function backplanes, all bays are accessed by both of the integrated SAS controllers. The bays support concurrent maintenance (hot-plug).

### **Cable management arm**

A folding arm is attached to the server's rails at the rear of the server. The server's power cords and the cables from the PCIe adapters or integrated ports run through the arm and into the rack. The arm enables the server to be pulled forward on its rails for service access to PCIe slots, memory, processors, and so on without disconnecting the cables from the server. Approximately 1 meter (3 feet) of cord/cable length is needed for the arm.

### **Integrated I/O ports**

In addition to the integrated SAS controllers and SAS ports associated with the storage backplane, there are two HMC ports, one system port, and three USB ports. The two HMC ports are RJ45 supporting 1 Gb Ethernet connections.

The one system port is RJ45 and is supported by AIX and Linux for attaching serial devices such as an asynchronous device like a console. If the device does not have an RJ45 connection, a converter cable such as feature 3930 can provide a 9-pin D-shell connection. Note that serial devices can have very individual characteristics (different pin outs), and the feature 3930 may not be appropriate for all possible devices. In this case, the user should acquire an OEM converter cable appropriate for their device.

Three USB-3 ports are available for general client use; one is located in front and two in the rear. Additionally, there are two USB-2 ports in the service processor located in the rear of the system. These ports are for limited client use. A converter cable ECCF provides a USB-to-9-pin D-Shell connection for this function.

### **Rack-integrated system with I/O expansion drawer**

Regardless of the rack-integrated system to which the PCIe Gen3 I/O Expansion Drawer is attached, if the expansion drawer is ordered as factory integrated, the PDUs in the rack will be defaulted to be placed horizontally to enhance cable management.

Expansion drawers complicate the access to vertical PDUs if located at the same height. IBM recommends accommodating PDUs horizontally on racks containing one or more PCIe Gen3 I/O Expansion Drawers.

After the rack with expansion drawers is delivered to the client, the client is allowed to rearrange the PDUs from horizontal to vertical. However, the configurator will continue to consider the PDUs as being placed horizontally for the matter of calculating the free space still available in the rack.

Vertical PDUs can be used only if CSRP (#0469) is on the order. When specifying CSRP, the client will provide the locations where the PCIe Gen3 I/O Expansion Drawers must be placed, avoiding locating those adjacent to vertical PDU locations, EIA 6 through 16 and 21 through 31.

### **RDX docking station**

The RDX docking station EUA4 accommodates RDX removable disk cartridges of any capacity. The disk is in a protective rugged cartridge enclosure that plugs into the docking station. The docking station holds one removable rugged disk drive/cartridge at a time. The rugged removable disk cartridge and docking station performs saves, restores, and backups similar to a tape drive. This docking station can be an excellent entry capacity/performance option.

### **EXP24SX SAS Storage Enclosure (#ESLS/#ELLS)**

The EXP24SX is a storage expansion enclosure with twenty-four 2.5-inch SFF SAS bays. It supports up to 24 hot-plug HDDs or SSDs in only 2 EIA of space in a 19-inch rack. The EXP24SX SFF bays use SFF Gen2 (SFF-2) carriers or trays.

The EXP24SX drawer feature ESLS is supported on the Power S914, S922, and S924 servers by AIX, IBM i, Linux, and VIOS. The EXP24SX drawer feature ELLS is supported on the Linux-only Power L922 server.

With AIX/Linux/VIOS, the EXP24SX can be ordered with four sets of six bays (mode 4), two sets of twelve bays (mode 2), or one set of twenty-four bays (mode 1). With IBM i, only one set of twenty-four bays (mode 1) is supported. It is possible to change the mode setting in the field using software commands along with a specifically documented procedure. The predecessor EXP24S did not support this mode change in the field.

**Important:** When changing modes, a skilled, technically qualified person should follow the special documented procedures. Improperly changing modes can potentially destroy existing RAID sets, prevent access to existing data, or allow other partitions to access another partition's existing data. Hire an expert to assist if you are not familiar with this type of reconfiguration work.

Four mini-SAS HD ports on the EXP24SX are attached to PCIe Gen3 SAS adapters or attached to an integrated SAS controller in a POWER9 scale-out server such as the Power S914, S922, or S924 servers. The following PCIe3 SAS adapters support the EXP24SX:

- PCIe3 RAID SAS Adapter Quad-port 6 Gb x8 (#EJ0J, #EJ0M, #EL3B, or #EL59)
- PCIe3 12 GB Cache RAID Plus SAS Adapter Quad-port 6 Gb x8 (#EJ14)

Earlier generation PCIe2 or PCIe1 SAS adapters are not supported with the EXP24SX.

The attachment between the EXP24SX and the PCIe3 SAS adapters or integrated SAS controllers is through SAS YO12 or X12 cables. X12 and YO12 cables are designed to support up to 12 Gb SAS. The PCIe Gen3 SAS adapters support up to 6

Gb throughput. The EXP24SX has been designed to support up to 12 Gb throughput if future SAS adapters support that capability. All ends of the YO12 and X12 cables have mini-SAS HD narrow connectors. Cable options are:

- X12 cable: 3-meter copper (#ECDJ)
- YO12 cables: 1.5-meter copper (#ECDT), 3-meter copper (#ECDU)
- 3M 100 GbE Optical Cable QSFP28 (AOC) (#EB5R)
- 5M 100 GbE Optical Cable QSFP28 (AOC) (#EB5S)
- 10M 100 GbE Optical Cable QSFP28 (AOC) (#EB5T)
- 15M 100 GbE Optical Cable QSFP28 (AOC) (#EB5U)
- 20M 100 GbE Optical Cable QSFP28 (AOC) (#EB5V)
- 30M 100 GbE Optical Cable QSFP28 (AOC) (#EB5W)
- 50M 100 GbE Optical Cable QSFP28 (AOC) (#EB5X)
- 100M 100 GbE Optical Cable QSFP28 (AOC) (#EB5Y)

An AA12 cable interconnecting a pair of PCIe3 12 GB cache adapters (two #EJ14) is not attached to the EXP24SX. These higher-bandwidth cables could support 12 Gb throughput if future adapters support that capability. Copper feature ECE0 is 0.6 meters long, ECE3 is 3 meters long, and optical AA12 feature ECE4 is 4.5-meter long.

One no-charge specify code is used with each EXP24SX I/O Drawer (#ESLS/#ELLS) to communicate to IBM configurator tools and IBM Manufacturing which mode setting, adapter, and SAS cable are needed. With this specify code, no hardware is shipped. The physical adapters, controllers, and cables must be ordered with their own chargeable feature numbers. There are more technically supported configurations than are represented by these specify codes. IBM Manufacturing and IBM configurator tools such as e-config only understand and support EXP24SX configurations represented by these specify codes.

Specify code	Mode	Adapter/ Controller	Cable to Drw	Environment
#EJW0	Mode 1	CEC SAS Ports	2 YO12 cables	AIX/IBM i/ Linux/VIOS
#EJW1	Mode 1	One (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 YO12 cable	AIX/IBM i/ Linux/VIOS
#EJW2	Mode 1	Two (one pair) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 YO12 cables	AIX/IBM i/ Linux/VIOS
#EJW3	Mode 2	Two (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 X12 cables	AIX/Linux/ VIOS
#EJW4	Mode 2	Four (two pair) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 X12 cables	AIX/Linux/ VIOS
#EJW5	Mode 4	Four (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 X12 cables	AIX/Linux/ VIOS
#EJW6	Mode 2	One (unpaired)	2 YO12 cables	AIX/Linux/ VIOS



Specify code	Mode	Adapter/ Controller	Cable to Drw	Environment
		#EJ0J/ #EJ0M/ #EL3B/ #EL59		
#EJW7	Mode 2	Two (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 YO12 cables	AIX/Linux/ VIOS
#EJWF	Mode 1	Two (one pair) #EJ14	2 YO12 cables	AIX/IBM i/ Linux/VIOS
#EJWG	Mode 2	Two (one pair) #EJ14	2 X12 cables	AIX/Linux/ VIOS
#EJWJ	Mode 2	Four (two pair) #EJ14	2 X12 cables	AIX/Linux/ VIOS
#EJWU	Mode 1	Controller EJ1G/EL67	1 YO12 cables	Linux

All of the above EXP24SX specify codes assume a full set of adapters and cables able to run all the SAS bays configured. The following specify codes communicate to IBM Manufacturing a lower-cost partial configuration is to be configured where the ordered adapters and cables can run only a portion of the SAS bays. The future MES addition of adapters and cables can enable the remaining SAS bays for growth. The following specify codes are used:

Specify	Mode	Adapter/ Controller	Cable to Drw	Environment
#EJWA (1/2 of #EJW7)	Mode 2	One (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 YO12 cables	AIX/Linux/ VIOS
#EJWB (1/2 of #EJW4)	Mode 2	Two (one pair) #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 X12 cable	AIX/Linux/ VIOS
#EJWC (1/4 of #EJW5)	Mode 4	One (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 X12 cable	AIX/Linux/ VIOS
#EJWD (1/2 of #EJW5)	Mode 4	Two (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 X12 cables	AIX/Linux/ VIOS
#EJWE (3/4 of #EJW5)	Mode 4	Three (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 X12 cables	AIX/Linux/ VIOS
#EJWH (1/2 of #EJWJ)	Mode 2	Two (one pair) #EJ14	1 X12 cables	AIX/Linux/ VIOS

An EXP24SX drawer in mode 4 can be attached to two or four SAS controllers and provide a great deal of configuration flexibility. For example, if using unpaired feature EJ0J adapters, these EJ0J adapters could be in the same server in the same partition, same server in different partitions, or even different servers.

An EXP24SX drawer in mode 2 has similar flexibility. If the I/O drawer is in mode 2, then half of its SAS bays can be controlled by one pair of PCIe3 SAS adapters, such

as a 12 GB write cache adapter pair (#EJ14), and the other half can be controlled by a different PCIe3 SAS 12 GB write cache adapter pair or by zero-write-cache PCIe3 SAS adapters.

Note that for simplicity, IBM configurator tools such as e-config assume that the SAS bays of an individual I/O drawer are controlled by one type of SAS adapter. As a client, you have more flexibility than e-config understands.

A maximum of twenty-four 2.5-inch SSDs or 2.5-inch HDDs is supported in the EXP24SX 24 SAS bays. There can be no mixing of HDDs and SSDs in the same mode 1 drawer. HDDs and SSDs can be mixed in a mode 2 or mode 4 drawer, but they cannot be mixed within a logical split of the drawer. For example, in a mode 2 drawer with two sets of 12 bays, one set could hold SSDs and one set could hold HDDs, but you cannot mix SSDs and HDDs in the same set of 12 bays.

The indicator feature EHS2 helps IBM Manufacturing understand where SSDs are placed in a mode 2 or a mode 4 EXP24SX drawer. On one mode 2 drawer, use a quantity of one feature EHS2 to have SSDs placed in just half the bays, and use two EHS2 features to have SSDs placed in any of the bays. Similarly, on one mode 4 drawer, use a quantity of one, two, three, or four EHS2 features to indicate how many bays can have SSDs. With multiple EXP24SX orders, IBM Manufacturing will have to guess which quantity of feature ESH2 is associated with each EXP24SX. Consider using CSP (#0456) to reduce guessing.

Two-and-a-half inch small form factor (SFF) SAS HDDs and SSDs are supported in the EXP24SX. All drives are mounted on Gen2 carriers/trays and thus named SFF-2 drives.

The EXP24SX drawer has many high-reliability design points:

- SAS drive bays that support hot swap
- Redundant and hot-plug-capable power and fan assemblies
- Dual line cords
- Redundant and hot-plug enclosure service modules (ESMs)
- Redundant data paths to all drives
- LED indicators on drives, bays, ESMs, and power supplies that support problem identification
- Through the SAS adapters/controllers, drives that can be protected with RAID and mirroring and hot-spare capability

Order two ESLA features for AC power supplies. The enclosure is shipped with adjustable depth rails and can accommodate 19-inch rack depths from 59.5 - 75 cm (23.4 - 29.5 in.). Slot filler panels are provided for empty bays when initially shipped from IBM.

### **EXP12SX SAS Storage Enclosure (#ESLL/#ELL)**

The EXP12SX is a storage expansion enclosure with twelve 3.5-inch LFF SAS bays. It supports up to 12 hot-plug HDDs in only 2 EIA of space in a 19-inch rack. The EXP12SX SFF bays use LFF Gen1 (LFF-1) carriers/trays. The 4k byte sector drives (#4096 or #4224) are supported. SSDs are not supported.

The EXP12SX drawer feature ESLL is supported on the Power S914, S922, and S924 servers by AIX, Linux, and VIOS. The EXP24SX drawer feature ELLL is supported on the Linux-only Power L922 server.

With AIX/Linux/VIOS, the EXP12SX enclosure can be ordered with four sets of three bays (mode 4), two sets of six bays (mode 2), or one set of twelve bays (mode 1). The mode setting can be changed in the field using software commands along with a specifically documented procedure.

**Important:** When changing modes, it is very important that you follow the documented procedures. Improperly changing modes can potentially destroy existing RAID sets, prevent access to existing data, or allow other partitions to

access another partition's existing data. Hire an expert to assist if you are not familiar with this type of reconfiguration work.

Four mini-SAS HD ports on the EXP12SX are attached to PCIe Gen3 SAS adapters or attached to an integrated SAS controller in a POWER9 scale-out server such as the Power S914, S922, or S924 server. The following PCIe3 SAS adapters support the EXP12SX:

- PCIe3 RAID SAS Adapter Quad-port 6 Gb x8 (#EJ0J, #EJ0M, #EL3B, or #EL59)
- PCIe3 12 GB Cache RAID Plus SAS Adapter Quad-port 6 Gb x8 (#EJ14)

Earlier generation PCIe2 or PCIe1 SAS adapters are not supported with the EXP12SX drawer.

The EXP12SX drawer and the PCIe3 SAS adapters or integrated SAS controllers are attached through SAS YO12 or X12 cables. X12 and YO12 cables are designed to support up to 12 Gb. The PCIe Gen3 SAS adapters support up to 6 Gb throughput. The EXP12SX has been designed to support up to 12 Gb throughput if future SAS adapters support that capability. All ends of the YO12 and X12 cables have mini-SAS HD narrow connectors. Cable options are:

- X12 cable: 3-meter copper (#ECDJ)
- YO12 cables: 1.5-meter copper (#ECDT), 3-meter copper (#ECDU)
- 3M 100 GbE Optical Cable QSFP28 (AOC) (#EB5R)
- 5M 100 GbE Optical Cable QSFP28 (AOC) (#EB5S)
- 10M 100 GbE Optical Cable QSFP28 (AOC) (#EB5T)
- 15M 100 GbE Optical Cable QSFP28 (AOC) (#EB5U)
- 20M 100 GbE Optical Cable QSFP28 (AOC) (#EB5V)
- 30M 100 GbE Optical Cable QSFP28 (AOC) (#EB5W)
- 50M 100 GbE Optical Cable QSFP28 (AOC) (#EB5X)
- 100M 100 GbE Optical Cable QSFP28 (AOC) (#EB5Y)

An AA12 cable interconnecting a pair of PCIe3 12 GB cache adapters (two #EJ14) is not attached to the EXP12SX drawer. These higher-bandwidth cables could support 12 Gb throughput if future adapters support that capability. Copper feature ECE0 is 0.6-meter long, feature ECE3 is 3-meter long, and optical AA12 feature ECE4 is 4.5-meter long.

One no-charge specify code is used with each EXP12SX I/O Drawer (#ELLL/#ESLL) to communicate to IBM configurator tools and IBM Manufacturing which mode setting, adapter, and SAS cable are needed. With this specify code, no hardware is shipped. The physical adapters, controllers, and cables must be ordered with their own chargeable feature numbers. There are more technically supported configurations than are represented by these specify codes. IBM Manufacturing and IBM configurator tools such as e-config only understand and support EXP12SX configurations represented by these specify codes.

Specify	Mode	Adapter/ Controller	Cable to Drw	Environment
#EJV0	Mode 1	CEC SAS Ports	2 YO12 cables	AIX/Linux/ VIOS
#EJV1	Mode 1	One (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 YO12 cable	AIX/Linux/ VIOS
#EJV2	Mode 1	Two (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 YO12 cables	AIX/Linux/ VIOS

<b>Specify</b>	<b>Mode</b>	<b>Adapter/ Controller</b>	<b>Cable to Drw</b>	<b>Environment</b>
#EJV3	Mode 2	Two (one pair) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 X12 cables	AIX/Linux/ VIOS
#EJV4	Mode 2	Four (two pair) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 X12 cables	AIX/Linux/ VIOS
#EJV5	Mode 4	Four (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 X12 cables	AIX/Linux/ VIOS
#EJV6	Mode 2	One(unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 YO12 cables	AIX/Linux/ VIOS
#EJV7	Mode 2	Two (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 YO12 cables	AIX/Linux/ VIOS
#EJVF	Mode 1	Two #EJ14 (one pair)	2 YO12 cables	AIX/Linux/ VIOS
#EJVG	Mode 2	Two #EJ14 (one pair)	2 X12 cables	AIX/Linux/ VIOS
#EJVJ	Mode 2	Four #EJ14 (two pair)	2 X12 cable	AIX/Linux/ VIOS
#EJVU	Mode 1	Controller EJ1G/EL67	1 YO12 cables	Linux

All of the above EXP12SX specify codes assume a full set of adapters and cables able to run all the SAS bays configured. The following specify codes communicate to IBM Manufacturing a lower cost, partial configuration is to be configured where the ordered adapters and cables can run only a portion of the SAS bays. The future MES addition of adapters and cables can enable the remaining SAS bays for growth. The following specify codes are used:

<b>Specify</b>	<b>Mode</b>	<b>Adapter/ Controller</b>	<b>Cable to Drw</b>	<b>Environment</b>
#EJVA (1/2 of #EJV7)	Mode 2	One (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 YO12 cables	AIX/Linux/ VIOS
#EJVB (1/2 of #EJV4)	Mode 2	One pair #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 X12 cable	AIX/Linux/ VIOS
#EJVC (1/4 of #EJV5)	Mode 4	One (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	1 X12 cable	AIX/Linux/ VIOS
#EJVD (2/4 of #EJV5)	Mode 4	Two (unpaired) #EJ0J/ #EJ0M/	1 X12 cables	AIX/Linux/ VIOS

Specify	Mode	Adapter/ Controller	Cable to Drw	Environment
		#EL3B/ #EL59		
#EJVE (3/4 of #EJV5)	Mode 4	Three (unpaired) #EJ0J/ #EJ0M/ #EL3B/ #EL59	2 X12 cables	AIX/Linux/ VIOS

An EXP12SX drawer in mode 4 can be attached to two or four SAS controllers and provide a great deal of configuration flexibility. For example, if using unpaired feature EJ0J adapters, these EJ0J adapters could be in the same server in the same partition, same server in different partitions, or even different servers.

An EXP12SX drawer in mode 2 has similar flexibility. If the I/O drawer is in mode 2, then half of its SAS bays can be controlled by one pair of PCIe3 SAS adapters, such as a 12 GB write cache adapter pair (#EJ14), and the other half can be controlled by a different PCIe3 SAS 12 GB write cache adapter pair or by zero-write-cache PCIe3 SAS adapters.

Note that for simplicity, IBM configurator tools such as e-config assume that the SAS bays of an individual I/O drawer are controlled by one type of SAS adapter. As a client, you have more flexibility than e-config understands.

The 3.5-inch large form factor (LFF) SAS HDDs are supported in the EXP24SX. All drives are mounted on Gen1 carriers/trays and thus named LFF-1 drives. Only 4k byte sector drives are supported in the EXP24SX drawer. The 5xx byte sector drives are not announced or planned. Drives are 7200 rpm and sometimes referred to as *nearline*. These drives provide excellent cost per gigabyte. Note that formatting or rebuilding arrays on large disk drives can take hours. If higher performance is required, consider higher rpm disks or SSDs in the EXP24SX drawer.

EXP12SX drives for feature ESSL (multi-OS) are the 3.86 TB/4.0 TB 4k 7200 RPM (#ES62) and 7.72 TB/8.0 TB 4k 7200 RPM (#ES64) drives. Drives for feature ELLL (Linux-only) are the 3.86 TB/4.0 TB 4k 7200 RPM (#EL62) and the 7.72 TB/8.0 TB 4k 7200 RPM (#EL64) drives.

The EXP12SX drawer has many high-reliability design points:

- SAS bays that support hot swap
- Redundant and hot-plug power and fan assemblies
- Dual line cords
- Redundant and hot-plug ESMs
- Redundant data paths to all drives
- LED indicators on drives, bays, ESMs, and power supplies that support problem identification
- Through the SAS adapters/controllers, drives that can be protected with RAID and mirroring and hot-spare capability

Order two ESLA features for AC power supplies. The enclosure is shipped with adjustable depth rails and can accommodate 19-inch rack depths from 59.5 - 75 cm (23.4 - 29.5 in.). Slot filler panels are provided for empty bays when initially shipped from IBM.

EXP24SX and EXP12SX enclosures can be mixed on the same server. EXP24SX and EXP12SX enclosures can be mixed on the same PCIe3 adapter.

### PCIe Gen3 I/O Drawer Cabling Option

A copper cabling option (#ECCS) is available for the scale-out servers. The cable option offers a much lower-cost connection between the server and the PCIe Gen3 I/O drawer fanout modules. The currently available Active Optical Cable (AOC) offers much longer length cables, providing rack placement flexibility. Plus AOC cables are

much thinner and have tighter bend radius and thus are much easier to cable in the rack.

The 3M Copper CXP Cable Pair (#ECCS) has the same performance and same reliability, availability, and serviceability (RAS) characteristics as the AOC cables. One copper cable length of 3 m is offered. Note that the cable management arm of the scale-out servers requires about 1 m of cable.

Like the AOC cable pair, the copper pair is cabled in the same manner. One cable attaches to the top CXP port in the PCIe adapter in the x16 PCIe slot in the server system unit and then attaches to the top CXP port in the fanout module in the I/O drawer. Its cable pair attaches to the bottom CXP port of the same PCIe adapter and to the bottom CXP port of the same fanout module. Note that the PCIe adapter providing the CXP ports on the server was named a PCIe3 "Optical" Cable Adapter. In hindsight, this naming was unfortunate as the adapter's CXP ports are not unique to optical. But at the time, optical cables were the only connection option planned.

Copper and AOC cabling can be mixed on the same server. However, they cannot be mixed on the same PCIe Gen3 I/O drawer or mixed on the same fanout module.

Copper cables have the same operating system software prerequisites as AOC cables.

### **High-function (switched and monitored) PDUs**

The high-function PDUs (power distribution units) provide switching, better monitoring, and 50% more C19 receptacles than previous Power System PDUs. Depending on country wiring standards, either two or four full-price features are orderable.

	<b>208 V 3-phase delta</b>	<b>200 V - 240 V 1-phase or 3-phase wye</b>
<b>12 x C13</b>	#EPTQ	#EPTN
<b>9 x C19</b>	#EPTL	#EPTJ

These PDUs can be mounted vertically in rack-side pockets or they can be mounted horizontally. If mounted horizontally, they each use 1 EIA (1U) of rack space. See feature EPTH for horizontal mounting hardware, which is used when IBM Manufacturing doesn't automatically factory-install the PDU. Two RJ45 ports on the front of the PDU enable the client to monitor each receptacle's electrical power usage and to remotely switch any receptacle on or off. The PDU is shipped with a generic PDU password, and IBM strongly urges clients to change it upon installation. These PDUs do provide the same low price as the low-function 12xC13 PDU feature (#7188).

### **Reliability, Availability, and Serviceability**

#### **Reliability, fault tolerance, and data correction**

The reliability of systems starts with components, devices, and subsystems that are designed to be highly reliable. During the design and development process, subsystems go through rigorous verification and integration testing processes. During system manufacturing, systems go through a thorough testing process to help ensure the highest level of product quality.

#### **Memory subsystem RAS**

The memory has error detection and correction circuitry designed such that the failure of any one specific memory module within an ECC word by itself can be corrected absent any other fault.

#### **Mutual surveillance**

The service processor monitors the operation of the firmware during the boot process and also monitors the hypervisor for termination. The hypervisor monitors the service processor and reports a service reference code when it detects

surveillance loss. In the PowerVM environment, it will perform a reset/reload if it detects the loss of the service processor.

### **Environmental monitoring functions**

The Power Systems family does ambient and over temperature monitoring and reporting.

### **POWER9 processor functions**

As in POWER8, the POWER9 processor has the ability to do processor instruction retry for some transient errors.

### **Cache availability**

The L2 and L3 caches in the POWER9 processor in the memory buffer chip are protected with double-bit detect, single-bit correct error detection code (ECC). In addition, a threshold of correctable errors detected on cache lines can result in the data in the cache lines being purged and the cache lines removed from further operation without requiring a reboot in the PowerVM environment.

Modified data would be handled through Special Uncorrectable Error handling. L1 data and instruction caches also have a retry capability for intermittent errors and a cache set delete mechanism for handling solid failures.

### **Special Uncorrectable Error handling**

Special Uncorrectable Error (SUE) handling prevents an uncorrectable error in memory or cache from immediately causing the system to terminate. Rather, the system tags the data and determines whether it will ever be used again. If the error is irrelevant, it will not force a check stop. If the data is used, termination may be limited to the program/kernel or hypervisor owning the data; or the I/O adapters controlled by an I/O hub controller would freeze if data were transferred to an I/O device.

### **PCI extended error handling**

PCI extended error handling (EEH)-enabled adapters respond to a special data packet generated from the affected PCI slot hardware by calling system firmware, which will examine the affected bus, allow the device driver to reset it, and continue without a system reboot. For Linux, EEH support extends to the majority of frequently used devices, although some third-party PCI devices may not provide native EEH support.

### **Uncorrectable error recovery**

When the auto-restart option is enabled, the system can automatically restart following an unrecoverable software error, hardware failure, or environmentally induced (AC power) failure.

### **Serviceability**

The purpose of serviceability is to efficiently repair the system while attempting to minimize or eliminate impact to system operation. Serviceability includes system installation, MES (system upgrades/downgrades), and system maintenance/repair. Depending upon the system and warranty contract, service may be performed by the client, an IBM representative, or an authorized warranty service provider.

The serviceability features delivered in this system help provide a highly efficient service environment by incorporating the following attributes:

- Design for Customer Set Up (CSU), Customer Installed Features (CIF), and Customer Replaceable Units (CRU)
- Error Detection and Fault Isolation (ED/FI)
- First Failure Data Capture (FFDC)
- Lightpath service indicators

- Service labels and service diagrams available on the system and delivered through IBM Knowledge Center
- Step-by-step service procedures documented in IBM Knowledge Center or available through the Hardware Management Console
- Automatic reporting of serviceable events to IBM through the Electronic Service Agent™ Call Home application
- CRU videos planned to be available on the web at general availability
- Mobile access to important customer service functions available by scanning a QR label

### **Service environment**

In the PowerVM environment, the HMC is a dedicated server that provides functions for configuring and managing servers for either partitioned or full-system partition using a GUI or command-line interface (CLI) or REST API. An HMC attached to the system allows support personnel (with client authorization) to remotely, or locally to the physical HMC that is in proximity of the server being serviced, log in to review error logs and perform remote maintenance if required.

The POWER9 processor-based platforms support several service environments:

- Attachment to one or more HMCs or vHMCs is a supported option by the system with PowerVM. This is the default configuration for servers supporting logical partitions with dedicated or virtual I/O. In this case, all servers have at least one logical partition.
- For non-HMC systems.
  - Full-system partition with PowerVM: A single partition owns all the server resources and only one operating system may be installed. The primary service interface is through the operating system and the service processor.

### **Service interface**

Support personnel can use the service interface to communicate with the service support applications in a server using an operator console, a graphical user interface on the management console or service processor, or an operating system terminal. The service interface helps to deliver a clear, concise view of available service applications, helping the support team to manage system resources and service information in an efficient and effective way. Applications available through the service interface are carefully configured and placed to give service providers access to important service functions.

Different service interfaces are used, depending on the state of the system, hypervisor, and operating environment. The primary service interfaces are:

- LEDs
- Operator Panel
- Service Processor menu
- Operating system service menu
- Service Focal Point on the HMC or vHMC with PowerVM

In the light path LED implementation, the system can clearly identify components for replacement by using specific component-level LEDs, and can also guide the servicer directly to the component by signaling (turning on solid) the amber system fault LED, enclosure fault LED, and component FRU fault LED. The servicer can also use the identify function to blink the FRU-level LED. When this function is activated, a roll-up to the blue enclosure locate and system locate LEDs will occur. These enclosure LEDs will turn on solid and can be used to follow the light path from the system to the enclosure and down to the specific FRU in the PowerVM environment.

### **First Failure Data Capture and error data analysis**



First Failure Data Capture (FFDC) is a technique that helps ensure that when a fault is detected in a system, the root cause of the fault will be captured without the need to re-create the problem or run any sort of extending tracing or diagnostics program. For the vast majority of faults, a good FFDC design means that the root cause can also be detected automatically without service intervention.

FFDC information, error data analysis, and fault isolation are necessary to implement the advanced serviceability techniques that enable efficient service of the systems and to help determine the failing items.

In the rare absence of FFDC and Error Data Analysis, diagnostics are required to re-create the failure and determine the failing items.

## **Diagnostics**

General diagnostic objectives are to detect and identify problems so they can be resolved quickly. Elements of IBM's diagnostics strategy include:

- Provide a common error code format equivalent to a system reference code with PowerVM, system reference number, checkpoint, or firmware error code.
- Provide fault detection and problem isolation procedures. Support remote connection ability to be used by the IBM Remote Support Center or IBM Designated Service.
- Provide interactive intelligence within the diagnostics with detailed online failure information while connected to IBM's back-end system.

## **Automatic diagnostics**

Because of the FFDC technology designed into IBM servers, it is not necessary to perform re-create diagnostics for failures or require user intervention. Solid and intermittent errors are designed to be correctly detected and isolated at the time the failure occurs. Runtime and boot-time diagnostics fall into this category.

## **Stand-alone diagnostics with PowerVM**

As the name implies, stand-alone or user-initiated diagnostics requires user intervention. The user must perform manual steps, including:

- Booting from the diagnostics CD, DVD, USB, or network
- Interactively selecting steps from a list of choices

## **Concurrent maintenance**

The determination of whether a firmware release can be updated concurrently is identified in the readme information file that is released with the firmware. An HMC is required for the concurrent firmware update with PowerVM. In addition, concurrent maintenance of PCIe adapters is supported with PowerVM. Concurrent maintenance of the Operator Panel is supported through ASMI. Additional concurrent maintenance includes power supplies, fans, and HDD/SSD drives.

## **Service labels**

Service providers use these labels to assist them in performing maintenance actions. Service labels are found in various formats and positions and are intended to transmit readily available information to the service technician during the repair process. Following are some of these service labels and their purpose:

- Location diagrams: Location diagrams are located on the system hardware, relating information regarding the placement of hardware components. Location diagrams may include location codes, drawings of physical locations, concurrent maintenance status, or other data pertinent to a repair. Location diagrams are especially useful when multiple components such as DIMMs, CPUs, processor books, fans, adapter cards, LEDs, and power supplies are installed.
- Remove/replace procedures: Service labels that contain remove/replace procedures are often found on a cover of the system or in other spots accessible

to the servicer. These labels provide systematic procedures, including diagrams detailing how to remove or replace certain serviceable hardware components.

- Arrows: Numbered arrows are used to indicate the order of operation and the serviceability direction of components. Some serviceable parts such as latches, levers, and touch points need to be pulled or pushed in a certain direction and in a certain order for the mechanical mechanisms to engage or disengage. Arrows generally improve the ease of serviceability.

## **QR labels**

QR labels are placed on the system to provide access to key service functions through a mobile device. Once the QR label is scanned, it will go to a landing page specific to that server which contains many of the service functions of interest while physically located at the server. These include things such as installation and repair instructions, service diagrams, reference code look up, and so on.

## **Packaging for service**

The following service enhancements are included in the physical packaging of the systems to facilitate service:

- Color coding (touch points): Blue-colored touch points delineate touchpoints on service components where the component can be safely handled for service actions such as removal or installation.
- Tool-less design: Selected IBM systems support tool-less or simple tool designs. These designs require no tools or simple tools such as flathead screw drivers to service the hardware components.
- Positive retention: Positive retention mechanisms help to assure proper connections between hardware components such as cables to connectors, and between two cards that attach to each other. Without positive retention, hardware components run the risk of becoming loose during shipping or installation, preventing a good electrical connection. Positive retention mechanisms like latches, levers, thumb-screws, pop Nylatches (U-clips), and cables are included to help prevent loose connections and aid in installing (seating) parts correctly. These positive retention items do not require tools.

## **Error handling and reporting**

In the event of system hardware or environmentally induced failure, the system runtime error capture capability systematically analyzes the hardware error signature to determine the cause of failure. The analysis result will be stored in system NVRAM. When the system can be successfully restarted either manually or automatically, or if the system continues to operate, the error will be reported to the operating system. Hardware and software failures are recorded in the system log. When an HMC is attached in the PowerVM environment, an ELA routine analyzes the error, forwards the event to the Service Focal Point (SFP) application running on the HMC, and notifies the system administrator that it has isolated a likely cause of the system problem. The service processor event log also records unrecoverable checkstop conditions, forwards them to the SFP application, and notifies the system administrator.

The system has the ability to call home through the operating system to report platform-recoverable errors and errors associated with PCI adapters/devices.

In the HMC-managed environment, a call home service request will be initiated from the HMC and the pertinent failure data with service parts information and part locations will be sent to an IBM service organization. Customer contact information and specific system-related data such as the machine type, model, and serial number, along with error log data related to the failure, are sent to IBM Service.

## **Live Partition Mobility**

With Live Partition Mobility, users can migrate an AIX or IBM i partition running on one POWER partition system to another POWER system without disrupting services. The migration transfers the entire system environment, including processor state,

memory, attached virtual devices, and connected users. It provides continuous operating system and application availability during planned partition outages for repair of hardware and firmware faults.

### **Service processor**

The service processor provides the capability to diagnose, check the status of, and sense the operational conditions of a system. It runs on its own power boundary and does not require resources from a system processor to be operational to perform its tasks.

Under PowerVM, the service processor supports surveillance of the connection to the HMC and to the system firmware (hypervisor). It also provides several remote power control options, environmental monitoring, reset, restart, remote maintenance, and diagnostic functions, including console mirroring. The service processors menus (ASMI) can be accessed concurrently with system operation, allowing nondisruptive abilities to change system default parameters.

### **Call home**

*Call home* refers to an automatic or manual call from a client location to the IBM support structure with error log data, server status, or other service-related information. Call home invokes the service organization in order for the appropriate service action to begin. Call home can be done through HMC or most non-HMC-managed systems through Electronic Service Agent running on top of the operating system. While configuring call home is optional, clients are encouraged to implement this feature in order to obtain service enhancements such as reduced problem determination and faster and potentially more accurate transmittal of error information. In general, using the call home feature can result in increased system availability. The Electronic Service Agent application can be configured for automated call home. See the next section for specific details on this application.

### **IBM Electronic Services**

Electronic Service Agent and the IBM Electronic Services web portal comprise the IBM Electronic Services solution, which is dedicated to providing fast, exceptional support to IBM clients. IBM Electronic Service Agent is a no-charge tool that proactively monitors and reports hardware events such as system errors, performance issues, and inventory. Electronic Service Agent can help focus on the client's company business initiatives, save time, and spend less effort managing day-to-day IT maintenance issues.

System configuration and inventory information collected by Electronic Service Agent also can be viewed on the secure Electronic Services web portal and used to improve problem determination and resolution between the client and the IBM support team. As part of an increased focus to provide even better service to IBM clients, Electronic Service Agent tool configuration and activation comes standard with the system. In support of this effort, a new HMC External Connectivity security whitepaper has been published, which describes data exchanges between the HMC and the IBM Service Delivery Center (SDC) and the methods and protocols for this exchange. To read the whitepaper and prepare for Electronic Service Agent installation, see the "Security" section at the [IBM Electronic Service Agent](#) website.

Select your country. Click "IBM Electronic Service Agent Connectivity Guide."

### **Benefits: increased uptime**

Electronic Service Agent is designed to enhance the warranty and maintenance service by potentially providing faster hardware error reporting and uploading system information to IBM Support. This can optimize the time monitoring the symptoms, diagnosing the error, and manually calling IBM Support to open a problem record. And 24x7 monitoring and reporting means no more dependency on human intervention or off-hours client personnel when errors are encountered in the middle of the night.

**Security:** The Electronic Service Agent tool is designed to help secure the monitoring, reporting, and storing of the data at IBM. The Electronic Service Agent tool is designed to help securely transmit either through the internet (HTTPS or VPN) or modem to provide clients a single point of exit from their site. Communication is one way. Activating Electronic Service Agent does not enable IBM to call into a client's system.

For additional information, see the [IBM Electronic Service Agent](#) website.

### **More accurate reporting**

Because system information and error logs are automatically uploaded to the IBM Support Center in conjunction with the service request, clients are not required to find and send system information, decreasing the risk of misreported or misdiagnosed errors. Once inside IBM, problem error data is run through a data knowledge management system, and knowledge articles are appended to the problem record.

### **Customized support**

By using the IBMid entered during activation, clients can view system and support information in the "My Systems" and "Premium Search" sections of the Electronic Services website.

The Electronic Services web portal is a single internet entry point that replaces the multiple entry points traditionally used to access IBM internet services and support. This web portal enables you to gain easier access to IBM resources for assistance in resolving technical problems. The newly improved My Systems and Premium Search functions make it even easier for Electronic Service Agent-enabled clients to track system inventory and find pertinent fixes.

My Systems provides valuable reports of installed hardware and software using information collected from the systems by IBM Electronic Service Agent. Reports are available for any system associated with the client's IBMid. Premium Search combines the function of search and the value of Electronic Service Agent information, providing advanced search of the technical support knowledgebase. Using Premium Search and the Service Agent information that has been collected from the system, clients are able to see search results that apply specifically to their systems.

For more information on how to utilize the power of IBM Electronic Services, see the following website or contact an [IBM Systems Services Representative](#).

### **Accessibility by people with disabilities**

---

A US Section 508 Voluntary Product Accessibility Template (VPAT) containing details on accessibility compliance can be found on the [Product accessibility information](#) website.

### **Section 508 of the US Rehabilitation Act**

---

The Power S914 server (9009-41A) is capable as of March 20, 2018, when used in accordance with IBM's associated documentation, of satisfying the applicable requirements of Section 508 of the Rehabilitation Act, provided that any assistive technology used with the product properly interoperates with it. A US Section 508 Voluntary Product Accessibility Template (VPAT) can be found on the [Product accessibility information](#) website.

---

## **Product positioning**

---

IBM is leading the cognitive and cloud space. Integrated cloud capabilities in POWER9 go in line with IBM's cloud strategy and enable you to connect current

enterprise data with cloud-based AI or analytics offerings like Watson™. IBM gives you best-in-class on-premises cloud deployment possibilities with this announcement in addition to the off-premises portfolio already maintained. And IBM applies that innovation to cognitive infrastructure, helping you on your journey to AI.

IBM aligns cutting-edge innovation with enterprise dependability: IBM has over 105 years of aligning continuous innovation with clients' business needs.

The POWER9 scale-out family delivers a set of entry servers that comes cloud enabled out of the box with integrated PowerVM Enterprise capabilities. Additionally, on-chip analytics and algorithms help clients run their workloads at an optimized processor frequency for performance and throughput. Live Partition Mobility capabilities are built in, to cloud-enable your POWER9 infrastructure and help you migrate from previous Power Systems. Every new S914 also has the option of a temporary PowerVM license for your old server to support a seamless move of workloads to POWER9. The Power System S914 server has built-in security that can help you to be ready for current and future security threats.

---

## Product number

---

The following are newly announced features on the specific models of the IBM Power Systems 9009 machine type:

Description	Machine type	Model	Feature number
IBM Power System S914	9009	41A	
One CSC Billing Unit	9009	41A	0010
Ten CSC Billing Units	9009	41A	0011
Mirrored System Disk Level, Specify Code	9009	41A	0040
Device Parity Protection-All, Specify Code	9009	41A	0041
Mirrored System Bus Level, Specify Code	9009	41A	0043
Device Parity RAID-6 All, Specify Code	9009	41A	0047
RISC-to-RISC Data Migration	9009	41A	0205
AIX Partition Specify	9009	41A	0265
Linux Partition Specify	9009	41A	0266
IBM i Operating System Partition Specify	9009	41A	0267
Specify Custom Data Protection	9009	41A	0296
Mirrored Level System Specify Code	9009	41A	0308
RAID Hot Spare Specify	9009	41A	0347
V.24/EIA232 6.1m (20-Ft) PCI Cable	9009	41A	0348
V.35 6.1m (20-Ft) PCI Cable	9009	41A	0353
X.21 6.1m (20-Ft) PCI Cable	9009	41A	0359
CBU Specify	9009	41A	0444
Customer Specified Placement	9009	41A	0456
19 inch, 1.8 meter high rack	9009	41A	0551
19 inch, 2.0 meter high rack	9009	41A	0553
Rack Filler Panel Kit	9009	41A	0599
Load Source Not in CEC	9009	41A	0719
SAN Load Source Specify	9009	41A	0837
US TAA Compliance Indicator	9009	41A	0983
Product assembled in USA manufacturing plant	9009	41A	0984
Modem Cable - US/Canada and General Use	9009	41A	1025
USB 500 GB Removable Disk Drive	9009	41A	1107
Custom Service Specify, Rochester Minn, USA	9009	41A	1140
Quantity 150 of #1964	9009	41A	1818
Quantity 150 of #1953	9009	41A	1929
300GB 15k RPM SAS SFF-2 Disk Drive (AIX/Linux)	9009	41A	1953
600GB 10k RPM SAS SFF-2 Disk Drive (AIX/Linux)	9009	41A	1964
Primary OS - IBM i	9009	41A	2145
Primary OS - AIX	9009	41A	2146
Primary OS - Linux	9009	41A	2147

Factory Deconfiguration of 1-core	9009	41A	2319
2M LC-SC 50 Micron Fiber Converter Cable	9009	41A	2456
2M LC-SC 62.5 Micron Fiber Converter Cable	9009	41A	2459
3M Asynchronous Terminal/Printer Cable EIA-232	9009	41A	2934
Asynchronous Cable EIA-232/V.24 3M	9009	41A	2936
Serial-to-Serial Port Cable for Drawer/Drawer-3.7M	9009	41A	3124
Serial-to-Serial Port Cable for Rack/Rack- 8M	9009	41A	3125
Widescreen LCD Monitor	9009	41A	3632
0.3M Serial Port Converter Cable, 9-Pin to 25-Pin	9009	41A	3925
Serial Port Null Modem Cable, 9-pin to 9-pin, 3.7M	9009	41A	3927
Serial Port Null Modem Cable, 9-pin to 9-pin, 10M	9009	41A	3928
System Serial Port Converter Cable	9009	41A	3930
1.8 M (6-ft) Extender Cable for Displays (15-pin D-shell to 15-pin D-shell)	9009	41A	4242
Extender Cable - USB Keyboards, 1.8M	9009	41A	4256
VGA to DVI Connection Converter	9009	41A	4276
Rack Integration Services: BP only	9009	41A	4648
Rack Integration Services	9009	41A	4649
Rack Indicator- Not Factory Integrated	9009	41A	4650
Rack Indicator, Rack #1	9009	41A	4651
Rack Indicator, Rack #2	9009	41A	4652
Rack Indicator, Rack #3	9009	41A	4653
Rack Indicator, Rack #4	9009	41A	4654
Rack Indicator, Rack #5	9009	41A	4655
Rack Indicator, Rack #6	9009	41A	4656
Rack Indicator, Rack #7	9009	41A	4657
Rack Indicator, Rack #8	9009	41A	4658
Rack Indicator, Rack #9	9009	41A	4659
Rack Indicator, Rack #10	9009	41A	4660
Rack Indicator, Rack #11	9009	41A	4661
Rack Indicator, Rack #12	9009	41A	4662
Rack Indicator, Rack #13	9009	41A	4663
Rack Indicator, Rack #14	9009	41A	4664
Rack Indicator, Rack #15	9009	41A	4665
Rack Indicator, Rack #16	9009	41A	4666
Power Active Memory Expansion Enablement	9009	41A	4794
Solution Edition for IBM i (6-core)	9009	41A	4927
Solution Edition for IBM i (4-core)	9009	41A	4928
Software Preload Required	9009	41A	5000
PowerVM Enterprise Edition	9009	41A	5228
Sys Console On HMC	9009	41A	5550
System Console-Ethernet LAN adapter	9009	41A	5557
PCIe2 8Gb 4-port Fibre Channel Adapter	9009	41A	5729
8 Gigabit PCI Express Dual Port Fibre Channel Adapter	9009	41A	5735
POWER GXT145 PCI Express Graphics Accelerator	9009	41A	5748
4 Port Async EIA-232 PCIe Adapter	9009	41A	5785
PCIe2 4-port 1GbE Adapter	9009	41A	5899
Opt Front Door for 1.8m Rack	9009	41A	6068
Opt Front Door for 2.0m Rack	9009	41A	6069
1.8m Rack Acoustic Doors	9009	41A	6248
2.0m Rack Acoustic Doors	9009	41A	6249
1.8m Rack Trim Kit	9009	41A	6263
2.0m Rack Trim Kit	9009	41A	6272
Power Cord 4.3m (14-ft), Drawer to IBM PDU (250V/10A)	9009	41A	6458
Power Cord 4.3m (14-ft), Drawer To OEM PDU (125V, 15A)	9009	41A	6460
Power Cord 4.3m (14-ft), Drawer to wall/OEM PDU (250V/15A) U. S.	9009	41A	6469
Power Cord 1.8m (6-ft), Drawer to wall (125V/15A)	9009	41A	6470
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU (250V/10A)	9009	41A	6471
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU (250V/16A)	9009	41A	6472
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU (250V/10A)	9009	41A	6473
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU, (250V/13A)	9009	41A	6474
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU, (250V/16A)	9009	41A	6475

Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU, (250V/10A)	9009	41A	6476
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU, (250V/16A)	9009	41A	6477
Power Cord 2.7 M(9-foot), To wall/OEM PDU, (250V, 16A)	9009	41A	6478
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU, (125V/15A or 250V/10A )	9009	41A	6488
4.3m (14-Ft) 3PH/24A 380-415V Power Cord	9009	41A	6489
4.3m (14-Ft) 1PH/63A 200-240V Power Cord	9009	41A	6491
4.3m (14-Ft) 1PH/48-60A 200-240V Power Cord	9009	41A	6492
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU, (250V/10A)	9009	41A	6493
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU, (250V/10A)	9009	41A	6494
Power Cord 2.7M (9-foot), To wall/OEM PDU, (250V, 10A)	9009	41A	6496
Power Cable - Drawer to IBM PDU, 200-240V/10A	9009	41A	6577
Optional Rack Security Kit	9009	41A	6580
Power Cord 2.7M (9-foot), To wall/OEM PDU, (125V, 15A)	9009	41A	6651
4.3m (14-Ft) 3PH/16A 380-415V Power Cord	9009	41A	6653
4.3m (14-Ft) 1PH/24-30A Pwr Cord	9009	41A	6654
4.3m (14-Ft) 1PH/24-30A WR Pwr Cord	9009	41A	6655
4.3m (14-Ft) 1PH/24A Power Cord	9009	41A	6656
4.3m (14-Ft) 1PH/32A Power Cord	9009	41A	6657
4.3m (14-Ft) 1PH/24A Pwr Cd-Korea	9009	41A	6658
Power Cord 2.7M (9-foot), To wall/OEM PDU, (250V, 15A)	9009	41A	6659
Power Cord 4.3m (14-ft), Drawer to wall/OEM PDU (125V/15A)	9009	41A	6660
Power Cord 2.8m (9.2-ft), Drawer to IBM PDU, (250V/10A)	9009	41A	6665
4.3m (14-Ft) 3PH/32A 380-415V Power Cord-Australia	9009	41A	6667
Power Cord 4.3M (14-foot), Drawer to OEM PDU, (250V, 15A)	9009	41A	6669
Power Cord 2.7M (9-foot), Drawer to IBM PDU, 250V/10A	9009	41A	6671
Power Cord 2M (6.5-foot), Drawer to IBM PDU, 250V/10A	9009	41A	6672
Power Cord 2.7m (9-ft), Drawer to wall/OEM PDU, (250V/10A)	9009	41A	6680
Intelligent PDU+, 1 EIA Unit, Universal UTG0247 Connector	9009	41A	7109
Environmental Monitoring Probe	9009	41A	7118
Power Distribution Unit	9009	41A	7188
Power Distribution Unit (US) - 1 EIA Unit, Universal, Fixed Power Cord	9009	41A	7196
Ethernet Cable, 15m, Hardware Management Console to System Unit	9009	41A	7802
Linux Software Preinstall	9009	41A	8143
Linux Software Preinstall (Business Partners)	9009	41A	8144
USB Mouse	9009	41A	8845
Order Routing Indicator- System Plant	9009	41A	9169
Language Group Specify - US English	9009	41A	9300
New AIX License Core Counter	9009	41A	9440
New IBM i License Core Counter	9009	41A	9441
New Red Hat License Core Counter	9009	41A	9442
New SUSE License Core Counter	9009	41A	9443
Other AIX License Core Counter	9009	41A	9444
Other Linux License Core Counter	9009	41A	9445
3rd Party Linux License Core Counter	9009	41A	9446
VIOS Core Counter	9009	41A	9447
Other IBM i License Core Counter	9009	41A	9448
Other License Core Counter	9009	41A	9449
Ubuntu Linux License Core Counter	9009	41A	9450
Month Indicator	9009	41A	9461
Day Indicator	9009	41A	9462
Hour Indicator	9009	41A	9463
Minute Indicator	9009	41A	9464
Qty Indicator	9009	41A	9465
Countable Member Indicator	9009	41A	9466
Language Group Specify - Dutch	9009	41A	9700

Language Group Specify - French	9009	41A	9703
Language Group Specify - German	9009	41A	9704
Language Group Specify - Polish	9009	41A	9705
Language Group Specify - Norwegian	9009	41A	9706
Language Group Specify - Portuguese	9009	41A	9707
Language Group Specify - Spanish	9009	41A	9708
Language Group Specify - Italian	9009	41A	9711
Language Group Specify - Canadian French	9009	41A	9712
Language Group Specify - Japanese	9009	41A	9714
Language Group Specify - Traditional Chinese (Taiwan)	9009	41A	9715
Language Group Specify - Korean	9009	41A	9716
Language Group Specify - Turkish	9009	41A	9718
Language Group Specify - Hungarian	9009	41A	9719
Language Group Specify - Slovakian	9009	41A	9720
Language Group Specify - Russian	9009	41A	9721
Language Group Specify - Simplified Chinese (PRC)	9009	41A	9722
Language Group Specify - Czech	9009	41A	9724
Language Group Specify - Romanian	9009	41A	9725
Language Group Specify - Croatian	9009	41A	9726
Language Group Specify - Slovenian	9009	41A	9727
Language Group Specify - Brazilian Portuguese	9009	41A	9728
Language Group Specify - Thai	9009	41A	9729
Customer Install MES	9009	41A	9742
Notify CSO After Install	9009	41A	9743
Product Renovated by IBM Indicator	9009	41A	9993
10m (30.3-ft), IBM Passive QSFP+ MTP Optical Cable	9009	41A	EB2J
30m (90.3-ft), IBM Passive QSFP+ MTP Optical Cable	9009	41A	EB2K
AC Power Supply - 900W	9009	41A	EB2L
AC Power Supply - 1400W for Server (200-240 VAC)	9009	41A	EB2M
Lift tool based on GenieLift GL-8 (standard)	9009	41A	EB3Z
10Gb Optical Transceiver SFP+	9009	41A	EB46
25Gb Optical Transceiver SFP28	9009	41A	EB47
0.5m SFP28/25GbE copper Cable	9009	41A	EB4J
1.0m SFP28/25GbE copper Cable	9009	41A	EB4K
1.5m SFP28/25GbE copper Cable	9009	41A	EB4L
2.0m SFP28/25GbE copper Cable	9009	41A	EB4M
2.0m QSFP28/100GbE copper split Cable to SFP28 4x25GbE	9009	41A	EB4P
Service wedge shelf tool kit for EB3Z	9009	41A	EB4Z
0.5m EDR IB Copper Cable QSFP28	9009	41A	EB50
1.0m EDR IB Copper Cable QSFP28	9009	41A	EB51
2.0M EDR IB Copper Cable QSFP28	9009	41A	EB52
1.5M EDR IB Copper Cable QSFP28	9009	41A	EB54
100Gb Optical Transceiver QSFP28	9009	41A	EB59
3M EDR IB Optical Cable QSFP28	9009	41A	EB5A
5M EDR IB Optical Cable QSFP28	9009	41A	EB5B
10M EDR IB Optical Cable QSFP28	9009	41A	EB5C
15M EDR IB Optical Cable QSFP28	9009	41A	EB5D
20M EDR IB Optical Cable QSFP28	9009	41A	EB5E
30M EDR IB Optical Cable QSFP28	9009	41A	EB5F
50M EDR IB Optical Cable QSFP28	9009	41A	EB5G
100M EDR IB Optical Cable QSFP28	9009	41A	EB5H
0.5M 100GbE Copper Cable QSFP28	9009	41A	EB5J
1.0M 100GbE Copper Cable QSFP28	9009	41A	EB5K
1.5M 100GbE Copper Cable QSFP28	9009	41A	EB5L
2.0M 100GbE copper Cable QSFP28	9009	41A	EB5M
25M EDR IB optical Cable QSFP28	9009	41A	EB5N
3M 100GbE optical Cable QSFP28 (AOC)	9009	41A	EB5R
5M 100GbE optical cable QSFP28 (AOC)	9009	41A	EB5S
10M 100GbE Optical Cable QSFP28 (AOC)	9009	41A	EB5T
15M 100GbE optical Cable QSFP28 (AOC)	9009	41A	EB5U
20M 100GbE optical Cable QSFP28 (AOC)	9009	41A	EB5V
30M 100GbE Optical Cable QSFP28 (AOC)	9009	41A	EB5W
50M 100GbE optical cable QSFP28 (AOC)	9009	41A	EB5X
100M 100GbE optical cable QSFP28 (AOC)	9009	41A	EB5Y
IBM i 7.2 Indicator	9009	41A	EB72
IBM i 7.3 Indicator	9009	41A	EB73
Rack Front Door (Black)	9009	41A	EC01
Rack Rear Door	9009	41A	EC02
Rack Side Cover	9009	41A	EC03



Rack Suite Attachment Kit	9009	41A	EC04
Slim Rear Acoustic Door	9009	41A	EC07
Slim Front Acoustic Door	9009	41A	EC08
Rear Door Heat Exchanger for 2.0 Meter Slim Rack	9009	41A	EC15
PCIe3 2-Port 10Gb NIC&ROCE SR/Cu Adapter	9009	41A	EC2S
PCIe3 2-Port 25/10Gb NIC&ROCE SR/Cu Adapter	9009	41A	EC2U
PCIe3 2-port 100GbE (NIC&ROCE) QSFP28 Adapter x16	9009	41A	EC3M
PCIe3 NVMe carrier card w/2 M.2 module slots	9009	41A	EC59
PCIe4 1-port 100Gb EDR IB CAPI adapter	9009	41A	EC63
PCIe4 2-port 100Gb EDR IB CAPI adapter	9009	41A	EC65
SAS X Cable 3m - HD Narrow 6Gb 2-Adapters to Enclosure	9009	41A	ECBJ
SAS X Cable 6m - HD Narrow 6Gb 2-Adapters to Enclosure	9009	41A	ECBK
SAS X Cable 10m - HD Narrow 6Gb 2-Adapters to Enclosure	9009	41A	ECBL
SAS X Cable 15m - HD Narrow 3Gb 2-Adapters to Enclosure	9009	41A	ECBM
SAS YO Cable 1.5m - HD Narrow 6Gb Adapter to Enclosure	9009	41A	ECBT
SAS YO Cable 3m - HD Narrow 6Gb Adapter to Enclosure	9009	41A	ECBU
SAS YO Cable 6m - HD Narrow 6Gb Adapter to Enclosure	9009	41A	ECBV
SAS YO Cable 10m - HD Narrow 6Gb Adapter to Enclosure	9009	41A	ECBW
SAS YO Cable 15m - HD Narrow 3Gb Adapter to Enclosure	9009	41A	ECBX
SAS AE1 Cable 4m - HD Narrow 6Gb Adapter to Enclosure	9009	41A	ECBY
SAS YE1 Cable 3m - HD Narrow 6Gb Adapter to Enclosure	9009	41A	ECBZ
SAS AA Cable 0.6m - HD Narrow 6Gb Adapter to Adapter	9009	41A	ECC0
SAS AA Cable 1.5m - HD Narrow 6Gb Adapter to Adapter	9009	41A	ECC2
SAS AA Cable 3m - HD Narrow 6Gb Adapter to Adapter	9009	41A	ECC3
SAS AA Cable 6m - HD Narrow 6Gb Adapter to Adapter	9009	41A	ECC4
3M Optical Cable Pair for PCIe3 Expansion Drawer	9009	41A	ECC7
10M Optical Cable Pair for PCIe3 Expansion Drawer	9009	41A	ECC8
System Port Converter Cable for UPS	9009	41A	ECCF
3M Copper CXP Cable Pair for PCIe3 Expansion Drawer	9009	41A	ECCS
3.0M SAS X12 Cable (Two Adapter to Enclosure)	9009	41A	ECDJ
4.5M SAS X12 Active Optical Cable (Two Adapter to Enclosure)	9009	41A	ECDK
10M SAS X12 Active Optical Cable (Two Adapter to Enclosure)	9009	41A	ECDL
1.5M SAS Y012 Cable (Adapter to Enclosure)	9009	41A	ECDT
3.0M SAS Y012 Cable (Adapter to Enclosure)	9009	41A	ECDU
4.5M SAS Y012 Active Optical Cable (Adapter to Enclosure)	9009	41A	ECDV
10M SAS Y012 Active Optical Cable (Adapter to Enclosure)	9009	41A	ECDW
0.6M SAS AA12 Cable (Adapter to Adapter)	9009	41A	ECE0
3.0M SAS AA12 Cable	9009	41A	ECE3
4.5M SAS AA12 Active Optical Cable (Adapter to Adapter)	9009	41A	ECE4
2.0 Meter Slim Rack	9009	41A	ECR0
Rack Front Door High-End appearance	9009	41A	ECRF
Rack Rear Door Black	9009	41A	ECRG
Rack Side Cover	9009	41A	ECRJ
Rack Rear Extension 5-In	9009	41A	ECRK
Rack Front Door for Rack (Black/Flat)	9009	41A	ECRM
Indicator Assembled and Tested in China	9009	41A	ECS0
Custom Service Specify, Montpellier, France	9009	41A	ECSF
NeuCloud Indicator/Specify	9009	41A	ECSJ
Custom Service Specify, Mexico	9009	41A	ECSM
Custom Service Specify, Poughkeepsie, USA	9009	41A	ECSP
Integrated Solution Packing	9009	41A	ECSS
Optical wrap Plug	9009	41A	ECW0
Boot Drive / Load Source in EXP12SX Specify (in			

#ESLL or #ELLL)	9009	41A	EHR1
Boot Drive / Load Source in EXP24SX Specify (in #ESLS or #ELLS)	9009	41A	EHR2
SSD Placement Indicator - #ESLS/#ELLS	9009	41A	EHS2
PCIe3 Optical Cable Adapter for PCIe3 Expansion Drawer	9009	41A	EJ08
PCIe3 RAID SAS Adapter Quad-port 6Gb x8	9009	41A	EJ0J
SAS Ports/Cabling for Dual IOA BackPlane	9009	41A	EJ0W
PCIe3 SAS Tape/DVD Adapter Quad-port 6Gb x8	9009	41A	EJ10
PCIe3 12GB Cache RAID PLUS SAS Adapter Quad-port 6Gb x8	9009	41A	EJ14
Base Storage Backplane 12 SFF-3 Bays/RDX Bay	9009	41A	EJ1C
Expanded Function Storage Backplane 18 SFF-3 Bays/Dual IOA with Write Cache/Opt Ext SAS port Split #EJ1C to 6+6 SFF-3 Bays: Add 2nd SAS Controller	9009	41A	EJ1D
Expanded Function Storage Backplane 12 SFF-3 Bays/RDX Bay/Opt Ext SAS port	9009	41A	EJ1E
PCIe3 Crypto Coprocessor BSC-Gen3 4767	9009	41A	EJ1M
Non-paired Indicator EJ14 PCIe SAS RAID+ Adapter	9009	41A	EJ33
Rack-mount Rail Kit	9009	41A	EJRL
Front IBM Bezel for 12-Bay BackPlane	9009	41A	EJTZ
Front OEM Bezel for 12-Bay BackPlane	9009	41A	EJU2
Front IBM Bezel for 12-Bay BackPlane	9009	41A	EJU4
Front IBM Bezel for 18-Bay BackPlane	9009	41A	EJU8
Front OEM Bezel for 12-Bay BackPlane	9009	41A	EJU9
Front OEM Bezel for 18-Bay BackPlane	9009	41A	EJUA
Front IBM Bezel 18-Bay BackPlane	9009	41A	EJUB
Front OEM Bezel for 18-Bay BackPlane	9009	41A	EJUF
Specify Mode-1 & CEC SAS Ports & (2)Y012 for EXP12SX #ESLL/ELLL	9009	41A	EJUH
Specify Mode-1 & (1)EJ0J/EJ0M/EL3B/EL59 & (1)Y012 for EXP12SX #ESLL/ELLL	9009	41A	EJV0
Specify Mode-1 & (2)EJ0J/EJ0M/EL3B/EL59 & (2)Y012 for EXP12SX #ESLL/ELLL	9009	41A	EJV1
Specify Mode-2 & (2)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP12SX #ESLL/ELLL	9009	41A	EJV2
Specify Mode-2 & (4)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP12SX #ESLL/ELLL	9009	41A	EJV3
Specify Mode-2 & (4)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP12SX #ESLL/ELLL	9009	41A	EJV4
Specify Mode-4 & (4)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP12SX #ESLL/ELLL	9009	41A	EJV5
Specify Mode-2 & (1)EJ0J/EJ0M/EL3B/EL59 & (2)Y012 for EXP12SX #ESLL/ELLL	9009	41A	EJV6
Specify Mode-2 & (2)EJ0J/EJ0M/EL3B/EL59 & (2)Y012 for EXP12SX #ESLL/ELLL	9009	41A	EJV7
Specify Mode-2 & (1)EJ0J/EJ0M/EL3B/EL59 & (1)Y012 for EXP12SX #ESLL/ELLL	9009	41A	EJVA
Specify Mode-2 & (2)EJ0J/EJ0M/EL3B/EL59 & (1)X12 for EXP12SX #ESLL/ELLL	9009	41A	EJVB
Specify Mode-4 & (1)EJ0J/EJ0M/EL3B/EL59 & (1)X12 for EXP12SX #ESLL/ELLL	9009	41A	EJVC
Specify Mode-4 & (2)EJ0J/EJ0M/EL3B/EL59 & (1)X12 for EXP12SX #ESLL/ELLL	9009	41A	EJVD
Specify Mode-4 & (3)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP12SX #ESLL/ELLL	9009	41A	EJVE
Specify Mode-1 & (2)EJ14 & (2)Y012 for EXP12SX #ESLL/ELLL	9009	41A	EJVF
Specify Mode-1 & CEC SAS Ports & (2)Y012 for EXP24SX #ESLS/ELS	9009	41A	EJW0
Specify Mode-1 & (1)EJ0J/EJ0M/EL3B/EL59 & (1)Y012 for EXP24SX #ESLS/ELLS	9009	41A	EJW1
Specify Mode-1 & (2)EJ0J/EJ0M/EL3B/EL59 & (2)Y012 for EXP24SX #ESLS/ELLS	9009	41A	EJW2
Specify Mode-2 & (2)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJW3
Specify Mode-2 & (4)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJW4
Specify Mode-4 & (4)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJW5
Specify Mode-2 & (1)EJ0J/EJ0M/EL3B/EL59 & (2)Y012 for EXP24SX #ESLS/ELLS	9009	41A	EJW6
Specify Mode-2 & (2)EJ0J/EJ0M/EL3B/EL59 & (2)Y012 for EXP24SX #ESLS/ELLS	9009	41A	EJW7
Specify Mode-2 & (1)EJ0J/EJ0M/EL3B/EL59 &			

(1)Y012 for EXP24SX #ESLS/ELLS	9009	41A	EJWA
Specify Mode-2 & (2)EJ0J/EJ0M/EL3B/EL59 & (1)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJWB
Specify Mode-4 & (1)EJ0J/EJ0M/EL3B/EL59 & (1)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJWC
Specify Mode-4 & (2)EJ0J/EJ0M/EL3B/EL59 & (1)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJWD
Specify Mode-4 & (3)EJ0J/EJ0M/EL3B/EL59 & (2)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJWE
Specify Mode-1 & (2)EJ14 & (2)Y012 for EXP24SX #ESLS/ELLS	9009	41A	EJWF
Specify Mode-2 & (2)EJ14 & (2)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJWG
Specify Mode-2 & (2)EJ14 & (1)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJWH
Specify Mode-2 & (4)EJ14 & (2)X12 for EXP24SX #ESLS/ELLS	9009	41A	EJWJ
PDU Access Cord 0.38m	9009	41A	ELC0
#ESD4 Load Source Specify (571GB 10K RPM SAS SFF-3 for IBM i)	9009	41A	ELS4
#ESDA Load Source Specify (283GB 15K RPM SAS SFF-3 for IBM i)	9009	41A	ELSA
#ESFU Load Source Specify (1.7TB HDD SFF-3)	9009	41A	ELT0
#ES81 Load Source Specify (1.9TB SFF-2 SSD)	9009	41A	ELT1
#ESF2 Load Source Specify (1.1TB HDD SFF-2)	9009	41A	ELT2
#ESF4 Load Source Specify (571GB HDD SFF-3)	9009	41A	ELT4
#ES86 Load Source Specify (387GB SFF-2 SSD 4k for IBM i)	9009	41A	ELT6
#ESF8 Load Source Specify (1.1TB HDD SFF-3)	9009	41A	ELT8
#ESFA Load Source Specify (283GB 15K RPM SAS SFF-3 4K Block - 4224)	9009	41A	ELTA
#ES8D Load Source Specify (775GB SFF-2 SSD 4k for IBM i)	9009	41A	ELTD
#ESFE Load Source Specify (571GB 15K RPM SAS SFF-3 4K Block - 4224)	9009	41A	ELTE
#ES8G Load Source Specify (1.55TB SFF-2 SSD 4k for IBM i)	9009	41A	ELTG
#ES8K Load Source Specify (1.9TB SFF-3 SSD)	9009	41A	ELTK
#ES7L Load Source Specify (387GB SFF-3 SSD 5xx for IBM i)	9009	41A	ELTL
#ESFN Load Source Specify (571GB 15K RPM SAS SFF-2 4K Block - 4224)	9009	41A	ELTN
#ES8P Load Source Specify (387GB SFF-3 SSD 4k for IBM i)	9009	41A	ELTP
#ES7Q Load Source Specify (775GB SFF-3 SSD 5xx for IBM i)	9009	41A	ELTQ
#ES8R Load Source Specify (775GB SFF-3 SSD 4k for IBM i)	9009	41A	ELTR
#ESFS Load Source Specify (1.7TB HDD SFF-2)	9009	41A	ELTS
#ESEU Load Source Specify (571GB HDD SFF-2)	9009	41A	ELTU
#ES8W Load Source Specify (1.55TB SFF-3 SSD 4k for IBM i)	9009	41A	ELTW
#ESEY Load Source Specify (283GB 15K RPM SAS SFF-2 4K Block - 4224)	9009	41A	ELTY
#ESNJ Load Source Specify (283GB HDD SFF-3)	9009	41A	ELUJ
#ESNL Load Source Specify (283GB HDD SFF-2)	9009	41A	ELUL
#ESNN Load Source Specify (571GB HDD SFF-3)	9009	41A	ELUN
#ESNQ Load Source Specify (571GB HDD SFF-2)	9009	41A	ELUQ
#ESE2 Load Source Specify (3.72TB SSD SFF-3)	9009	41A	ELZ2
#ES93 Load Source Specify (1.86TB SSD SFF-3)	9009	41A	ELZ3
#ES84 Load Source Specify (931GB SSD SFF-3)	9009	41A	ELZ4
#ES97 Load Source Specify (1.86TB SSD SFF-2)	9009	41A	ELZ7
#ESE8 Load Source Specify (3.72TB SSD SFF-2)	9009	41A	ELZ8
#ESGA Load Source Specify (387GB SSD SFF-3)	9009	41A	ELZA
#ESGC Load Source Specify (387GB SSD SFF-2)	9009	41A	ELZC
#ESGE Load Source Specify (387GB SSD SFF-3)	9009	41A	ELZE
#ESGJ Load Source Specify (775GB SSD SFF-3)	9009	41A	ELZJ
#ESGL Load Source Specify (775GB SSD SFF-2)	9009	41A	ELZL
#ESGN Load Source Specify (775GB SSD SFF-3)	9009	41A	ELZN
#ESGQ Load Source Specify (1.55TB SSD SFF-2)	9009	41A	ELZQ
#ESGS Load Source Specify (1.55TB SSD SFF-3)	9009	41A	ELZS
#ES8Z Load Source Specify (931GB SSD SFF-2)	9009	41A	ELZZ
16 GB DDR4 Memory	9009	41A	EM62
32 GB DDR4 Memory	9009	41A	EM63

64 GB DDR4 Memory	9009	41A	EM64
PCIe Gen3 I/O Expansion Drawer	9009	41A	EMX0
AC Power Supply Conduit for PCIe3 Expansion Drawer	9009	41A	EMXA
PCIe3 6-Slot Fanout Module for PCIe3 Expansion Drawer	9009	41A	EMXF
PCIe3 6-Slot Fanout Module for PCIe3 Expansion Drawer	9009	41A	EMXG
1m (3.3-ft), 10Gb E'Net Cable SFP+ Act Twinax Copper	9009	41A	EN01
3m (9.8-ft), 10Gb E'Net Cable SFP+ Act Twinax Copper	9009	41A	EN02
5m (16.4-ft), 10Gb E'Net Cable SFP+ Act Twinax Copper	9009	41A	EN03
PCIe3 16Gb 2-port Fibre Channel Adapter	9009	41A	EN0A
PCIe3 4-port (10Gb FCoE & 1GbE) SR&RJ45	9009	41A	EN0H
PCIe3 4-port (10Gb FCoE & 1GbE) SFP+Copper&RJ45	9009	41A	EN0K
PCIe2 4-Port (10Gb+1GbE) SR+RJ45 Adapter	9009	41A	EN0S
PCIe2 4-port (10Gb+1GbE) Copper SFP+RJ45 Adapter	9009	41A	EN0U
PCIe2 2-port 10/1GbE BaseT RJ45 Adapter	9009	41A	EN0W
PCIe 1-port Bisync Adapter	9009	41A	EN13
PCIe3 4-port 10GbE SR Adapter	9009	41A	EN15
PCIe3 32Gb 2-port Fibre Channel Adapter	9009	41A	EN1A
PCIe3 16Gb 4-port Fibre Channel Adapter	9009	41A	EN1C
4-core Typical 2.3 to 3.8 GHz (max) POWER9 Processor	9009	41A	EP10
6-core Typical 2.3 to 3.8 GHz (max) POWER9 Processor	9009	41A	EP11
8-core Typical 2.8 to 3.8 GHz (max) POWER9 Processor	9009	41A	EP12
One Processor Core Activation for #EP10	9009	41A	EP40
One Processor Core Activation for #EP11	9009	41A	EP41
One Processor Core Activation for #EP12	9009	41A	EP42
Horizontal PDU Mounting Hardware	9009	41A	EPTH
High Function 9xC19 PDU: Switched, Monitoring	9009	41A	EPTJ
High Function 9xC19 PDU 3-Phase: Switched, Monitoring	9009	41A	EPTL
High Function 12xC13 PDU: Switched, Monitoring	9009	41A	EPTN
High Function 12xC13 PDU 3-Phase: Switched, Monitoring	9009	41A	EPTQ
One Zero-Priced Processor Core Activation for #EP10	9009	41A	EPZL
One Zero-Priced Processor Core Activation for #EP11	9009	41A	EPZM
Quantity 150 of #ES62 3.86-4.0 TB 7200 rpm 4k LFF-1 Disk	9009	41A	EQ62
Quantity 150 of #ES64 7.72-8.0 TB 7200 rpm 4k LFF-1 Disk	9009	41A	EQ64
Quantity 150 of #ES78 387GB SFF-2 SSD 5xx	9009	41A	EQ78
Quantity 150 of #ES7E 775GB SFF-2 SSD 5xx	9009	41A	EQ7E
Quantity 150 of #ES80 1.9TB SFF-2 SSD 4k	9009	41A	EQ80
Quantity 150 of ES81 1.9TB SFF-2 SSD 4k	9009	41A	EQ81
Quantity 150 of #ES85 387GB SFF-2 SSD 4k	9009	41A	EQ85
Quantity 150 of #ES86 387GB SFF-2 SSD 4k	9009	41A	EQ86
Quantity 150 of #ES8C 775GB SFF-2 SSD 4k	9009	41A	EQ8C
Quantity 150 of #ES8D 775GB SFF-2 SSD 4k	9009	41A	EQ8D
Quantity 150 of #ES8F 1.55TB SFF-2 SSD 4k	9009	41A	EQ8F
Quantity 150 of #ES8G 1.55TB SFF-2 SSD 4k	9009	41A	EQ8G
Quantity 150 of #ES8Y 931GB SFF-2 SSD 4k	9009	41A	EQ8Y
Quantity 150 of ES8Z 931GB SFF-2 SSD 4k	9009	41A	EQ8Z
Quantity 150 of ES96 1.86TB SFF-2 SSD 4k	9009	41A	EQ96
Quantity 150 of ES97 1.86TB SFF-2 SSD 4k	9009	41A	EQ97
Quantity 150 of #ESE7 3.72TB SFF-2 SSD 4k	9009	41A	EQE7
Quantity 150 of ESE8 3.72TB SFF-2 SSD 4k	9009	41A	EQE8
Quantity 150 of #ESEU (571GB 10k SFF-2)	9009	41A	EQEU
Quantity 150 of #ESEV (600GB 10k SFF-2)	9009	41A	EQEV
Quantity 150 of #ESEY (283 GB SFF-2)	9009	41A	EQEY
Quantity 150 of #ESEZ (300GB SFF-2)	9009	41A	EQEZ
Quantity 150 of #ESF2 (1.1TB 10k SFF-2)	9009	41A	EQF2
Quantity 150 of #ESF3 (1.2TB 10k SFF-2)	9009	41A	EQF3
Quantity 150 of #ESFN (571GB SFF-2)	9009	41A	EQFN
Quantity 150 of #ESFP (600GB SFF-2)	9009	41A	EQFP
Quantity 150 of #ESFS (1.7TB 10k SFF-2)	9009	41A	EQFS

Quantity 150 of #ESFT (1.8TB 10k SFF-2)	9009	41A	EQFT
Quantity 150 of #ESG5 (387GB SAS 5xx)	9009	41A	EQG5
Quantity 150 of #ESGB (387GB SAS 4k)	9009	41A	EQGB
Quantity 150 of #ESGC (387GB SAS 4k)	9009	41A	EQGC
Quantity 150 of #ESGF (775GB SAS 5xx)	9009	41A	EQGF
Quantity 150 of #ESGK (775GB SAS 4k)	9009	41A	EQGK
Quantity 150 of #ESGL (775GB SAS 4k)	9009	41A	EQGL
Quantity 150 of #ESGP (1.55TB SAS 4k)	9009	41A	EQGP
Quantity 150 of #ESGQ (1.55TB SAS 4k)	9009	41A	EQGQ
42U Slim Rack	9009	41A	ER05
RFID Tags for Servers, Compute Nodes, Chassis, Racks, and HMCs	9009	41A	ERF1
Rear rack extension	9009	41A	ERG0
Mainstream 400GB SSD NVMe M.2 module	9009	41A	ES14
3.86-4.0 TB 7200 RPM 4K SAS LFF-1 Nearline Disk Drive (AIX/Linux)	9009	41A	ES62
7.72-8.0 TB 7200 RPM 4K SAS LFF-1 Nearline Disk Drive (AIX/Linux)	9009	41A	ES64
387GB SFF-2 SSD 5xx eMLC4 for AIX/Linux	9009	41A	ES78
775GB SFF-2 SSD 5xx eMLC4 for AIX/Linux	9009	41A	ES7E
387GB SFF-3 SSD 5xx eMLC4 for AIX/Linux	9009	41A	ES7K
387GB SFF-3 SSD 5xx eMLC4 for IBM i	9009	41A	ES7L
775GB SFF-3 SSD 5xx eMLC4 for AIX/Linux	9009	41A	ES7P
775GB SFF-3 SSD 5xx eMLC4 for IBM i	9009	41A	ES7Q
1.9TB Read Intensive SAS 4k SFF-2 SSD for AIX/ Linux	9009	41A	ES80
1.9TB Read Intensive SAS 4k SFF-2 SSD for IBM i	9009	41A	ES81
931GB Mainstream SAS 4k SFF-3 SSD for AIX/Linux	9009	41A	ES83
931GB Mainstream SAS 4k SFF-3 SSD for IBM i	9009	41A	ES84
387GB SFF-2 SSD 4k eMLC4 for AIX/Linux	9009	41A	ES85
387GB SFF-2 SSD 4k eMLC4 for IBM i	9009	41A	ES86
775GB SFF-2 SSD 4k eMLC4 for AIX/Linux	9009	41A	ES8C
775GB SFF-2 SSD 4k eMLC4 for IBM i	9009	41A	ES8D
1.55TB SFF-2 SSD 4k eMLC4 for AIX/Linux	9009	41A	ES8F
1.55TB SFF-2 SSD 4k eMLC4 for IBM i	9009	41A	ES8G
1.9TB Read Intensive SAS 4k SFF-3 SSD for AIX/ Linux	9009	41A	ES8J
1.9TB Read Intensive SAS 4k SFF-3 SSD for IBM i	9009	41A	ES8K
387GB SFF-3 SSD 4k eMLC4 for AIX/Linux	9009	41A	ES8N
387GB SFF-3 SSD 4k eMLC4 for IBM i	9009	41A	ES8P
775GB SFF-3 SSD 4k eMLC4 for AIX/Linux	9009	41A	ES8Q
775GB SFF-3 SSD 4k eMLC4 for IBM i	9009	41A	ES8R
1.55TB SFF-3 SSD 4k eMLC4 for AIX/Linux	9009	41A	ES8V
1.55TB SFF-3 SSD 4k eMLC4 for IBM i	9009	41A	ES8W
931GB Mainstream SAS 4k SFF-2 SSD for AIX/Linux	9009	41A	ES8Y
931GB Mainstream SAS 4k SFF-2 SSD for IBM i	9009	41A	ES8Z
1.86TB Mainstream SAS 4k SFF-3 SSD for AIX/Linux	9009	41A	ES92
1.86TB Mainstream SAS 4k SFF-3 SSD for IBM i	9009	41A	ES93
1.86TB Mainstream SAS 4k SFF-2 SSD for AIX/Linux	9009	41A	ES96
1.86TB Mainstream SAS 4k SFF-2 SSD for IBM i	9009	41A	ES97
S&H - No Charge	9009	41A	ESC0
S&H-b	9009	41A	ESC6
571GB 10K RPM SAS SFF-3 Disk Drive (IBM i)	9009	41A	ESD4
600GB 10K RPM SAS SFF-3 Disk Drive (AIX/Linux)	9009	41A	ESD5
283GB 15K RPM SAS SFF-3 Disk Drive (IBM i)	9009	41A	ESDA
300GB 15K RPM SAS SFF-3 Disk Drive (AIX/Linux)	9009	41A	ESDB
3.72TB Mainstream SAS 4k SFF-3 SSD for AIX/Linux	9009	41A	ESE1
3.72TB Mainstream SAS 4k SFF-3 SSD for IBM i	9009	41A	ESE2
3.72TB Mainstream SAS 4k SFF-2 SSD for AIX/Linux	9009	41A	ESE7
3.72TB Mainstream SAS 4k SFF-2 SSD for IBM i	9009	41A	ESE8
571GB 10K RPM SAS SFF-2 Disk Drive 4K Block - 4224	9009	41A	ESEU
600GB 10K RPM SAS SFF-2 Disk Drive 4K Block - 4096	9009	41A	ESEV
283GB 15K RPM SAS SFF-2 4K Block - 4224 Disk Drive	9009	41A	ESEY
300GB 15K RPM SAS SFF-2 4K Block - 4096 Disk Drive	9009	41A	ESEZ
1.1TB 10K RPM SAS SFF-2 Disk Drive 4K Block - 4224	9009	41A	ESF2
1.2TB 10K RPM SAS SFF-2 Disk Drive 4K Block - 4096	9009	41A	ESF3
571GB 10K RPM SAS SFF-3 Disk Drive 4K Block - 4224	9009	41A	ESF4

600GB 10K RPM SAS SFF-3 Disk Drive 4K Block - 4096	9009	41A	ESF5
1.1TB 10K RPM SAS SFF-3 Disk Drive 4K Block - 4224	9009	41A	ESF8
1.2TB 10K RPM SAS SFF-3 Disk Drive 4K Block - 4096	9009	41A	ESF9
283GB 15K RPM SAS SFF-3 4K Block - 4224 Disk Drive	9009	41A	ESFA
300GB 15K RPM SAS SFF-3 4K Block - 4096 Disk Drive	9009	41A	ESFB
571GB 15K RPM SAS SFF-3 4K Block - 4224 Disk Drive	9009	41A	ESFE
600GB 15K RPM SAS SFF-3 4K Block - 4096 Disk Drive	9009	41A	ESFF
283GB 15K RPM SAS SFF-3 Disk 4K Block	9009	41A	ESFG
571GB 15K RPM SAS SFF-2 4K Block - 4224 Disk Drive	9009	41A	ESFN
600GB 15K RPM SAS SFF-2 4K Block - 4096 Disk Drive	9009	41A	ESFP
1.7TB 10K RPM SAS SFF-2 Disk Drive 4K Block - 4224	9009	41A	ESFS
1.8TB 10K RPM SAS SFF-2 Disk Drive 4K Block - 4096	9009	41A	ESFT
1.7TB 10K RPM SAS SFF-3 Disk Drive 4K Block - 4224	9009	41A	ESFU
1.8TB 10K RPM SAS SFF-3 Disk Drive 4K Block - 4096	9009	41A	ESFV
387GB Enterprise SAS 5xx SFF-2 SSD for AIX/Linux	9009	41A	ESG5
387GB Enterprise SAS 5xx SFF-3 SSD for AIX/Linux	9009	41A	ESG9
387GB Enterprise SAS 5xx SFF-3 SSD for IBM i	9009	41A	ESGA
387GB Enterprise SAS 4k SFF-2 SSD for AIX/Linux	9009	41A	ESGB
387GB Enterprise SAS 4k SFF-2 SSD for IBM i	9009	41A	ESGC
387GB Enterprise SAS 4k SFF-3 SSD for AIX/Linux	9009	41A	ESGD
387GB Enterprise SAS 4k SFF-3 SSD for IBM i	9009	41A	ESGE
775GB Enterprise SAS 5xx SFF-2 SSD for AIX/Linux	9009	41A	ESGF
775GB Enterprise SAS 5xx SFF-3 SSD for AIX/Linux	9009	41A	ESGH
775GB Enterprise SAS 5xx SFF-3 SSD for IBM i	9009	41A	ESGJ
775GB Enterprise SAS 4k SFF-2 SSD for AIX/Linux	9009	41A	ESGK
775GB Enterprise SAS 4k SFF-2 SSD for IBM i	9009	41A	ESGL
775GB Enterprise SAS 4k SFF-3 SSD for AIX/Linux	9009	41A	ESGM
775GB Enterprise SAS 4k SFF-3 SSD for IBM i	9009	41A	ESGN
1.55TB Enterprise SAS 4k SFF-2 SSD for AIX/Linux	9009	41A	ESGP
1.55TB Enterprise SAS 4k SFF-2 SSD for IBM i	9009	41A	ESGQ
1.55TB Enterprise SAS 4k SFF-3 SSD for AIX/Linux	9009	41A	ESGR
1.55TB Enterprise SAS 4k SFF-3 SSD for IBM i	9009	41A	ESGS
Specify AC Power Supply for EXP12SX/EXP24SX Storage Enclosure	9009	41A	ESLA
EXP12SX SAS Storage Enclosure	9009	41A	ESLL
EXP24SX SAS Storage Enclosure	9009	41A	ESLS
283GB 15K RPM SAS SFF-3 4k Block Cached Disk Drive (IBM i)	9009	41A	ESNJ
300GB 15K RPM SAS SFF-3 4k Block Cached Disk Drive (AIX/Linux)	9009	41A	ESNK
283GB 15K RPM SAS SFF-2 4k Block Cached Disk Drive (IBM i)	9009	41A	ESNL
300GB 15K RPM SAS SFF-2 4k Block Cached Disk Drive (AIX/Linux)	9009	41A	ESNM
571GB 15K RPM SAS SFF-3 4k Block Cached Disk Drive (IBM i)	9009	41A	ESNN
600GB 15K RPM SAS SFF-3 4k Block Cached Disk Drive (AIX/Linux)	9009	41A	ESNP
571GB 15K RPM SAS SFF-2 4k Block Cached Disk Drive (IBM i)	9009	41A	ESNQ
600GB 15K RPM SAS SFF-2 4k Block Cached Disk Drive (AIX/Linux)	9009	41A	ESNR
Quantity 150 of #ESNL (283GB 15k SFF-2)	9009	41A	ESPL
Quantity 150 of #ESNM (300GB 15k SFF-2)	9009	41A	ESPM
Quantity 150 of #ESNQ (571GB 15k SFF-2)	9009	41A	ESPQ
Quantity 150 of #ESNR (600GB 15k SFF-2)	9009	41A	ESPR
RDX USB Internal Docking Station for Removable Disk Cartridge	9009	41A	EU00
1TB Removable Disk Drive Cartridge	9009	41A	EU01
RDX USB External Docking Station for Removable Disk Cartridge	9009	41A	EU04

RDX 320 GB Removable Disk Drive	9009	41A	EU08
Operator Panel LCD Display	9009	41A	EU0B
1.5TB Removable Disk Drive Cartridge	9009	41A	EU15
Cable Ties & Labels	9009	41A	EU19
Express Edition 4 core (IBM i)	9009	41A	EU2C
Express Edition 6-core (IBM i)	9009	41A	EU2D
2TB Removable Disk Drive Cartridge (RDX)	9009	41A	EU2T
RDX USB External Docking Station	9009	41A	EUA4
Standalone USB DVD drive w/cable	9009	41A	EUA5
Core Use HW Feature	9009	41A	EUC6
Core Use HW Feature 10X	9009	41A	EUC7

The following is a newly announced feature on the specific models of the IBM Power Systems 7014 and 7965 machine type:

### New feature available March 20, 2018

Description	Machine type	Model	Feature number
Rack Content Specify: 9009-41A - 4E1A	7014	T00	ER2X
	7014	T42	
	7965	94Y	
	7965	S42	

---

## Business Partner information

If you are a Direct Reseller - System Reseller acquiring products from IBM, you may link directly to Business Partner information for this announcement. A PartnerWorld<sup>(R)</sup> ID and password are required (use IBMid).

[BP Attachment for Announcement Letter 118-023](#)

---

## Publications

Power Systems hardware documentation provides clients with the following topical information:

- Licenses, notices, safety, and warranty information
- Planning for the system
- Installing and configuring the system
- Troubleshooting, service, and support
- Installing, configuring, and managing consoles, terminals, and interfaces
- Installing operating systems
- Creating a virtual computing environment
- Enclosures and expansion units
- Glossary

You can access the product documentation at [IBM Knowledge Center](#).

Product documentation is also available on DVD (SK5T-7087).

The following information is shipped with the 9009-41A:

- Power Hardware Information DVD SK5T-7087
- Installing the 9009-41A
- Important Notices

- Warranty Information
- License Agreement for Machine Code

Hardware documentation such as installation instructions, user's information, and service information is available to download or view at the [IBM Support](#) website.

You can access IBM i documentation at the [IBM i](#) website.

You can access AIX documentation at the [AIX](#) website.

You can access documentation about Linux on IBM systems at the [Linux information for IBM systems](#) website.

The IBM Systems Information Center provides you with a single information center where you can access product documentation for IBM systems hardware, operating systems, and server software. Through a consistent framework, you can efficiently find information and personalize your access. See the IBM Systems Information Center, at [IBM Knowledge Center](#).

IBM Knowledge Center provides you with a single point of reference where you can access product documentation for IBM systems hardware, operating systems, and server software. Through a consistent framework, you can efficiently find information and personalize your access by going to [IBM Knowledge Center](#) for all your product information needs.

To access the IBM Publications Center Portal, go to the [IBM Publications Center](#) website.

The Publications Center is a worldwide central repository for IBM product publications and marketing material with a catalog of 70,000 items. Extensive search facilities are provided. A large number of publications are available online in various file formats, which can currently be downloaded.

---

## Services

---

### **IBM Systems Lab Services**

---

IBM Systems Lab Services offers a wide array of services available for your enterprise. It brings expertise on the latest technologies from the IBM development community and can help with your most difficult technical challenges.

IBM Systems Lab Services exists to help you successfully implement emerging technologies so as to accelerate your return on investment and improve your satisfaction with your IBM systems and solutions. Services examples include initial implementation, integration, migration, and skills transfer on IBM systems solution capabilities and recommended practices. IBM Systems Lab Services is one of the service organizations of IBM's world-renowned IBM Systems Group development labs.

For details on available services, contact your IBM representative or go to the [IBM Systems Lab Services](#) website.

### **Global Technology Services**

---

IBM services include business consulting, outsourcing, hosting services, applications, and other technology management.

These services help you learn about, plan, install, manage, or optimize your IT infrastructure to be an on-demand business. They can help you integrate your high-speed networks, storage systems, application servers, wireless protocols, and an array of platforms, middleware, and communications software for IBM and many non-IBM offerings. IBM is your one-stop shop for IT support needs.



For details on available services, contact your IBM representative or go to the [IBM Global Technology Services<sup>\(R\)</sup>](#) website.

For details on available IBM Business Continuity and Recovery Services, contact your IBM representative or go to the [Resiliency Services](#) website.

Details on education offerings related to specific products can be found on the [IBM authorized training](#) website.

---

## Technical information

---

### Specified operating environment

---

#### *Physical specifications*

- 19-inch rack-mount hardware
  - Width: 482 mm (18.97 in.)
  - Depth: 769.6 mm (30.3 in.)
  - Height: 173.3 mm (6.8 in.)
  - Weight: 36.3 kg (80 lb)
- Tower hardware
  - Width: 182.4 mm (7.18 in.)
  - Width with stand: 328.5 mm (12.93 in.)
  - Depth: 751.7 mm (29.59 in.)
  - Depth with front-rotatable door: 814.7 mm (32.07 in.)
  - Height: 486.1 mm (19.14 in.)
  - Height with handle: 522 mm (20.55 in.)
  - Weight: 46.94 kg (103.5 lb)

To assure installability and serviceability in non-IBM industry-standard racks, review the installation planning information for any product-specific installation requirements.

#### *Operating environment*

- Temperature: (nonoperating) 5°C - 45°C (41°F - 113°F); recommended temperature (operating) 18°C - 27°C (64°F - 80°F); allowable operating temperature 5°C - 40°C (41°F - 104°F)
- Relative humidity: Nonoperating 8% - 80%; recommended 5.5°C (42°F) dew point to 60% RH and 15°C (59°F) dew point
- Maximum dew point: 21°C (70°F)(allowable operating)
- Operating voltage:
  - 900 W PSU: 100 - 127 V AC or 200 - 240 V AC
  - 1400 W PSU: 200 - 240 V AC
- Operating frequency: 47/63 Hz
- Maximum power consumption: 1600 watts (maximum)
- Power factor: 0.98
- Thermal output: 5,461 Btu/hour (maximum)
- Power-source loading
  - 1.65 kVa (maximum configuration)
  - Maximum altitude: 3,050 m (10,000 ft)

**Note:** The maximum measured value is the worst case power consumption expected from a fully populated server under an intensive workload. The maximum measured value also accounts for component tolerance and non-ideal

operating conditions. Power consumption and heat load vary greatly by server configuration and utilization. The [IBM Systems Energy Estimator](#) should be used to obtain a heat output estimate based on a specific configuration.

### **Noise levels and declared A-weighted sound power level**

- Tower system: 5.8 bels operating; 5.3 bels idling
- Rack-mount system: 5.9 bels operating; 5.3 bels idling

See the *Installation Planning Guide* in [IBM Knowledge Center](#) for additional detail.

For example, the actual power noise level is impacted by multiple factors, including:

- Enablement of Maximum Performance mode increases fan speed, which increases power noise levels.
- Usage of Maximum Performance mode further increases fan speed, which further increases power noise levels.
- Using higher wattage PCIe adapters increases fan speed, which increases power noise levels.
- Placing multiple servers in a rack increases the total power noise level.
- Placing servers in racks with acoustic doors reduces the power noise levels.

### **EMC conformance classification**

This equipment is subject to FCC rules and shall comply with the appropriate FCC rules before final delivery to the buyer or centers of distribution.

- US: FCC Class A
- Europe: CISPR 22 Class A
- Japan: VCCI-A
- Korea: Korean Requirement Class A
- China: People's Republic of China commodity inspection law Class A

### **Homologation -- Telecom environmental testing (Safety and EMC):**

Homologation approval for specific countries has been initiated with the IBM Homologation and Type Approval (HT&A) organization in LaGaude, France. This Power Systems model and applicable features meet the environmental testing requirements of the country telecom and have been designed and tested in compliance with the Full Quality Assurance Approval (FQAA) process as delivered by the British Approval Board for Telecom (BABT), the UK Telecom regulatory authority.

This product is not certified for connection by any means whatsoever to interfaces of public telecommunications networks. Certification may be required by law prior to making any such connection. Contact an IBM representative or reseller for any questions.

### **Product safety/Country testing/Certification**

- UL 60950-1:2007 Underwriters Laboratory, Safety Information
- CSA C22.2 No. 60950-1-07, Canadian Standards Association
- EN60950 European Norm
- IEC 60950, Edition 1, International Electrotechnical Commission, Safety Information
- Nordic deviations to IEC 60950-1 1st Edition

### **General requirements**

The product is in compliance with IBM Corporate Bulletin C-B 0-2594-000 Statement of Conformity of IBM Product to External Standard (Suppliers Declaration).

## Homologation

This product is not certified for direct connection by any means whatsoever to interfaces of public telecommunications networks. Certification may be required by law prior to making any such connection. Contact an IBM representative or reseller for any questions.

## Hardware requirements

### Power S914 system configuration

The minimum Power S914 initial order must include a processor module, two 16 GB DIMMs, four or two power supplies and line cords, an operating system indicator, a cover set indicator, and a Language Group Specify. Also, it must include one of the storage options and the network options below:

Storage options:

- For boot from NVMe: One NVMe carrier and one NVMe M.2 Module.
- For boot from local SFF-3 HDD/SDD: One storage backplane and one SFF-3 HDD or SDD.
- For boot from SAN: Internal HDD or SSD and RAID card are not required if feature 0837 (Boot from SAN) is selected. A Fibre Channel adapter must be ordered if feature 0837 is selected.

Network options:

- One PCIe2 4-port 1 Gb Ethernet adapter.
- One of the supported 10 Gb Ethernet adapters

AIX or Linux is the primary operating system. The minimum defined initial order configuration is as follows:

Feature number	Description	Quantity	Notes
EU0B	Operator Panel LCD Display	1	
Processors			
EP10	4-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor	1	
or			
EP11	6-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor	1	
or			
EP12	8-core, typical 2.8 to 3.8 GHz (max) POWER9 Processor	1	Rack-mount configuration only
Processor activations			
EP40	One Processor Core Activation for #EP10	4	
or			
EP41	One Processor Core Activation for #EP11	6	
or			
EP42	One Processor Core Activation for #EP12	8	
Memory DIMMs			

<b>Feature number</b>	<b>Description</b>	<b>Quantity</b>	<b>Notes</b>
EM62	16 GB DDR4 Memory	2	
or			
EM63	32 GB DDR4 Memory	2	
or			
EM64	64 GB DDR4 Memory	2	
<b>Storage Backplane</b>			
EJ1C	Twelve SFF-3 Bays/RDX Bay	1	Optional split card EJ1E
or			
EJ1D	Eighteen SFF-3 Bays/RDX Bay/ Dual IOA with Write Cache	1	
or			
EJ1M	Twelve SFF-3 Bays/RDX Bay/2x EXT PT	1	
or			
EC59	PCIe3 NVMe carrier card w/2 M.2 module slots	1	Must order, at a minimum, one of feature ES14
<b>Disk Drive</b>			
ESDB	300 GB 15K RPM SAS SFF-3 Disk Drive (AIX/Linux)	1	
<b>LAN Adapter</b>			
5899	PCIe2 LP 4-port 1 GbE Adapter	1	
<b>Power supplies/ Power cord</b>			
EB2L	AC Power Supply - 900 W for Server (200 - 240 V AC)	4	41A Tower: Qty 4 of #EB2L required
or			
EB2M	AC Power Supply - 1400 W for Server (200 - 240 V AC)	2	41A Rack: Qty 2 of #EB2M required
6458	Power Cord 4.3 m (14 ft), Drawer to IBM PDU (250V/10A)	4	41A Tower: Qty 4, or 41A Rack: Qty 2
9300/97xx	Language Group Specify	1	9300 - (default)
<b>Front Bezel</b>			
EJU2	Front IBM Bezel for 12-Bay BackPlane	1	41A Rack: used with #EJ1C or #EJ1M backplanes or with #EC59
or			
EJUF	Front IBM Bezel for 18-Bay Backplane	1	41A Rack: used with #EJ1D backplane
or			
EJU4	Front OEM Bezel for 12-Bay BackPlane	1	41A Rack: used with #EJ1C or #EJ1M backplanes or with #EC59

Feature number	Description	Quantity	Notes
or			
EJUH	Front OEM Bezel for 18-Bay BackPlane	1	41A Rack: used with #EJ1D backplane
or			
EJU8	Front IBM Bezel for 12-Bay BackPlane	1	41A Tower: used with #EJ1C or #EJ1M backplanes or with #EC59
or			
EJU9	Front IBM Bezel for 18-Bay BackPlane	1	41A Tower: used with #EJ1D backplane
or			
EJUA	Front OEM Bezel for 12-Bay BackPlane	1	41A Tower: used with #EJ1C or #EJ1M backplanes or with #EC59
or			
EJUB	Front OEM Bezel for 18-Bay BackPlane	1	41A Tower: used with #EJ1D backplane
Primary operating system			
2146	Primary Operating System Indicator - AIX	1	
or			
2147	Primary Operating System Indicator - Linux	1	

- The racking approach for the initial order must be either a 7014-T00, 7014-T42, 7965-S42, or 7953-94Y. If an additional rack is required for I/O expansion drawers as an MES to an existing system, either a feature 0551, 0553, or ER05 rack must be ordered.
- If NVMe carrier card feature EC59 is selected, no disk units are required to be ordered. If neither feature EC59 nor feature 0837 (SAN boot) is ordered, then at least one disk unit is required to be ordered. If no HDD/SSD/SAN boot (#0837) is ordered, then feature EC59 (with at least one of #ES14) is the load source.
- One PCIe2 4-port 1 GbE Adapter (#5899) is defaulted. Options for servers with AIX and Linux as the primary operating system are one of a 10 Gb Ethernet adapter, either feature EC2S, EC2U, EN0H, EN0K, EN0S, EN0U, EN0W, or EN15.
- Feature ES14 is not supported by IBM i virtualized through VIOS. If using IBM i (#2148), a storage option supported by IBM i with VIOS must be used with IBM i.

The minimum defined initial order configuration, if no choice is made, when IBM i is the primary operating system, is:

Feature number	Description	Quantity	Notes
EU0B	Operator Panel LCD Display	1	
Processors			
EP10	4-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor	1	
or			
EP11	6-core, typical 2.3 to 3.8 GHz (max) POWER9 Processor	1	
or			

Feature number	Description	Quantity	Notes
EP12	8-core, typical 2.8 to 3.8 GHz (max) POWER9 Processor	1	Rack-mount configuration only
Processor activations			
EP40	One Processor Core Activation for #EP10	4	
or			
EP41	One Processor Core Activation for #EP11	6	
or			
EP42	One Processor Core Activation for #EP12	8	
Memory DIMMs			
EM62	16 GB DDR4 Memory	2	
or			
EM63	32 GB DDR4 Memory	2	
or			
EM64	64 GB DDR4 Memory	2	
Storage Backplane			
EJ1C	Twelve SFF-3 Bays/RDX Bay	1	Optional split card EJ1E
or			
EJ1D	Eighteen SFF-3 Bays/RDX Bay/ Dual IOA with Write Cache	1	
or			
EJ1M	Twelve SFF-3 Bays/RDX Bay/2x EXT PT	1	
Disk Drive			
ESNJ	283 GB 15K RPM SAS SFF-3 4k Block Cached Disk Drive (IBM i)	2	One system data protection specify code required
LAN Adapter			
5899	PCIe2 LP 4-port 1 GbE Adapter	1	
or			
EN15	PCIe3 4-port 10 GbE SR Adapter	1	
or			
EC2S	PCIe3 2-Port 10 Gb NIC&ROCE SR/Cu Adapter	1	
or			
EC2U	PCIe3 2-Port 25/10 Gb NIC&ROCE SR/ Cu Adapter	1	
Power supplies/ Power cord			

Feature number	Description	Quantity	Notes
EB2L	AC Power Supply - 900 W for Server (200 - 240 V AC)	4	41A Tower: Qty 4 of #EB2L required
or			
EB2M	AC Power Supply - 1400 W for Server (200 - 240 V AC)	2	41A Rack: Qty 2 of #EB2M required
6458	Power Cord 4.3 m (14 ft), Drawer to IBM PDU (250V/10A)	4	41A Tower: Qty 4, or 41A Rack: Qty 2
9300/97xx	Language Group Specify	1	9300 - (default)
Front Bezel			
EJU2	Front IBM Bezel for 12-Bay BackPlane	1	41A Rack: used with #EJ1C or #EJ1M backplanes
or			
EJUF	Front IBM Bezel for 18-Bay Backplane	1	41A Rack: used with #EJ1D backplane
or			
EJU8	Front IBM Bezel for 12-Bay BackPlane	1	41A Tower: used with #EJ1C or #EJ1M backplanes
or			
EJU9	Front IBM Bezel for 18-Bay BackPlane	1	41A Tower: used with #EJ1D backplane
Primary operating system			
2145	Primary Operating System Indicator - IBM i	1	Feature EB72 or EB73 is required

- The racking approach for the initial order must be either a 7014-T00, 7014-T42, 7965-S42, or 7953-94Y. If an additional rack is required for I/O expansion drawers as an MES to an existing system, either a feature 0551, 0553, or ER05 rack must be ordered.
- IBM i operating system performance: Clients with write-sensitive disk/HDD workloads should upgrade from the #EJ1C/#EJ1E base storage backplane to the #EJ1M/#EJ1D expanded function storage backplanes to gain the performance advantage of write cache.

### Hardware Management Console (HMC) machine code

An HMC is required to manage the Power S914 server (9009-41A) implementing partitioning. Multiple POWER7<sup>(R)</sup>, POWER8<sup>(R)</sup>, and POWER9 processor-based servers can be supported by a single HMC. Planned HMC hardware and software support:

- X86 based - 7042-CR7, 7042-CR8, 7042-CR9
  - vHMC x86
- POWER8 based Open Power: 7063-CR1
  - vHMC PowerVM based LPAR

If you are attaching an HMC to a new server or adding function to an existing server that requires a firmware update, the HMC machine code may need to be updated because HMC code must always be equal to or higher than the managed server's firmware. Access to firmware and machine code updates is conditioned on entitlement and license validation in accordance with IBM policy and practice.

IBM may verify entitlement through customer number, serial number, electronic restrictions, or any other means or methods employed by IBM at its discretion.

To determine the HMC machine code level required for the firmware level on any server, go to the following web page to access the Fix Level Recommendation Tool (FLRT) on or after the planned availability date for this product. FLRT will identify the correct HMC machine code for the selected system firmware level; see the [IBM Support: Fix Central](#) website.

If a single HMC is attached to multiple servers, the HMC machine code level must be updated to be at or higher than the server with the most recent firmware level. All prior levels of server firmware are supported with the latest HMC machine code level.

The HMC code latest level contains the following:

- Support for managing IBM Power System S922, S924, S914, and L922 systems.
- Support for the new HMC model 7063-CR1.
- Support for PowerVM functions such as the new HMC GUI interface for VIOS management.
- GUI for HMC's Performance and Capacity Monitoring function.
- An HMC command to initiate a remote restart operation. This removes the requirement of VMControl for the PowerVM Remote Restart function.
- For PowerVM GUI functions, VIOS is recommended.

For clients installing systems higher than the EIA 29 position (location of the rail that supports the rack-mounted server) in any IBM or non-IBM rack, acquire approved tools outlined in the server specifications section at [IBM Knowledge Center](#). In situations where IBM service is required and the recommended tools are not available, there could be delays in repair actions.

### **Software requirements**

If installing the Linux operating system LPAR:

- Red Hat Enterprise Linux 7 for Power LE, version 7.4, or later
- SUSE Linux Enterprise Server 12 Service Pack 3, or later
- Ubuntu Server 16.04.4, or later

If installing IBM i, the IBM i operating system levels supported are:

- IBM i 7.3 TR4
- IBM i 7.2 TR8

If installing the AIX operating system LPAR with any I/O configuration (one of these):

- AIX Version 7.2 with the 7200-02 Technology Level and Service Pack 7200-02-02-1810, or later
- AIX Version 7.1 with the 7100-05 Technology Level and Service Pack 7100-05-02-1810, or later
- AIX Version 6.1 with the 6100-09 Technology Level and Service Pack 6100-09-11-1810, or later (AIX 6.1 service extension required)
- AIX Version 7.2 with the 7200-01 Technology Level and Service Pack 7200-01-04-1806, or later (planned availability May 4, 2018)
- AIX Version 7.2 with the 7200-00 Technology Level and Service Pack 7200-00-06-1806, or later (planned availability May 4, 2018)
- AIX Version 7.1 with the 7100-04 Technology Level and Service Pack 7100-04-06-1806, or later (planned availability May 4, 2018)

If installing the AIX operating system Virtual I/O only LPAR (one of these):



- AIX Version 7.2 with the 7200-02 Technology Level and Service Pack 7200-02-01-1732, or later
- AIX Version 7.2 with the 7200-01 Technology Level and Service Pack 7200-01-01-1642, or later
- AIX Version 7.2 with the 7200-00 Technology Level and Service Pack 7200-00-01-1543, or later
- AIX Version 7.1 with the 7100-05 Technology Level and Service Pack 7100-05-01-1731, or later
- AIX Version 7.1 with the 7100-04 Technology Level and Service Pack 7100-04-01-1543, or later
- AIX Version 6.1 with the 6100-09 Technology Level and Service Pack 6100-09-06-1543, or later (AIX 6.1 service extension required)

If installing VIOS:

- VIOS 2.2.6.21 or later

### **Limitations**

- Integrated system port is not supported under AIX or Linux when the HMC ports are connected to an HMC. Either the HMC ports or the integrated system ports can be used, but not both. The FSP2 USB 2.0 port is used for communication to a UPS.
- The integrated system port is supported for modem and TTY terminal connections by AIX or Linux. Any other application using serial ports requires a serial port adapter to be installed in a PCI slot. The integrated system port does not support HACMP™ configurations.

### **Boot requirements**

- If IBM i (#2145) is selected as the primary operating system and SAN boot is not selected (#0837), one of the load source specify codes must be specified.
- If IBM i (#2145) is selected and the load source disk unit is not in the CEC (system unit), one of the following specify codes must also be selected:
  - #0719 Load Source Not in CEC and are to be placed in I/O drawers or in external SAN-attached disk
  - #EHR2 Load Source Specifies DASD are placed in an EXP24SX SFF Gen 2 bay Drawer (#ESLS or #ELLS)
  - #0837 SAN Operating System Load Source Specify
- If IBM i (#2145) is selected, one of the following system console specify codes must be selected:
  - #5550 - System Console on HMC
  - #5557 - System Console - Internal LAN

### **4-core S914 processor feature**

The PCIe expansion drawer (#EMX0) and EXP24SX /EXP12SX SAS Storage Enclosures (#ESLS/ELLS or #ESLL/ELLL) do not apply to the 4-core configuration S914 server.

### **Planning information**

---

#### **Cable orders**

No additional cables are required.

#### **Security, auditability, and control**

---

This product uses the security and auditability features of host hardware and application software.

The customer is responsible for evaluation, selection, and implementation of security features, administrative procedures, and appropriate controls in application systems and communications facilities.

---

### **IBM Systems Lab Services**

For details on available services, contact your IBM representative or go to the [IBM Systems Lab Services](#) website.

---

### **IBM Electronic Services**

IBM has transformed its delivery of hardware and software support services to help you achieve higher system availability. Electronic Services is a web-enabled solution that offers an exclusive, no-additional-charge enhancement to the service and support available for IBM servers. These services are designed to provide the opportunity for greater system availability with faster problem resolution and preemptive monitoring. Electronic Services comprises two separate, but complementary, elements: Electronic Services news page and Electronic Services Agent.

The Electronic Services news page is a single internet entry point that replaces the multiple entry points traditionally used to access IBM Internet services and support. The news page enables you to gain easier access to IBM resources for assistance in resolving technical problems.

The Electronic Service Agent™ is no-additional-charge software that resides on your server. It monitors events and transmits system inventory information to IBM on a periodic, client-defined timetable. The Electronic Service Agent automatically reports hardware problems to IBM. Early knowledge about potential problems enables IBM to deliver proactive service that may result in higher system availability and performance. In addition, information collected through the Service Agent is made available to IBM service support representatives when they help answer your questions or diagnose problems. Installation and use of IBM Electronic Service Agent for problem reporting enables IBM to provide better support and service for your IBM server.

To learn how Electronic Services can work for you, go to the [IBM Electronic Support](#) website.

---

### **Terms and conditions**

---

#### **Volume orders**

Contact your IBM representative.

---

#### **IBM Global Financing**

Yes

---

#### **Products - terms and conditions**

---

##### ***Warranty period***

<b>Warranty and additional coverage options:</b>	<b>Coverage summary<sup>1</sup>:</b>
Warranty Period:	3 years
Service Level:	IBM On-Site Limited, 9x5 Next Business Day

---

##### **Service Upgrade Options :**

<b>Warranty and additional coverage options:</b>	<b>Coverage summary<sup>1</sup>:</b>
Warranty Service Upgrade	IBM On-Site Repair, 9x5 Same Day <sup>2</sup> and 24x7 Same Day options
Maintenance Services (Post-Warranty):	IBM On-Site Repair, Next Business Day and Same Day options
IBM Hardware Maintenance Services - committed maintenance <sup>3</sup> :	Y

<sup>1</sup> See complete coverage details below.

<sup>2</sup> Offered in US and EMEA only.

<sup>3</sup> Not offered in the US.

Three years.

To obtain copies of the IBM Statement of Limited Warranty, contact your reseller or IBM.

An IBM part or feature installed during the initial installation of an IBM machine is subject to the full warranty period specified by IBM. An IBM part or feature that replaces a previously installed part or feature assumes the remainder of the warranty period for the replaced part or feature. An IBM part or feature added to a machine without replacing a previously installed part or feature is subject to a full warranty. Unless specified otherwise, the warranty period, type of warranty service, and service level of a part or feature are the same as those for the machine in which it is installed.

Any IBM Mainstream devices (previously called *read intensive device*) identified in this document have a maximum number of write cycles. IBM Mainstream device failures will be replaced during standard warranty and maintenance period for devices that have not reached the maximum number of write cycles. Devices that reach this limit may fail to operate according to specifications and must be replaced at the client's expense. Individual service life may vary and can be monitored using an operating system command.

The IBM warranty covers feature number EB4Z. For warranty terms associated with feature number EB3Z and the Lift tool based on GenieLift GL-8, see the separate warranty terms provided by Genie found in the Genie Operator's Manual at the [Genie](#) website.

For clients installing systems higher than the EIA 29 position (location of the rail that supports the rack-mounted server) in any IBM or non-IBM rack, acquire approved tools outlined in the server specifications section at [IBM Knowledge Center](#). In situations where IBM service is required and the recommended tools are not available, there could be delays in repair actions.

### **Warranty services**

If required, IBM provides repair or exchange service depending on the types of warranty service specified for the machine. IBM will attempt to resolve your problem over the telephone, or electronically through an IBM website. Certain machines contain remote support capabilities for direct problem reporting, remote problem determination, and resolution with IBM. You must follow the problem determination and resolution procedures that IBM specifies. Following problem determination, if IBM determines on-site service is required, scheduling of service will depend upon the time of your call, machine technology and redundancy, and availability of parts. If applicable to your product, parts considered Customer Replaceable Units (CRUs) will be provided as part of the machine's standard warranty service.

Service levels are response-time objectives and are not guaranteed. The specified level of warranty service may not be available in all worldwide locations. Additional charges may apply outside IBM's normal service area. Contact your local IBM representative or your reseller for country-specific and location-specific information.

## **CRU Service**

IBM provides replacement CRUs to you for you to install. CRU information and replacement instructions are shipped with your machine and are available from IBM upon your request. CRUs are designated as being either a Tier 1 (mandatory) or a Tier 2 (optional) CRU.

### **Tier 1 (mandatory) CRU**

Installation of Tier 1 CRUs, as specified in this announcement, is your responsibility. If IBM installs a Tier 1 CRU at your request, you will be charged for the installation.

The following parts have been designated as Tier 1 CRUs:

- DASD SFF Drive
- DASD SSD Drive
- RDX Drive
- Enclosure
- Power Cable
- NVMe M.2 Carrier card and Flash Modules
- SAS Card
- Op Panel - Base
- Op Panel - LCD
- Memory DIMM
- All PCI Adapters
- FAN
- Upper Fan cable
- TPM Card
- Power Supplies
- Service Processor Card/FSP
- TOD Battery
- Air Baffle
- Bezel
- SAS Cable
- Front Heatsink
- Service Cover
- DASD Backplane Power Cable
- DASD Backplane Signal Cable

### **Tier 2 (optional) CRU**

You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge.

Based upon availability, CRUs will be shipped for next-business-day (NBD) delivery. IBM specifies, in the materials shipped with a replacement CRU, whether a defective CRU must be returned to IBM. When return is required, return instructions and a container are shipped with the replacement CRU. You may be charged for the replacement CRU if IBM does not receive the defective CRU within 15 days of your receipt of the replacement.

### **CRU and On-site Service**

At IBM's discretion, you will receive specified CRU service, or IBM will repair the failing machine at your location and verify its operation. You must provide a suitable working area to allow disassembly and reassembly of the IBM machine. The area must be clean, well-lit, and suitable for the purpose.

Service level is:

- 9 hours per day, Monday through Friday, excluding holidays, next-business-day response. Calls must be received by 3:00 PM local time in order to qualify for next-business-day response.

### **Warranty service**

IBM is now shipping machines with selected non-IBM parts that contain an IBM field replaceable unit (FRU) part number label. These parts are to be serviced during the IBM machine warranty period. IBM is covering the service on these selected non-IBM parts as an accommodation to their customers, and normal warranty service procedures for the IBM machine apply.

### **International Warranty Service**

International Warranty Service allows you to relocate any machine that is eligible for International Warranty Service and receive continued warranty service in any country where the IBM machine is serviced. If you move your machine to a different country, you are required to report the machine information to your Business Partner or IBM representative.

The warranty service type and the service level provided in the servicing country may be different from that provided in the country in which the machine was purchased. Warranty service will be provided with the prevailing warranty service type and service level available for the eligible machine type in the servicing country, and the warranty period observed will be that of the country in which the machine was purchased.

The following types of information can be found on the [International Warranty Service](#) website

- Machine warranty entitlement and eligibility
- Directory of contacts by country with technical support contact information
- Announcement Letters

### **Warranty service upgrades**

During the warranty period, warranty service upgrades provide an enhanced level of On-site Service for an additional charge. Service levels are response-time objectives and are not guaranteed. See the [Warranty services](#) section for additional details.

IBM will attempt to resolve your problem over the telephone or electronically by access to an IBM website. Certain machines contain remote support capabilities for direct problem reporting, remote problem determination, and resolution with IBM. You must follow the problem determination and resolution procedures that IBM specifies. Following problem determination, if IBM determines on-site service is required, scheduling of service will depend upon the time of your call, machine technology and redundancy, and availability of parts.

### **Maintenance service options**

#### **CRU and On-site Service**

At IBM's discretion, you will receive CRU service or IBM will repair the failing machine at your location and verify its operation. You must provide a suitable working area to allow disassembly and reassembly of the IBM machine. The area must be clean, well-lit, and suitable for the purpose. The following on-site response-time objectives are available as warranty service upgrades for your machine. Available offerings are:

- On-Site Repair, Monday through Friday (excluding holidays), 8 AM to 5 PM, 4-hour on-site response objective. Response times are objectives and are not guaranteed
- On-Site Repair, 7 days a week, 24hrs/day.

- On-Site Repair, 7 days a week, 24hrs/day, 2-hour response objective. Response times are objectives and are not guaranteed.

Customer Replaceable Units (CRUs) may be provided as part of the machine's standard warranty CRU Service except that you may install a CRU yourself or request IBM installation, at no additional charge, under the CRU and On-site Service level specified above. For additional information on the CRU Service, see the warranty information.

### **Maintenance services**

If required, IBM provides repair or exchange service depending on the types of maintenance service specified for the machine. IBM will attempt to resolve your problem over the telephone or electronically, through an IBM website. Certain machines contain remote support capabilities for direct problem reporting, remote problem determination, and resolution with IBM. You must follow the problem determination and resolution procedures that IBM specifies. Following problem determination, if IBM determines on-site service is required, scheduling of service will depend upon the time of your call, machine technology and redundancy, and availability of parts. Service levels are response-time objectives and are not guaranteed. The specified level of maintenance service may not be available in all worldwide locations. Additional charges may apply outside IBM's normal service area. Contact your local IBM representative or your reseller for country-specific and location-specific information.

The following service selections are available as maintenance options, at additional cost, for your machine type.

- On-Site Repair, Monday through Friday (excluding holidays), 8 AM to 5 PM, next business day.
- On-Site Repair, Monday through Friday (excluding holidays), 8 AM to 5 PM, 4-hour response objective. Response times are objectives and are not guaranteed.
- On-Site Repair, 7 days a week, 24hrs/day.
- On-Site Repair, 7 days a week, 24hrs/day, 2-hour response objective. Response times are objectives and are not guaranteed.

### **On-site Service**

IBM will repair the failing machine at your location and verify its operation. You must provide a suitable working area to allow disassembly and reassembly of the IBM machine. The area must be clean, well-lit, and suitable for the purpose.

### **Customer Replaceable Unit (CRU) Service**

If your problem can be resolved with a CRU (for example, keyboard, mouse, speaker, memory, or hard disk drive), and depending upon the maintenance service offerings in your geography, IBM will ship the replacement CRU to you for you to install. CRU information and replacement instructions are shipped with your machine and are available from IBM upon your request.

CRUs will be shipped based upon availability. IBM specifies, in the materials shipped with a replacement CRU, whether a defective CRU must be returned to IBM. When return is required, 1) return instructions and a container are shipped with the replacement CRU, and 2) you may be charged for the replacement CRU if IBM does not receive the defective CRU within 15 days of your receipt of the replacement.

CRUs are designated as being either a Tier 1 (mandatory) or a Tier 2 (optional) CRU.

Tier 1 (mandatory) CRUs: Installation of Tier 1 CRUs, as specified in this announcement, is your responsibility. If IBM installs a Tier 1 CRU at your request, you will be charged for the installation.

For machines with On-site Same-day Response Service, IBM will replace a Tier 1 CRU part at your request, at no additional charge.

The following parts have been designated as Tier 1 CRUs:

- DASD SFF Drive
- DASD SSD Drive
- RDX Drive
- Enclosure
- Power Cable
- NVMe M.2 Carrier card and Flash Modules
- SAS Card
- Op Panel - Base
- Op Panel - LCD
- Memory DIMM
- All PCI Adapters
- FAN
- Upper Fan cable
- TPM Card
- Power Supplies
- Service Processor Card/FSP
- TOD Battery
- Air Baffle
- Bezel
- SAS Cable Front
- Heatsink
- Service Cover
- DASD Backplane Power Cable
- DASD Backplane Signal Cable

Tier 2 (optional) CRUs: You may install a Tier 2 CRU yourself or request IBM to install it, at no additional charge.

### ***Non-IBM parts service***

Under certain conditions, IBM provides services for selected non-IBM parts at no additional charge for machines that are covered under warranty service upgrades or maintenance services.

This service includes hardware problem determination (PD) on the non-IBM parts (for example, adapter cards, PCMCIA cards, disk drives, memory) installed within IBM machines and provides the labor to replace the failing parts at no additional charge.

If IBM has a Technical Service Agreement with the manufacturer of the failing part, or if the failing part is an accommodations part (a part with an IBM FRU label), IBM may also source and replace the failing part at no additional charge. For all other non-IBM parts, customers are responsible for sourcing the parts. Installation labor is provided at no additional charge, if the machine is covered under a warranty service upgrade or a maintenance service.

### ***Usage plan machine***

No

### ***IBM hourly service rate classification***

Two

When a type of service involves the exchange of a machine part, the replacement may not be new, but will be in good working order.

## **General terms and conditions**

---

### ***Field-installable features***

Yes

### ***Model conversions***

No

### ***Machine installation***

Customer setup. Customers are responsible for installation according to the instructions IBM provides with the machine.

### ***Graduated program license charges apply***

Yes

The applicable processor group is: Small

### ***Licensed Machine Code***

IBM Machine Code is licensed for use by a customer on the IBM machine for which it was provided by IBM under the terms and conditions of the IBM License Agreement for Machine Code, to enable the machine to function in accordance with its specifications, and only for the capacity authorized by IBM and acquired by the customer. You can obtain the agreement by contacting your IBM representative. It can also be found on the [License Agreement for Machine Code and Licensed Internal Code](#) website.

Machine using LMC Type Model 9009-41A

Access to Machine Code updates is conditioned on entitlement and license validation in accordance with IBM policy and practice. IBM may verify entitlement through customer number, serial number, electronic restrictions, or any other means or methods employed by IBM in its discretion.

If the machine does not function as warranted and your problem can be resolved through your application of downloadable Machine Code, you are responsible for downloading and installing these designated Machine Code changes as IBM specifies. If you would prefer, you may request IBM to install downloadable Machine Code changes; however, you may be charged for that service.

### ***Machine Code License Acceptance Requirement***

B.) Acceptance-By-Use Machine: No, the Machine Code license requires signed acceptance by the machine's end user directly with IBM, applicable to orders for a new machine, machine type conversion MES, and to machines transferred to another user.

### ***Educational allowance***

A reduced charge is available to qualified education customers. The educational allowance may not be added to any other discount or allowance.

The educational allowance is 8% for the products in this announcement.

---

## **Prices**

---

For additional information and current prices, contact your local IBM representative.



## Product charges

The following are newly announced features on the specific models of the IBM Power Systems 9009 machine type:

Description	Model number	Feature number	Purchase price	Minimum Monthly Maint. Charge	Initial/MES/Both/Support	RP CSU	MES
IBM Power System S914	41A					Yes	
One CSC Billing Unit	41A	0010			Both	Yes	No
Ten CSC Billing Units	41A	0011			Both	Yes	No
Mirrored System Disk Level, Sp	41A	0040			Both	Yes	No
Device Parity Protection All	41A	0041			Both	Yes	No
Mirrored System Bus Level	41A	0043			Both	Yes	No
Device Parity RAID 6 All	41A	0047			Both	Yes	No
RISC to RISC Data Migration	41A	0205			Initial	N/A	No
AIX Partition Specify	41A	0265			Both	Yes	No
Linux Partition Specify	41A	0266			Both	Yes	No
IBM i Partition Specify	41A	0267			Both	Yes	No
Specify Custom Data Protection	41A	0296			Both	Yes	No
Mirrored Level System Specify	41A	0308			Both	Yes	No
RAID Hot Spare Specify	41A	0347			Both	Yes	No
V.24/EIA232 6.1m (20 Ft) PCI C	41A	0348			Both	Yes	No
V.35 6.1m (20 Ft) PCI Cable	41A	0353			Both	Yes	No
X.21 6.1m (20 Ft) PCI Cable	41A	0359			Both	Yes	No
CBU Specify	41A	0444			Initial	N/A	No
Customer Specified Placement	41A	0456			Initial	N/A	No
19 inch, 1.8 meter high rack	41A	0551			MES	Yes	No
19 inch, 2.0 meter high rack	41A	0553			MES	Yes	No
Rack Filler Panel Kit	41A	0599			Both	Yes	No
Load Source Not in CEC	41A	0719			Both	Yes	No
SAN Load Source Specify	41A	0837			Both	Yes	No
US TAA Compliance Indicator	41A	0983			Both	Yes	No
Asm in USA manufacturing plant	41A	0984			Both	N/A	No
Modem Cable US/Canada and GU	41A	1025			Both	Yes	No
USB 500 GB Removable Disk Dr	41A	1107			Both	Yes	No
Custom Serv. Specify, Roch							

	41A	1140	Both	Yes	No
Quantity 150 of #1964	41A	1818	Both	Yes	No
Quantity 150 of #1953	41A	1929	Both	Yes	No
300GB 15k RPM SAS SFF-2 Disk	41A	1953	Both	Yes	No
600GB 10k RPM SAS SFF-2 Disk	41A	1964	Both	Yes	No
Primary OS - IBM i	41A	2145	Both	Yes	No
Primary OS AIX	41A	2146	Both	Yes	No
Primary OS Linux	41A	2147	Both	Yes	No
Factory Deconfiguration of 1 c	41A	2319	Initial	N/A	No
LC-SC 50 Micron Fiber Conv Cab	41A	2456	Both	Yes	No
LC-SC 62.5 Mic.Fib.Conv.Cable	41A	2459	Both	Yes	No
Asynch.Termin/Print.Cbl	EIA232				
	41A	2934	Both	Yes	No
Asynchronous Cable EIA 232/V	41A	2936	Both	Yes	No
Ser to Ser Port Cab Draw/Draw	41A	3124	Both	Yes	No
Serial to Se.Port Cbl Rack 8M	41A	3125	Both	Yes	No
Widescreen LCD Monitor	41A	3632	Support	Yes	No
0.3M Serial Prt Converter Cbl	41A	3925	Both	Yes	No
Serial Port Null Mod Cab 3.7M	41A	3927	Both	Yes	No
Ser.Port Null Modem Cable,10M	41A	3928	Both	Yes	No
System Serial Port Converter C	41A	3930	Both	Yes	No
6Foot Extend.Cbl for Displays	41A	4242	Support	Yes	No
Extender Cable USB Keybo 1.8M	41A	4256	Both	Yes	No
VGA to DVI Connection Converte	41A	4276	Both	Yes	No
Rack Integration Services: BP	41A	4648	Initial	N/A	No
Rack Integration Services	41A	4649	Initial	N/A	No
One and only one rack indicator feature is required on all orders (#4650 to #4666).					
No Factory Integration Ind.	41A	4650	Initial	N/A	No
Rack Indicator, Rack 1	41A	4651	Initial	N/A	No
Rack Indicator, Rack 2	41A	4652	Initial	N/A	No
Rack Indicator, Rack 3	41A	4653	Initial	N/A	No
Rack Indicator, Rack 4	41A	4654	Initial	N/A	No
Rack Indicator, Rack 5	41A	4655	Initial	N/A	No
Rack Indicator, Rack 6	41A	4656	Initial	N/A	No
Rack Indicator, Rack 7	41A	4657	Initial	N/A	No
Rack Indicator, Rack 8	41A	4658	Initial	N/A	No
Rack Indicator, Rack 9	41A	4659	Initial	N/A	No
Rack Indicator, Rack 10	41A	4660	Initial	N/A	No

Rack Indicator, Rack 11	41A	4661	Initial	N/A	No
Rack Indicator, Rack 12	41A	4662	Initial	N/A	No
Rack Indicator, Rack 13	41A	4663	Initial	N/A	No
Rack Indicator, Rack 14	41A	4664	Initial	N/A	No
Rack Indicator, Rack 15	41A	4665	Initial	N/A	No
Rack Indicator, Rack 16	41A	4666	Initial	N/A	No
Power Active Memory Expansion	41A	4794	Both	Yes	No
IBM i Solution Edition	41A	4927	Initial	N/A	No
Solution Edition for IBM i	41A	4928	Initial	N/A	No
Software Preload Required	41A	5000	Initial	N/A	No
PowerVM Enterprise Edition	41A	5228	Both	Yes	No
Sys Console On HMC	41A	5550	Both	Yes	No
Sys Console-Ethernet LAN	41A	5557	Initial	N/A	No
PCIe2 8Gb 4-port Fibre Channel	41A	5729	Both	Yes	No
8 Gigabit PCI Express Dual Por	41A	5735	Both	Yes	No
POWER GXT145 PCI Express Graph	41A	5748	Both	Yes	No
4 Port Async EIA 232 PCIe Adap	41A	5785	Both	Yes	No
PCIe2 4-port 1GbE Adapter	41A	5899	Both	Yes	No
Opt Front Door for 1.8m Rack	41A	6068	MES	Yes	No
Opt Front Door for 2.0m Rack	41A	6069	MES	Yes	No
1.8m Rack Acoustic Doors	41A	6248	MES	Yes	No
2.0m Rack Acoustic Doors	41A	6249	MES	Yes	No
1.8m Rack Trim Kit	41A	6263	MES	Yes	No
2.0m Rack Trim Kit	41A	6272	MES	Yes	No
Pwr Crd 4.3m 14ft to IBM PDU	41A	6458	Both	Yes	No
Pwr Crd (14FT), Drwr - OEM PDU	41A	6460	Both	Yes	No
Pwr Crd 4.3m 14ft wall OEM PDU	41A	6469	Both	Yes	No
Pwr Crd 1.8m 6ft wall 125V/15A	41A	6470	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6471	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6472	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6473	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6474	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6475	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6476	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6477	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6478	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6488	Both	Yes	No

4.3m (14 Ft) 3PH/24A Power Cor	41A	6489	MES	Yes	No
4.3m (14 Ft) 1PH/63A Pwr Cord	41A	6491	MES	Yes	No
4.3m (14 Ft) 1PH/48 60A Pwr Co	41A	6492	MES	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6493	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6494	Both	Yes	No
Pwr Crd 2.7m 9ft wall 250V,10A	41A	6496	Both	Yes	No
Power Cable Drawer to IBM PD	41A	6577	Both	Yes	No
Optional Rack Security Kit	41A	6580	MES	Yes	No
Pwr Crd 2.7m 9ft wall 125V,15A	41A	6651	Both	Yes	No
4.3m 3PH/16A Power Cord	41A	6653	MES	Yes	No
4.3m 1PH/24-30A Pwr Cord	41A	6654	MES	Yes	No
4.3m 14Ft 1PH/24 30A WR Pwr	41A	6655	MES	Yes	No
4.3m 14Ft 1PH/24A Power Cord	41A	6656	MES	Yes	No
4.3m 14Ft 1PH/32A Power Cord	41A	6657	MES	Yes	No
4.3m 14Ft 1PH/24A Pwr Cd Kor	41A	6658	MES	Yes	No
Pwr.Cord(9ft),To wall/OEM PDU	41A	6659	Both	Yes	No
Pwr Crd 14ft 4.3m wallOEM PDU	41A	6660	Both	Yes	No
Pwr Crd 2.8m 9.2ft PDU	41A	6665	Both	Yes	No
4.3m 14Ft 3PH/32A Pwr Cd Aus	41A	6667	MES	Yes	No
Pwr Crd 4.3M, Drwr - OEM PDU	41A	6669	Both	Yes	No
Pwr Crd 2.7m, Drwr - IBM PDU	41A	6671	Both	Yes	No
Pwr Crd 2M, Drwr - IBM PDU	41A	6672	Both	Yes	No
Pwr Crd 2.7m 9ft wall OEM PDU	41A	6680	Both	Yes	No
IIntelligent PDU+ 1 EIA Unit	41A	7109	MES	Yes	No
Environmental Monitoring Probe	41A	7118	Both	Yes	No
Power Distribution Unit	41A	7188	MES	Yes	No
PowDistribUnit(US)Fixed PowCrd	41A	7196	Both	Yes	No
Eth Cbl 15M HW Management	41A	7802	Both	Yes	No
Linux Software Preinstall	41A	8143	Initial	N/A	No
Linux Software Preinstall BP	41A	8144	Initial	N/A	No
USB Mouse	41A	8845	Support	Yes	No
Order Routing Indicator Syste	41A	9169	Initial	N/A	No
Language Group Spcf-US Eng	41A	9300	Initial	N/A	No
New AIX License Core Counter	41A	9440	Initial	N/A	No
New IBM i Lic Core Counter	41A	9441	Initial	N/A	No
New Red Hat Lic Core Counter	41A	9442	Initial	N/A	No
New SUSE Lic Core Counter	41A	9443	Initial	N/A	No

Other AIX Lic Core Counter	41A	9444	Initial	N/A	No
Other Linux Lic Core Counter	41A	9445	Initial	N/A	No
3rd Party Linux Lic Core Cnt	41A	9446	Initial	N/A	No
VIOS Core Counter	41A	9447	Initial	N/A	No
Other License Core Counter	41A	9449	Initial	N/A	No
Ubuntu Linux License Core Cntr	41A	9450	Initial	N/A	No
Month Indicator	41A	9461	Initial	N/A	No
Day Indicator	41A	9462	Initial	N/A	No
Hour Indicator	41A	9463	Initial	N/A	No
Minute Indicator	41A	9464	Initial	N/A	No
Qty Indicator	41A	9465	Initial	N/A	No
Countable Member Indicator	41A	9466	Initial	N/A	No
Language Group Spcf-Dutch	41A	9700	Initial	N/A	No
Language Group Spcf-French	41A	9703	Initial	N/A	No
Language Group Spcf-German	41A	9704	Initial	N/A	No
Language Group Spcf-Polish	41A	9705	Initial	N/A	No
Lang Group Specify - Norwegian	41A	9706	Initial	N/A	No
Lang.Group Spcf-Portuguese	41A	9707	Initial	N/A	No
Language Group Spcf-Spanish	41A	9708	Initial	N/A	No
Language Group Spcf-Italian	41A	9711	Initial	N/A	No
Langua Gr Speci Canadian Frenc	41A	9712	Initial	N/A	No
Language Group Spcf-Japanese	41A	9714	Initial	N/A	No
Language Group Specify Tr Chin	41A	9715	Initial	N/A	No
Language Group Spcf-Korean	41A	9716	Initial	N/A	No
Language Group Spcf-Turkish	41A	9718	Initial	N/A	No
Language Group Spcf-Hungarian	41A	9719	Initial	N/A	No
Language Group Spcf-Slovakian	41A	9720	Initial	N/A	No
Language Group Spcf-Russian	41A	9721	Initial	N/A	No
Lang Group Spcf Simpl Chinese	41A	9722	Initial	N/A	No
Language Group Spcf-Czech	41A	9724	Initial	N/A	No
Language Group Spcf-Romanian	41A	9725	Initial	N/A	No
Lang Group Specify - Croatian	41A	9726	Initial	N/A	No
Language Group Spcf-Slovenian	41A	9727	Initial	N/A	No
Lang Group Specify - Braz Port	41A	9728	Initial	N/A	No
Lang Group Specify - Thai	41A	9729	Initial	N/A	No
10m QSFP+ MTP Optical Cable	41A	EB2J	Both	Yes	No
30m QSFP+ MTP Optical Cable					

AC Power Supply - 900W	41A	EB2K	Both	Yes	No
Power Supply 1400W 200-240 VAC	41A	EB2L	Both	Yes	No
Lift tool GenieLift GL-8	41A	EB2M	Both	Yes	No
10Gb Optical Transceiver SFP+	41A	EB3Z	Both	Yes	No
25Gb Opt Transceiver SFP28	41A	EB46	Both	Yes	No
0.5 SFP/25GbE CU Cable	41A	EB47	Both	Yes	No
1.0 SFP/25GbE CU Cable	41A	EB4J	Both	Yes	No
1.5 SFP/25GbE CU Cable	41A	EB4K	Both	Yes	No
2.0 SFP/25GbE CU Cable	41A	EB4L	Both	Yes	No
2.5 QSFP28/100GbE CU Cable	41A	EB4M	Both	Yes	No
Service wedge shelf for	41A	EB4P	Both	Yes	No
0.5m EDR IB Copper Cable	41A	EB4Z	Both	No	No
1.0m EDR IB Copper Cable	41A	EB50	Both	Yes	No
2.0M EDR IB Copper Cable	41A	EB51	Both	Yes	No
1.5M EDR IB Copper Cable	41A	EB52	Both	Yes	No
100Gb Optic Transceiver QSFP28	41A	EB54	Both	Yes	No
3M EDR IB Optical Cable	41A	EB59	Both	Yes	No
5M EDR IB Optical Cable	41A	EB5A	Both	Yes	No
10M EDR IB Optical Cable	41A	EB5B	Both	Yes	No
15M EDR IB Optical Cable	41A	EB5C	Both	Yes	No
20M EDR IB Optical Cable	41A	EB5D	Both	Yes	No
30M EDR IB Optical Cable	41A	EB5E	Both	Yes	No
50M EDR IB Optical Cable	41A	EB5F	Both	Yes	No
100M EDR IB Optical Cable	41A	EB5G	Both	Yes	No
0.5M 100GbE Cu Cable QSFP28	41A	EB5H	Both	Yes	No
1.0M 100GbE Cu Cable QSFP28	41A	EB5J	Both	Yes	No
1.5M 100GbE Cu Cable QSFP28	41A	EB5K	Both	Yes	No
2.0M 100GbE Cu Cable QSFP28	41A	EB5L	Both	Yes	No
25M EDR IB Optical Cable	41A	EB5M	Both	Yes	No
3M 100GbE optic Cable QSFP28	41A	EB5N	Both	Yes	No
5M 100GbE optic Cable QSFP28	41A	EB5R	Both	Yes	No
10M 100GbE optic Cable QSFP28	41A	EB5S	Both	Yes	No
15M 100GbE optic Cable QSFP28	41A	EB5T	Both	Yes	No
20M 100GbE optic Cable QSFP28	41A	EB5U	Both	Yes	No
30M 100GbE optic Cable QSFP28	41A	EB5V	Both	Yes	No
50M 100GbE optic Cable QSFP28	41A	EB5W	Both	Yes	No
100M 100GbE optic Cable QSFP28	41A	EB5X	Both	Yes	No

	41A	EB5Y	Both	Yes	No
IBM i 7.2 Indicator	41A	EB72	Both	Yes	No
IBM i 7.3 Indicator	41A	EB73	Both	Yes	No
Rack Front Door (Black)	41A	EC01	MES	Yes	No
Rack Rear Door	41A	EC02	MES	Yes	No
Rack Side Cover	41A	EC03	MES	Yes	No
Rack Suite Attachment Kit	41A	EC04	MES	Yes	No
Slim Rear Acoustic Door	41A	EC07	MES	Yes	No
Slim Front Acoustic Door	41A	EC08	MES	Yes	No
Rear Door Heat Exchanger	41A	EC15	MES	Yes	No
PCIe3 2-Port 10Gb NIC&ROCE	41A	EC2S	Both	Yes	No
PCIe3 2-Port 25/10Gb NIC&Ro	41A	EC2U	Both	Yes	No
PCIe3 2-port 100GbE Adapterx16	41A	EC3M	Both	Yes	No
PCIe3 NVMe carrier card	41A	EC59	Both	Yes	No
PCIe4 1-port 100Gb EDR IB	41A	EC63	Both	Yes	No
PCIe4 2-port 100Gb EDR IB	41A	EC65	Both	Yes	No
SAS X Cable 3m - HD Narrow	41A	ECBJ	Both	Yes	No
SAS X Cable 6m - HD Narrow	41A	ECBK	Both	Yes	No
SAS X Cable 10m - HD Narrow	41A	ECBL	Both	Yes	No
SAS X Cable 15m -HD Narrow 3Gb	41A	ECBM	Both	Yes	No
SAS YO Cable 1.5m - HD Narrow	41A	ECBT	Both	Yes	No
SAS YO Cable 3m - HD Narrow	41A	ECBU	Both	Yes	No
SAS YO Cable 6m - HD Narrow	41A	ECBV	Both	Yes	No
SAS YO Cable 10m - HD Narrow	41A	ECBW	Both	Yes	No
SAS YO Cable 15m-HD Narrow 3Gb	41A	ECBX	Both	Yes	No
SAS AE1 Cable 4m - HD Narrow	41A	ECBY	Both	Yes	No
SAS YE1 Cable 3m - HD Narrow	41A	ECBZ	Both	Yes	No
SAS AA Cable 0.6m - HD Narrow	41A	ECC0	Both	Yes	No
SAS AA Cable 1.5m - HD Narrow	41A	ECC2	Both	Yes	No
SAS AA Cable 3m - HD Narrow	41A	ECC3	Both	Yes	No
SAS AA Cable 6m - HD Narrow	41A	ECC4	Both	Yes	No
3M Optical Cable Pair	41A	ECC7	Both	Yes	No
10M Optical Cable Pair	41A	ECC8	Both	Yes	No
Port Converter Cable for UPS	41A	ECCF	Both	Yes	No
3M Copper CXP Cable Pair	41A	ECCS	Both	Yes	No
3.0M SAS X12 Cable	41A	ECDJ	Both	Yes	No
4.5M SAS X12 Cable	41A	ECDK	Both	Yes	No
10M SAS X12 Cable					

	41A	ECDL	Both	Yes	No
1.5M SAS Y012 Cable	41A	ECDT	Both	Yes	No
3.0M SAS Y012 Cable	41A	ECDU	Both	Yes	No
4.5M SAS Y012 Cable	41A	ECDV	Both	Yes	No
10M SAS Y012 Cable	41A	ECDW	Both	Yes	No
0.6M SAS AA12 Cable	41A	ECE0	Both	Yes	No
3.0M SAS AA12 Cable	41A	ECE3	Both	Yes	No
4.5M SAS AA12 Cable	41A	ECE4	Both	Yes	No
2.0 M Slim Rack	41A	ECR0	MES	Yes	No
Rack Front Door	41A	ECRF	MES	Yes	No
Rack Rear Door Black	41A	ECRG	MES	Yes	No
Rack Side Cover	41A	ECRJ	MES	Yes	No
Rack Rear Extension 5-In	41A	ECRK	MES	Yes	No
Rack Front Door (Black/Flat)	41A	ECRM	MES	Yes	No
Assembled and Tested in China	41A	ECS0	Both	Yes	No
Custom Serv. Specify, France	41A	ECSF	Both	Yes	No
NeuCloud Indicator/Specify	41A	ECSJ	Both	Yes	No
Custom Serv. Specify, Mexico	41A	ECSM	Both	Yes	No
Custom Serv. Spec Poughkeepsie	41A	ECSP	Both	Yes	No
Integrated Solution Packing	41A	ECSS	Initial	N/A	No
Optical wrap Plug	41A	ECW0	Both	Yes	No
Boot Drive in EXP12SX Specify	41A	EHR1	Both	Yes	No
Boot / Load in EXP24SX Specify	41A	EHR2	Both	Yes	No
SSD Placement Ind- #ESLS/#ELLS	41A	EHS2	Both	Yes	No
PCIe3 Optical Cable Adapter	41A	EJ08	Both	Yes	No
PCIe3 RAID SAS Adapter 4-port	41A	EJ0J	Both	Yes	No
SAS Ports: Dual IOA Backplane	41A	EJ0W	Both	Yes	No
PCIe3 SAS Tape/DVD Adapter	41A	EJ10	Both	Yes	No
PCIe3 12GB Cache RAID+ SAS Ada	41A	EJ14	Both	Yes	No
Backplane 12 SFF & RDX Bay	41A	EJ1C	Both	No	No
Backplane 18 SFF & Dual IOA	41A	EJ1D	Both	No	No
Split#EJ1C Add 2nd Controlle	41A	EJ1E	Both	No	No
Backplane 12 SFF & RDX Bay	41A	EJ1M	Both	No	No
PCIe3 Crypto Coproc BSC-3 4767	41A	EJ33	Both	Yes	No
Non-paired Indicator EJ0L PCIe	41A	EJRL	Both	Yes	No
Rack-mount Rail Kit	41A	EJTZ	Both	Yes	No
Front IBM Bezel 12-Bay BackP	41A	EJU2	Both	Yes	No
Front OEM Bezel 12-Bay BackP					



Front IBM Bezel 12-Bay BackP	41A	EJU4	Both	Yes	No
Front IBM Bezel 18-Bay BackP	41A	EJU8	Both	Yes	No
Front OEM Bezel 12-Bay BackP	41A	EJU9	Both	Yes	No
Front OEM Bezel 18-Bay BackP	41A	EJUA	Both	Yes	No
Front IBM Bezel 18-Bay BackP	41A	EJUB	Both	Yes	No
Front OEM Bezel 18-Bay BackP	41A	EJUF	Both	Yes	No
Specify Mode-1 & CEC Ports 2Y0	41A	EJUH	Both	Yes	No
Specify Mode-1 for EXP12SX 1&1	41A	EJV0	Both	Yes	No
Specify Mode-1 for EXP12SX 2&2	41A	EJV1	Both	Yes	No
Specify Mode-2 for EXP12SX 2&2	41A	EJV2	Both	Yes	No
Specify Mode-2 for EXP12SX 4&2	41A	EJV3	Both	Yes	No
Specify Mode-4 for EXP12SX 4&2	41A	EJV4	Both	Yes	No
Specify Mode-2 for EXP12SX 1&2	41A	EJV5	Both	Yes	No
Specify Mode-2 for EXP12SX 2&2	41A	EJV6	Both	Yes	No
Specify Mode-2 for EXP12SX 1&1	41A	EJV7	Both	Yes	No
Specify Mode-2 for EXP12SX 2&1	41A	EJVA	Both	Yes	No
Specify Mode-4 for EXP12SX 1&1	41A	EJVB	Both	Yes	No
Specify Mode-4 for EXP12SX 2&1	41A	EJVC	Both	Yes	No
Specify Mode-4 for EXP12SX 3&2	41A	EJVD	Both	Yes	No
Specify Mode-1 for EXP12SX 2&2	41A	EJVE	Both	Yes	No
Specify Mode-1 & CEC Ports 2Y0	41A	EJVF	Both	Yes	No
Specify Mode-1 for EXP24SX 1&1	41A	EJW0	Both	Yes	No
Specify Mode-1 for EXP24SX 2&2	41A	EJW1	Both	Yes	No
Specify Mode-2 for EXP24SX 2&2	41A	EJW2	Both	Yes	No
Specify Mode-2 for EXP24SX 4&2	41A	EJW3	Both	Yes	No
Specify Mode-4 for EXP24SX 4&2	41A	EJW4	Both	Yes	No
Specify Mode-2 for EXP24SX 1&2	41A	EJW5	Both	Yes	No
Specify Mode-2 for EXP24SX 2&2	41A	EJW6	Both	Yes	No
Specify Mode-2 for EXP24SX 1&1	41A	EJW7	Both	Yes	No
Specify Mode-2 for EXP24SX 2&1	41A	EJWA	Both	Yes	No
Specify Mode-4 for EXP24SX 1&1	41A	EJWB	Both	Yes	No
Specify Mode-4 for EXP24SX 2&1	41A	EJWC	Both	Yes	No
Specify Mode-4 for EXP24SX 3&2	41A	EJWD	Both	Yes	No
Specify Mode-1 for EXP24SX 2&2	41A	EJWE	Both	Yes	No
Specify Mode-2 for EXP24SX 2&2	41A	EJWF	Both	Yes	No
Specify Mode-2 for EXP24SX 2&1	41A	EJWG	Both	Yes	No
Specify Mode-2 for EXP24SX 4&2	41A	EJWH	Both	Yes	No

	41A	EJWJ	Both	Yes No
PDU Access Cord 0.38m	41A	ELC0	MES	Yes No
#ESD4 Load Source Specify	41A	ELS4	MES	Yes No
#ESDA Load Source Specify	41A	ELSA	MES	Yes No
#ESFU Load Source Specify	41A	ELT0	Both	Yes No
#ES81 Load Source Specify	41A	ELT1	MES	Yes No
#ESF2 Load Source Specify	41A	ELT2	Both	Yes No
#ESF4 Load Source Specify	41A	ELT4	Both	Yes No
#ES86 Load Source Specify	41A	ELT6	Both	Yes No
#ESF8 Load Source Specify	41A	ELT8	Both	Yes No
#ESFA Load Source Specify	41A	ELTA	Both	Yes No
#ES8D Load Source Specify	41A	ELTD	Both	Yes No
#ESFE Load Source Specify	41A	ELTE	Both	Yes No
#ES8G Load Source Specify	41A	ELTG	Both	Yes No
#ES8K Load Source Specify	41A	ELTK	MES	Yes No
#ES7L Load Source Specify	41A	ELTL	MES	Yes No
#ESFN Load Source Specify 571G	41A	ELTN	Both	Yes No
#ES8P Load Source Specify	41A	ELTP	Both	Yes No
#ES7Q Load Source Specify	41A	ELTQ	MES	Yes No
#ES8R Load Source Specify	41A	ELTR	Both	Yes No
#ESFS Load Source Specify	41A	ELTS	Both	Yes No
#ESEU Load Source Specify	41A	ELTU	Both	Yes No
#ES8W Load Source Specify	41A	ELTW	Both	Yes No
#ESEY Load Source Specify 283G	41A	ELTY	Both	Yes No
#ESNJ Load Source Specify	41A	ELUJ	Both	Yes No
#ESNL Load Source Specify	41A	ELUL	Both	Yes No
#ESNN Load Source Specify	41A	ELUN	Both	Yes No
#ESNQ Load Source Specify	41A	ELUQ	Both	Yes No
#ESE2 Load Source Specify	41A	ELZ2	Both	Yes No
#ES93 Load Source Specify	41A	ELZ3	Both	Yes No
#ES84 Load Source Specify	41A	ELZ4	Both	Yes No
#ES97 Load Source Specify	41A	ELZ7	Both	Yes No
#ESE8 Load Source Specify	41A	ELZ8	Both	Yes No
#ESGA Load Source Specify	41A	ELZA	MES	Yes No
#ESGC Load Source Specify	41A	ELZC	Both	Yes No
#ESGE Load Source Specify	41A	ELZE	Both	Yes No
#ESGJ Load Source Specify	41A	ELZJ	MES	Yes No
#ESGL Load Source Specify	41A			

	41A	ELZL	Both	Yes	No
#ESGN Load Source Specify	41A	ELZN	Both	Yes	No
#ESGQ Load Source Specify	41A	ELZQ	Both	Yes	No
#ESGS Load Source Specify	41A	ELZS	Both	Yes	No
#ES8Z Load Source Specify	41A	ELZZ	Both	Yes	No
16 GB DDR4 Memory	41A	EM62	Both	Yes	No
32 GB DDR4 Memory	41A	EM63	Both	Yes	No
64 GB DDR4 Memory	41A	EM64	Both	Yes	No
PCIe Gen3 I/O Expansion Drawer	41A	EMX0	Both	Yes	No
AC Power Supply Conduit	41A	EMXA	Both	Yes	No
PCIe3 6-slot Fanout Module	41A	EMXF	Support	Yes	No
PCIe3 6-slot Fanout Module	41A	EMXG	Both	Yes	No
1m 10GbE Cable SFP+ Act Twinax	41A	EN01	Both	Yes	No
3m 10GbE Cable SFP+ Act Twinax	41A	EN02	Both	Yes	No
5m 10GbE Cable SFP+ Act Twinax	41A	EN03	Both	Yes	No
PCIe3 16Gb 2-port Fibre Channe	41A	EN0A	Both	Yes	No
PICE3 4-port 10Gb FCoE & 1GbE	41A	EN0H	Both	Yes	No
PCIe3 4-port 10GB FCoE & 1GbE	41A	EN0K	Both	Yes	No
PCIe2 4-pt(10+1 GbE)SR+RJ45	41A	EN0S	Both	Yes	No
PCIe2 4-pt(10+1GbE)CRSR+RJ45	41A	EN0U	Both	Yes	No
PCIe2 2-pt 10/1GbE BaseT RJ45	41A	EN0W	Both	Yes	No
PCIe 1-port Bisync Adapter	41A	EN13	Support	Yes	No
PCIe3 4-port 10GbE SR Adapter	41A	EN15	Both	Yes	No
PCIe3 32Gb 2-port FC Adapter	41A	EN1A	Both	Yes	No
PCIe3 16Gb 4-port FC Adapter	41A	EN1C	Both	Yes	No
4-core 2.3/3.8 GHz POWER9	41A	EP10	Both	No	No
6-core 2.3/3.8 GHz POWER9	41A	EP11	Both	No	No
8-core 2.8/3.8 GHz POWER9	41A	EP12	Both	No	No
One Proc Activation for #EP10	41A	EP40	Both	Yes	No
One Proc Activation for #EP11	41A	EP41	Both	Yes	No
One Proc Activation for #EP12	41A	EP42	Both	Yes	No
Horizontal PDU Mounting Hardwr	41A	EPTH	Both	Yes	No
High Function 9xC19 PDU	41A	EPTJ	Both	Yes	No
High Function 9xC19 PDU 3Phase	41A	EPTL	Both	Yes	No
High Function 12xC13 PDU	41A	EPTN	Both	Yes	No
High Function 12xC13 PDU 3-Phs	41A	EPTQ	Both	Yes	No

Feature #EPZL is not available in People's Republic of China, Hong Kong S.A.R. of the PRC, Marco S.A.R. of the PRC and Taiwan.

One 0 Proc Activate for EP10		41A	EPZL	Initial	Yes	No
Feature #EPZM is not available in People's Republic of China, Hong Kong S.A.R. of the PRC, Marco S.A.R. of the PRC and Taiwan.						
One 0 Proc Activate for EP11		41A	EPZM	Initial	Yes	No
Qty 150	#ES62 3.86TB LFF Dsk	41A	EQ62	Both	Yes	No
Qty 150	#ES64 7.72TB LFF Dsk	41A	EQ64	Both	Yes	No
Qty 150	#ES78 SSD 387GB 5xx	41A	EQ78	Both	Yes	No
Qty 150	#ES7E SSD 775GB 5xx	41A	EQ7E	Both	Yes	No
Quantity 150 of	ES80 1.9TB SSD	41A	EQ80	Support	Yes	No
Quantity 150 of	ES81 1.9TB SSD	41A	EQ81	Support	Yes	No
Qty 150	#ES85 SSD 387GB 4k	41A	EQ85	Both	Yes	No
Qty 150	#ES86 SSD 387GB 4k	41A	EQ86	Both	Yes	No
Qty 150	#ES8C SSD 775GB 4k	41A	EQ8C	Both	Yes	No
Qty 150	#ES8D SSD 775GB 4k	41A	EQ8D	Both	Yes	No
Qty 150	#ES8F SSD 1.55TB 4k	41A	EQ8F	Both	Yes	No
Qty 150	#ES8G SSD 1.55TB 4k	41A	EQ8G	Both	Yes	No
Quantity 150 of	ES8Y 931GB	41A	EQ8Y	Both	Yes	No
Quantity 150 of	ES8Z 931GB	41A	EQ8Z	Both	Yes	No
Quantity 150 of	ES96 1.86TB	41A	EQ96	Both	Yes	No
Quantity 150 of	ES97 1.86TB	41A	EQ97	Both	Yes	No
Quantity 150 of	#ESE7 3.72TB	41A	EQE7	Both	Yes	No
Quantity 150 of	ESE8 3.72TB	41A	EQE8	Both	Yes	No
Quantity 150 of	#ESEU 571GB	41A	EQEU	Both	Yes	No
Quantity 150 of	#ESEV 600GB	41A	EQEV	Both	Yes	No
Quantity 150 of	#ESEY 283 GB S	41A	EQEY	Both	Yes	No
Quantity 150 of	#ESEZ 300GB	41A	EQEZ	Both	Yes	No
Quantity 150 of	#ESF2 1.2TB	41A	EQF2	Both	Yes	No
Quantity 150 of	#ESF3 1.2TB	41A	EQF3	Both	Yes	No
Quantity 150 of	#ESFN 571GB	41A	EQFN	Both	Yes	No
Quantity 150 of	#ESFP 600GB	41A	EQFP	Both	Yes	No
Quantity 150 of	#ESFS 1.7TB	41A	EQFS	Both	Yes	No
Quantity 150 of	#ESFT 1.8TB	41A	EQFT	Both	Yes	No
Quantity 150 of	#ESG5	41A	EQG5	Both	Yes	No
Quantity 150 of	#ESGB	41A	EQGB	Both	Yes	No
Quantity 150 of	#ESGC	41A	EQGC	Both	Yes	No
Quantity 150 of	#ESGF	41A	EQGF	Both	Yes	No
Quantity 150 of	#ESGK	41A	EQGK	Both	Yes	No
Quantity 150 of	#ESGL	41A	EQGL	Both	Yes	No

Quantity 150 of #ESGP	41A	EQGP	Both	Yes	No
Quantity 150 of #ESGQ	41A	EQGQ	Both	Yes	No
42U Slim Rack	41A	ER05	MES	Yes	No
RFID Tags for Compute Nodes	41A	ERF1	Initial	N/A	No
Rear rack extension	41A	ERG0	MES	Yes	No
Mainstream 400GB SSD NVMe	41A	ES14	Both	Yes	No
3.86TB 7200 RPM SAS LFF Disk	41A	ES62	Both	Yes	No
7.72TB 7200 RPM SAS LFF Disk	41A	ES64	Both	Yes	No
387GB SFF-2 SSD 5xx for AIX/L	41A	ES78	Both	Yes	No
775GB SFF-2 SSD 5xx for AIX/L	41A	ES7E	Both	Yes	No
387GB SFF-3 SSD 5xx for AIX/L	41A	ES7K	Both	Yes	No
387GB SFF-3 SSD 5xx for IBM i	41A	ES7L	Support	Yes	No
775GB SFF-3 SSD 5xx for AIX/L	41A	ES7P	Both	Yes	No
775GB SFF-3 SSD 5xx for IBM i	41A	ES7Q	Support	Yes	No
1.9TB RI SAS 4k SFF-2 SSD AIX	41A	ES80	Support	Yes	No
1.9TB RI SAS 4k SFF-2 SSD IBM	41A	ES81	Support	Yes	No
931GB Mainstream SAS 4k SSD	41A	ES83	Both	Yes	No
931GB Mainstream SAS 4k SSD	41A	ES84	Both	Yes	No
387GB SFF-2 SSD 4k for AIX/Li	41A	ES85	Both	Yes	No
387GB SFF-2 SSD 4k for IBM i	41A	ES86	Both	Yes	No
775GB SFF-2 SSD 4k for AIX/Li	41A	ES8C	Both	Yes	No
775GB SFF-2 SSD 4k for IBM i	41A	ES8D	Both	Yes	No
1.55TB SFF-2 SSD 4k for AIX/L	41A	ES8F	Both	Yes	No
1.55TB SFF-2 SSD 4k for IBM i	41A	ES8G	Both	Yes	No
1.9TB RI SAS 4k SFF-3 SSD AIX	41A	ES8J	Support	Yes	No
1.9TB RI SAS 4k SFF-3 SSD IBM	41A	ES8K	Support	Yes	No
387GB SFF-3 SSD 4k for AIX/Li	41A	ES8N	Both	Yes	No
387GB SFF-3 SSD 4k for IBM i	41A	ES8P	Both	Yes	No
775GB SFF-3 SSD 4k for AIX/Li	41A	ES8Q	Both	Yes	No
775GB SFF-3 SSD 4k for IBM i	41A	ES8R	Both	Yes	No
1.55TB SFF-3 SSD 4k for AIX/L	41A	ES8V	Both	Yes	No
1.55TB SFF-3 SSD 4k for IBM i	41A	ES8W	Both	Yes	No
931GB Mainstream SAS 4k SSD	41A	ES8Y	Both	Yes	No
931GB Mainstream SAS 4k SSD	41A	ES8Z	Both	Yes	No
1.86TB Mainstream SAS 4k SSD	41A	ES92	Both	Yes	No
1.86TB Mainstream SAS 4k SSD	41A	ES93	Both	Yes	No
1.86TB Mainstream SAS 4k SSD	41A	ES96	Both	Yes	No

1.86TB Mainstream SAS 4k SSD	41A	ES97	Both	Yes	No
S&H - No Charge	41A	ESC0	Both	Yes	No
S&H-b	41A	ESC6	Initial	N/A	No
571GB 10K RPM SAS SFF-3 Disk	41A	ESD4	Support	Yes	No
600GB 10K RPM SAS SFF3 Disk	41A	ESD5	Both	Yes	No
283GB 15K RPM SAS SFF-3 Disk	41A	ESDA	Support	Yes	No
300GB 15K RPM SAS SFF-3 Disk	41A	ESDB	Both	Yes	No
3.72TB Mainstream SAS 4k SSD	41A	ESE1	Both	Yes	No
3.72TB Mainstream SAS 4k SSD	41A	ESE2	Both	Yes	No
3.72TB Mainstream SAS 4k SSD	41A	ESE7	Both	Yes	No
3.72TB Mainstream SAS 4k SSD	41A	ESE8	Both	Yes	No
571GB 10K RPM SFF-2 Disk 4K	41A	ESEU	Both	Yes	No
600GB 10K RPM SFF-2 Disk 4K	41A	ESEV	Both	Yes	No
283GB 15K SAS SFF-2 4K BLK HDD	41A	ESEY	Both	Yes	No
300GB 15K SAS SFF-2 4K BLK HDD	41A	ESEZ	Both	Yes	No
1.1TB 10K RPM SFF-2 Disk 4K	41A	ESF2	Both	Yes	No
1.2TB 10K RPM SFF-2 Disk 4K	41A	ESF3	Both	Yes	No
571GB 10K RPM SFF-3 Disk 4K	41A	ESF4	Both	Yes	No
600GB 10K RPM SFF-3 Disk 4K	41A	ESF5	Both	Yes	No
1.1TB 10K RPM SFF-3 Disk 4K	41A	ESF8	Both	Yes	No
1.2TB 10K RPM SFF-3 Disk 4K	41A	ESF9	Both	Yes	No
283GB 15K SAS SFF-3 4K BLK HDD	41A	ESFA	Both	Yes	No
300GB 15K SAS SFF-3 4K BLK HDD	41A	ESFB	Both	Yes	No
571GB 15K SAS SFF-3 4K BLK HDD	41A	ESFE	Both	Yes	No
600GB 15K SAS SFF-3 4K BLK HDD	41A	ESFF	Both	Yes	No
283GB 15k SAS SFF-3 Disk 4k	41A	ESFG	Initial	N/A	No
571GB 15K SAS SFF-2 4K BLK HDD	41A	ESFN	Both	Yes	No
600GB 15K SAS SFF-2 4K BLK HDD	41A	ESFP	Both	Yes	No
1.7TB 10K RPM SFF-2 Disk 4K	41A	ESFS	Both	Yes	No
1.8TB 10K RPM SFF-2 Disk 4K	41A	ESFT	Both	Yes	No
1.7TB 10K RPM SFF-3 Disk 4K	41A	ESFU	Both	Yes	No
1.8TB 10K RPM SFF-3 Disk 4K	41A	ESFV	Both	Yes	No
387GB Enterprise SAS 5xx SSD	41A	ESG5	Both	Yes	No
387GB Enterprise SAS 5xx SSD	41A	ESG9	Both	Yes	No
387GB Enterprise SAS 5xx SSD	41A	ESGA	Support	Yes	No
387GB Enterprise SAS 4k SSD	41A	ESGB	Both	Yes	No
387GB Enterprise SAS 4k SSD	41A	ESGC	Both	Yes	No

387GB Enterprise SAS 4k SSD	41A	ESGD	Both	Yes	No
387GB Enterprise SAS 4k SSD	41A	ESGE	Both	Yes	No
775GB Enterprise SAS 5xx SSD	41A	ESGF	Both	Yes	No
775GB Enterprise SAS 5xx SSD	41A	ESGH	Both	Yes	No
775GB Enterprise SAS 5xx SSD	41A	ESGJ	Support	Yes	No
775GB Enterprise SAS 4k SSD	41A	ESGK	Both	Yes	No
775GB Enterprise SAS 4k SSD	41A	ESGL	Both	Yes	No
775GB Enterprise SAS 4k SSD	41A	ESGM	Both	Yes	No
775GB Enterprise SAS 4k SSD	41A	ESGN	Both	Yes	No
1.55TB Enterprise SAS 4k SSD	41A	ESGP	Both	Yes	No
1.55TB Enterprise SAS 4k SSD	41A	ESGQ	Both	Yes	No
1.55TB Enterprise SAS 4k SSD	41A	ESGR	Both	Yes	No
1.55TB Enterprise SAS 4k SSD	41A	ESGS	Both	Yes	No
Specify AC Power Supply	41A	ESLA	Both	Yes	No
EXP12SX SAS Storage Enclosure	41A	ESLL	Both	Yes	No
EXP24SX SAS Storage Enclosure	41A	ESLS	Both	Yes	No
283GB 15K SAS SFF-3 4k HDD	41A	ESNJ	Both	Yes	No
300GB 15K SAS SFF-3 4k HDD	41A	ESNK	Both	Yes	No
283GB 15K SAS SFF-2 4k HDD	41A	ESNL	Both	Yes	No
300GB 15K SAS SFF-2 4k HDD	41A	ESNM	Both	Yes	No
571GB 15K SAS SFF-3 4k HDD	41A	ESNN	Both	Yes	No
600GB 15K SAS SFF-3 4k HDD	41A	ESNP	Both	Yes	No
571GB 15K SAS SFF-2 4k HDD	41A	ESNQ	Both	Yes	No
600GB 15K SAS SFF-2 4k HDD	41A	ESNR	Both	Yes	No
Quantity 150 of #ESNL 283GB	41A	ESPL	Both	Yes	No
Quantity 150 of #ESNM 300GB	41A	ESPM	Both	Yes	No
Quantity 150 of #ESNQ 571GB	41A	ESPQ	Both	Yes	No
Quantity 150 of #ESNR 600GB	41A	ESPR	Both	Yes	No
RDX USB Internal Docking	41A	EU00	Both	Yes	No
1TB Removable Disk Cartridge	41A	EU01	Both	Yes	No
RDX USB External Docking	41A	EU04	Support	Yes	No
RDX 320 GB Removable Disk Driv	41A	EU08	Support	Yes	No
Operator Panel LCD Display	41A	EU0B	Both	Yes	No
1.5TB Removable Disk Cartridge	41A	EU15	Support	Yes	No
Cable Ties & Labels	41A	EU19	Both	Yes	No
Express Edition 4 core IBM i	41A	EU2C	Initial	N/A	No
Express Edition 6-core IBM i					

2TB Removable Disk Cartrdg-RDX	41A	EU2D	Initial	N/A	No
	41A	EU2T	Both	Yes	No
RDX USB External Docking Sta	41A	EUA4	Both	Yes	No
	41A	EUA5	Both	Yes	No
Standalone USB DVD drive w/c	41A	EUA5	Both	Yes	No
	41A	EUC6	MES	Yes	No
Core Use HW Feature	41A	EUC6	MES	Yes	No
	41A	EUC7	MES	Yes	No

The following are newly announced features on the specific models of the IBM Power Systems 7014 and 7965 machine type:

Description	Model	Feature	Purchase	Minimum	Initial/	RP
Machine type	7014	number	price	Monthly	Monthly	CSU
		number		Charge	MES/	MES
					Both/	
					Support	
Rack Specify	9009-41A	-4EIA			Initial	N/A
		T00	ER2X		Initial	N/A
		T42			Initial	N/A

Description	Model	Feature	Purchase	Minimum	Initial/	RP
Machine type	7965	number	price	Monthly	Monthly	CSU
		number		Charge	MES/	MES
					Both/	
					Support	
Rack Specify	9009-41A	-4EIA			Initial	N/A
		94Y	ER2X		Initial	N/A
		S42			Initial	N/A

CSU = Customer setup

RP MES = Return parts, miscellaneous equipment specifications

## Pricing terms

---

Prices in the following PDF prices link are suggested list prices on day of announcement for the U.S. only. They are provided for your information only. Dealer prices may vary, and prices may also vary by country. IBM list price does not include tax or shipping and is subject to change without notice.

[ENUS-118-023-LIST\\_PRICES\\_2018\\_02\\_13.PDF](#)

## Annual minimum maintenance charges

---

Not applicable

## ServiceElect (ESA) charges

---

For ServiceElect (ESA) maintenance service charges, contact IBM Global Services at 888-IBM-4343 (426-4343).

## IBM Global Financing

---

IBM Global Financing offers competitive financing to credit-qualified customers to assist them in acquiring IT solutions. Offerings include financing for IT acquisition, including hardware, software, and services, from both IBM and other manufacturers or vendors. Offerings (for all customer segments: small, medium, and large enterprise), rates, terms, and availability can vary by country. Contact your local



IBM Global Financing organization or go to the [IBM Global Financing](#) website for more information.

IBM Global Financing offerings are provided through IBM Credit LLC in the United States and other IBM subsidiaries and divisions worldwide to qualified commercial and government customers. Rates are based on a customer's credit rating, financing terms, offering type, equipment type and options, and may vary by country. Other restrictions may apply. Rates and offerings are subject to change, extension, or withdrawal without notice.

Financing solutions from IBM Global Financing can help you stretch your budget and affordably acquire the new product. But beyond the initial acquisition, our end-to-end approach to IT management can also help keep your technologies current, reduce costs, minimize risk, and preserve your ability to make flexible equipment decisions throughout the entire technology lifecycle.

---

## Order now

---

To order, contact the IBM Digital Sales Center, your local IBM representative, or your IBM Business Partner. To identify your local IBM representative or IBM Business Partner, call 800-IBM-4YOU (426-4968). For more information, contact the IBM Digital Sales Center.

Phone: 800-IBM-CALL (426-2255)

Fax: 800-2IBM-FAX (242-6329)

For IBM representative: [askibm@ca.ibm.com](mailto:askibm@ca.ibm.com)

For IBM Business Partner: [pwcs@us.ibm.com](mailto:pwcs@us.ibm.com)

IBM Digital Sales Offices 1177 S Belt Line Rd Coppell, TX 75019-4642, US

The IBM Digital Sales Center, our national direct marketing organization, can add your name to the mailing list for catalogs of IBM products.

**Note:** Shipments will begin after the planned availability date.

### **Trademarks**

POWER9, Power Systems, EnergyScale, Electronic Service Agent, Watson and HACMP are trademarks of IBM Corporation in the United States, other countries, or both.

IBM, Power, PowerVM, AIX, POWER, PartnerWorld, Global Technology Services, POWER8, POWER7, Express and PowerPC are registered trademarks of IBM Corporation in the United States, other countries, or both.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Other company, product, and service names may be trademarks or service marks of others.

### **Terms of use**

IBM products and services which are announced and available in your country can be ordered under the applicable standard agreements, terms, conditions, and prices in effect at the time. IBM reserves the right to modify or withdraw this announcement at any time without notice. This announcement is provided for your information only. Additional terms of use are located at

[Terms of use](#)

For the most current information regarding IBM products, consult your IBM representative or reseller, or go to the [IBM worldwide contacts page](#)

[IBM United States](#)

---

## Corrections

---

**(Corrected on March 27, 2018)**

The Description and Operating environment sections were revised.

**(Corrected on February 23, 2018)**

The Description and Hardware requirements sections were revised.